









Assembly Exploded Diagram






Gear box assembly




7

Left tire





8

Right tire








9



Front left steering hub assembly





10











R2835
Battery holder B

R2835
Battery holder A

R2821
Screws 2x6KB D3.5

20



R2836
Servo holder

R2858
Servo

R2821
Screws 2x6KB D3.5

21

