Owner's Manual




DiamondBoxx 40TWS

Box Contents

DiamondBoxx 40TWS Speaker 3.5mm stereo (TRS) audio cable Charging cable Owner's manual Power adapter

Control Panel



I. Power Button

Press and hold for three seconds to turn on/off

2. Previous Button

Press to navigate between tracks

Use to play and pause audio

3. Play / Pause Button

While in Bluetooth mode, press and hold to activate Siri or S-Voice Press again to disable

Incoming call: press once to answer, press again to end. Press and hold to decline call

4. Next Button

Press to navigate between tracks

Control Panel

5. Mode Button

Use this button to toggle between Bluetooth / Aux / USB modes Press and hold this button to pair in TWS mode (see TWS pairing section)


If there is no AUX cable inserted, speaker will automatically enter Bluetooth mode by default When in Bluetooth mode, press to initiate Bluetooth pairing

7. Charging Indicator

Flashing Red: Battery is low Solid Green: Speaker is charging

Control Panel

8. Battery Level Indicator



Control Panel

9. Volume Down Button

10. Proximity Sensor

Detects human hand proximity and activates LED button back-lighting

11. Microphone

Remain within 3 feet of microphone while speaking

12. Aux Indicator

When AUX cable is inserted into speaker, device will automatically enter AUX mode. When solid green indicator is light is on, AUX mode is enabled.

13. Volume Increase Button


Control Panel

14. Bluetooth Indicator

When Bluetooth is in pairing mode the indicator will be flashing Blue. Once a device has been paired, indicator will be solid blue. Indicator may also be yellow or purple (See TWS pairing Section)

Hold your device over this area to use NFC for Bluetooth Connection. "DiamondBoxx 40TWS" should pop up on the bluetooth device list of your bluetooth audio device, select it to connect

Rear Panel



Rear Panel

16. AUX IN Jack

Connects speaker to external media devices

17. AUX OUT Jack This is for headphone use

18. USB-C Jack

This is for charging the DiamondBoxx 40TWS

19. USB Power Jack

This is for charging your phone or other device. Speaker must be turned on to enable output Provides 5V, I A output

20. Reset Button

Press to reset speaker should operational issue occur

TWS (True Wireless Stereo) Pairing Instructions

TWS (True Wireless Stereo) *Two DiamondBoxx 40TWS are required

Start with both speakers powered off Power on one speaker

Pair this speaker with bluetooth audio source

Once speaker is successfully paired with bluetooth device, press and hold its MODE button for 2 seconds

Speaker is ready for TWS pairing when bluetooth LED flashes blue and purple. Power on 2nd speaker and make sure its bluetooth is not connected to anything Wait for 15-60 seconds.

A tone will sound when the two speakers have been

connected via TWS. The main (connected to audio source) speaker will be the left channel and its bluetooth LED should be solid purple. The secondary speaker will be the right channel and its bluetooth LED should be solid yellow.

12

TWS (True Wireless Stereo) Pairing Notes

TWS function available only in Bluetooth and AUX modes. Does not work with USB mode

There is no memory for TWS function, that is they will not automatically re-pair in TWS mode if speakers have been powered off since pairing last. Follow the above instructions for TWS pairing again

Instructions

Bluetooth

- I. Power on speaker and hold your phone or other device within 3 feet of speaker, press Bluetooth Button and the speaker will enter pairing mode and the Bluetooth LED will flash blue
- 2. Pairing mode will be cancelled (indicated by a beep) after 3 minutes. To re-enter pairing mode go back to step 1.
- 3. Ensure Bluetooth is enabled on the device you wish to pair
- 4. The speaker will appear as "DiamondBoxx 40TWS" in the list.
- 5. Select "DiamondBoxx 40TWS" from the list, if prompted for a PIN enter 0000.
- 6. When device is successfully connected Bluetooth LED will be solid Blue.

Instructions

- 7. When in Bluetooth mode you can switch to AUX mode by inserting an AUX cable
- 8. Incoming calls will override music and other media with an incoming call voice prompt. Press the Play/Pause button to answer/end or press and hold to decline the call.
- 9. Press and hold Play/Pause button for 3 seconds to activate Siri or S-Voice

- I. TWS Speaker with DiamondBoxx engineered sound
- 2. MaxxBass Technology

Features

- 3. Bluetooth, NFC, and AUX connection capability
- 4. 10 hours of playtime (at 50% volume)
- 5. Built-in phone functionality allows you to answer or decline incoming calls
- 6. Hands free calling with integrated microphone
- 7. Supports Siri and S-Voice
- 8. LED Power / Charging status indicator
- 9. Proximity sensor automatically activates LED backlighting of buttons 15
- 10. Auto Power-Off after 40 minutes idle for battery saving

Specifications

Bluetooth version 5.0 Battery Voltage 7.4V Charging Voltage 5V DC Power Output 20W RMS x 2 = 40W RMS Frequency Response 50 Hz - 18kHz Battery capacity 17Wh , 7.4V 4400mAh 18650 x 2 THD < 0.1% SNR > 80dB Dimensions = 2.9" x 3.3" x 8.6" Dimensions = 77mm x 85mm x 218mm

Caution

Proper Use

- 1. To prevent damage do not expose to shock, vibration or water
- 2. Do not expose to flame or high heat
- 3. Always use on a level surface or vibrations may cause it to slide and fall
- 4. Do not use excessive force on buttons or grille
- 5. To clean use a cloth dampened with water

17

Caution

Safety

To prevent fire, shock, or injury, please do not disassemble or replace any parts of this speaker. In the event that your device becomes damaged or in need of repair, please contact DiamondBoxx or a qualified repair center for assistance. We are not responsible for any personal injury or property damage caused by improper use of this product.

Please do not allow the use of this speaker buy children without adult supervision

18

19

20