

## PRODUCT USE GUIDE



www.marvo-tech.com

QUICK INSTALLATION GUIDE

# GT-64

## PS4 WIRELESS GAMEPAD

### TECH SPECS

Connection: wireless or wired (USB cable)  
 Wireless versions: V4.2  
 Buttons: 15  
 Battery capacity: 600 mA  
 Speaker: 6/BQ-1W  
 Interface: EXT support, 3.5 mm jack  
 Compatibility: PS4 and \*PC (D-INPUT/X-INPUT/PS3)  
 Sensor: 3D-Sensor, G-Sensor  
 Micro USB cable: 80 cm

QUICK INSTALLATION GUIDE

### PRODUCT PRESENTATION


#### 1. FEATURES

- Wireless gamepad with built-in battery
- Double vibration effect
- Big blue LED light bar
- Wired mode (X-input) available on PC
- Motion sensor: 3D-Sensor + G-Sensor
- 3.5 mm stereo headset jack support

#### 2. SYSTEM REQUIREMENTS

PC system or compatible with one USB port available and Windows 7 or newer operating system, PS4, and \*PC (D-INPUT/X-INPUT/PS3) device.

QUICK INSTALLATION GUIDE



QUICK INSTALLATION GUIDE

### SAFETY NOTES

- Keep the equipment dry. Keep away from precipitation, humidity, all types of liquids and condensation.
- Do not use the product with wet hands.
- Do not use or store the equipment in dusty or dirty areas.
- Do not store the equipment under high-temperature or low-temperature conditions (this may damage it).
- Do not drop, knock or shake the equipment as it may damage it.

### INSTALLATION

#### C1. PS4/ PS3 Connection

When the gamepad is not connected to the current PS4/ PS3 host, you first need to use a USB cable to communicate with the PS4/ PS3 host. When the USB is connected, press the PS button, the LED will be on and the main unit will be connected.

#### C2. PC Connection

The gamepad is supported by USB cable. D-input, X-input are automatically recognized for plug and play; On power up, the default is D-input. To switch to X-input mode, you can switch by pressing and holding the SHARE and TOUCH for 3 seconds.

www.marvo-tech.com


QUICK INSTALLATION GUIDE

### USE

#### 1. PS4 & PC Key functions

	Button Function													
	□	△	○	×	L1	R1	L2	R2	SHARE	OPTION	L3	R3	PS	TOUCH
PS4	1	2	3	4	5	6	7	8	9	10	11	12	13	14
PC	X	A	B	Y	L.B	R.B	L.T	R.T	BACK	START	L3	R3	/	/

#### 2. 3D-Sensor and G-Sensor



X axis: The acceleration motion of the X axis (X+/X-direction motion) is: left → right, right → left;

Y-axis: Acceleration motion of the Y-axis (Y+/Y-direction motion), the action is: front → back, back → front;

Z axis: acceleration motion of Z axis (Z+/Z-direction motion), the action is: up → down, down → up;

Roll axis (left and right tilt): The Y axis is tilted left and right as the center axis, and the action is: horizontal → left tilt, horizontal → right tilt;

Pitch axis (tilt back and forth): rotates back and forth with the X axis as the center axis. The action is: horizontal → front tilt, horizontal → rear tilt.

Yaw axis: (left and right rotation): The left and right rotations are centered on the Z axis. The actions are: horizontal → left rotation, horizontal → right rotation.

QUICK INSTALLATION GUIDE

### TROUBLESHOOTING

If the gamepad does not vibrate or it is not recognized, please check that the game you are trying to play supports vibrations effects.

In case of incorrect operation follow the steps below:

- Check the integrity of the connectors;
- Check the connection to the device;
- Check your device settings;
- Disconnect and reconnect the equipment; restart the device.

If the problem persists, please contact your local seller.

### GENERAL INFORMATION

- Unauthorized repairs or disassembly of the product will void the warranty and may cause its damage.

- This product is safe and complies to EU requirements.

- This product is manufactured conforming with the European RoHS standard.

This standard was introduced to reduce the amount of electrical and electronic waste emitted into the atmosphere.

- Using the WEEE symbol (the crossed-out bin) indicates that this product is not household waste. When recycling waste properly, you protect the environment and people health. Segregated household waste collection, aids recycle materials and components used for the production of this device. For detailed information about recycling, please contact your retailer or a local authority.

QUICK INSTALLATION GUIDE

QUICK INSTALLATION GUIDE

### Warranty Card

Product Model: \_\_\_\_\_

Product Serial No: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_

Customer Name: \_\_\_\_\_

TEL: \_\_\_\_\_

Address: \_\_\_\_\_

Distributor Name: \_\_\_\_\_

TEL: \_\_\_\_\_

Warranty Card is the important certificate for after-sale service of Marvo products, please keep it safe.

www.marvo-tech.com

QUICK INSTALLATION GUIDE

**BORN FOR GAMING**



FACEBOOK Scan Me



Want to Know More? Scan Me