DESIGN BY SHENZHEN MARK TECHNOLOGY CO., LTD. BRAND / 品牌 PARTS/配件 This Design Is Protected By Intellectual Property Law. You Shall Not Have The Right To Duplicate, Reproduce, Copy, distribute Or Disseminate It. You Shall Take All Reasonable Precautions To Ensure Against Any Breach Of Confidentiality. MARVO 此款设计受知识产品版权法保护。 您无权复制,仿造或分发,传播雷同设计。 您应采取一切必要措施保证此设计的保密性。 SKU CODE / 产品型号 PACK TYPE / 包装类型 SIZE / 尺寸 MATERIAL / 材质 说明书 **GT-84** 80g书写纸 140_(L)*90_(W)mm **VERSION** V1.0 **V2.0** V3.0 V4.0 V5.0 | V6.0 V7.0 **REPRO** PRINT PROCESS / 平板胶印 WARNISH / 表面处理/工艺 LINA LINA 双面印刷 风琴折 90% Black 22/03/14 21/11/16 免责声明

PRODUCT USE **GUIDE**

GT-84

WIRELESS GAMEPAD

TECH SPECS

INSTALLATION

GUIDE

Number of buttons: 15 Analog sticks: 2 Interface: USB 2.0/MICRO MICRO cable length: 80cm Joystick/keys life: 1 million times Built-in battery: 600mAh Speaker: 6/8Ω-1W Interface: EXT support, 3.5 mm jack Sensor: 3D-Sensor, G-Sensor Wireless specification: 4.2+2.1EDR Operating distance: 10m Compatibility: Wireless support: PS4/IOS13/Android

Wired support: PC/D-INPUT/ PS3

INSTALLATION GUIDE


PRODUCT PRESENTATION

1. FEATURES

Eraonomic design Two analog mini sticks bring more comfortable and convenient using experience Dual left and right vibration motors provide realistic vibration feedback

2. SYSTEM REQUIREMENTS

Wired compatible with PS3, D-INPUT or PC system Wireless compatible with PS4, IOS13, Android.



INSTALLATION

GUIDE

INSTALLATION

SAFETY NOTES

- Keep the equipment dry. Keep away from precipitation, humidity, all types of liquids and condensation.
- Do not use the product with wet hands.
- Do not use or store the equipment in dusty or dirty areas.
- Do not store the equipment under high-temperature or low-temperature conditions (this may damage it).
- Do not drop, knock or shake the equipment as it may damage it.

INSTALLATION

1. Connect USB port of the gamepad to equipment correctly, 2. Check whether the equipment can recognize the gamepad;

3. Operate according to User Manual; 4. Please do not use the product in an extreme environment


www.marvo-tech.com

MARVO

INSTALLATION

GUIDE USE

Gamepad button functions: Arrow keys: up, down, left, right



The LED indicates whether the MODE button is active or not.

1. PS4 console online method

(1) When the gamepad is first connected to the PS4 host, a USB cable is required to make a wired connection to the PS4 host. The program automatically conducts code pairing during the connection process.

(2) Press the PS button, the gamepad for wireless connection state, at this time the LED light shows one color is always on, that is, connected to the host. Different gamepad connected to the host, LED lights show different colors to distinguish

INSTALLATION GUIDE

between different users.

(3) The general PS4 host supports multiple wireless devices, and the gamepad supports the PS4 series of games.

2. IOS13.0 or above system connection method

(1) The gamepad support Apple devices in IOS13.0 or above system connection, support Apple Store inside the game operation, compatible with the Apple system, can support alloy slug 3, my world, wild ride 8 and other games.

(2) Currently the gamepad does not support touch, 6-axis, vibration for the time being, consistent with the original handle.

(3) Connection method

② When the gamepad is off, press and hold the (SHARE+PS) keys for 3s, the gamepad enters the pairing state and the white light flashes;

③ Open iPhone & iPad device, click "Wireless" option, find the "DUALSHOCK 4 Wireless Controller", click connect to the device after the light shows pink, if not connected to the device, the gamepad about 60s to shut down hibernation; when the gamepad is connected to the host, if you need to shut down the gamepad, long press the PS button for 10s to shut down.

(1) The gamepad in the off state, long press (SHARE + PS) keys for 3s, the gamepad into the pairing state, then the white light flashing, open the device search the "Wireless Controller", click connect to the device after the light shows white, if not connected to the device, the gamepad about 60s to shut down hibernation; when the gamepad is connected to the host, if you need to turn off the gamepad, long press the PS button for 10s to shut down.

(2) Games supported by Android devices: Grape Game Room, Battle of the Bands, Alloy Slug 2, Dinosaur Express, Contra, etc.

INSTALLATION GUIDE

4. PC connection method

Wired connection: The gamepad is connected to the PC by one USB cable, the PC will automatically install the driver, and you can see the driver being installed directly in the interface of WIN7/10. After the driver is installed, the icon of the controller will appear in the interface of "Devices and Printers", and the name of the device is "Wireless Controller"

TROUBLESHOOTING

s not vibrate or it is not recognized, please check that the

- game you are trying to play supports vibrations effects. In case of incorrect operation follow the steps below:
- Check the integrity of the connectors;
- Check the connection to the device; - Check your device settings;
- Check the battery level;
- Disconnect and reconnect the equipment; restart the device.

If the problem persists, please contact your local seller.

GENERAL INFORMATION

- Unauthorized repairs or disassembly of the product will void the warranty and may cause its damage.
- This product is safe and complies to EU requirements.
- This product is manufactured conforming with the European RoHS standard.
- This standard was introduced to reduce the amount of electrical and electronic

INSTALLATION GUIDE

waste emitted into the atmosphere.

- Using the WEEE symbol (the crossed-out bin) indicates that this product is not household waste. When recycling waste properly, you protect the environment and people health. Segregated household waste collection, aids recycle materials and components used for the production of this device. For detailed information about recycling, please contact your retailer or a local authority.

Warranty Card

Product Model:

Product Se	ial No:		
Date of Pur	chase:		
Customer N	lame:		
TEL:			
Address:_			
TEL:			

Warranty Card is the important certificate for after-sale service of Marvo products, please keep it safe.

NOTE: Specifications and design are subject to change without notice due to product improvements.

BORN FOR GAMING



