


Please read and understand this manual carefully before using this product.




1. SAFETY WARNING & INSTRUCTIONS 1. When shipping this device, make sure that it is always powered down

- 2. This device is not suitable for: people under the age of 18 years; This tobacco product damages your health and is addictive.
- 3. Keep this device and its components out of reach of children and pets.
- 4. Keep this device in room temperature. Do not expose the device to excessive heat or humidity
- 5. Do not immerse any part or component of the device in water.
- 6. Do not use this device where flammable substances, liquids, gases, or oxygen are present
- 7. Do not use this device during charging.
- 8. Do not use a charging device that does not meet the requirements for charging.
- 9. Before cleaning, opening, or making direct contact with the internal heating components, you must ensure that the device main body has cooled down.
- 10. Please use and keep the device at an ambient temperature of 5 ~ 40 °C. A lower or higher temperature environment may temporarily reduce battery life or cause damage to the device.
- 11. If you notice any abnormal situation such as odor or smoke. please stop charging and using immediately, and contact your service provider.
- 12. If the battery leaks from the product, please avoid contact with the skin and eyes. If you accidentally touch it, wash affected areas with clean water immediately and consult a doctor
- 13. The precautions contained in the user guide cannot cover all










Possible solution

27mm (L) X 17mm(W) X 90mm(H)

51 grams





To start the TA mode, click the button once and then 5 times quickly. The LED light will blink green, white and purple alternatively. When the LED light stops blinking, click the button to change the temperature heating mode.

Press and hold the power button to confirm the heating mode or wait for 10 seconds to guit the TA mode.

Make sure the device is switched off and cooled down before attempting to clean it.


- 1. Separate the top cover from the main body
- 2. Pull out the heating pin from the main body.











7. TROUBLESHOOTING

Product Size

Product Weight

Capacity at full charge

Can't insert the	Check if tobacco residue	
tobacco stick	from previous tobacco	Clean the heating
into the	stick is stuck in the	chamber.
heating chamber.	heating chamber.	1
Can't insert the	Check if the slot between	
tobacco stick	the tobacco stick holder	Clean the heating
into the	and the heating chamber	chamber.
heating chamber.	is aligned and fastened properly.	
The Cap can't	Check alignment between	
close and clip	the cap and device, make	Adjust the direction
properly	the tobacco stick hole is in	of buckling
property	the same position.	Of Buckling
Can't start the device		Charge the device
	Check the leftover power	until the charge is
		complete
		deplete power fully, ther
	Not used for a long time?	recharge fully
	Button damaged?	Send it to the local
	_	service center.
	Indicator light damaged?	Send it to the local
		service center.
Blinking red light	The leftover battery	Charge the device
for 5 seconds	capacity is low	at once.
Solid red light and		
gap vibration for	Check heating pin	Change heating pin.
3 seconds		

Troubleshoot

8. GENERAL INFORMATION

Manufacturer: Dongguan Mysmok Electronic Technology Co.,Ltd Distributor: ISMOD UK LTD

For all warranty information or to register your device, please visit https://www.ismodeurope.com - https://www.ismod.co.uk

9. DISCLAIMERS

- 1. The ISMOD NANO is battery powered. It needs to get recharged when the battery is low. Do not put the ISMOD NANO near the high-temperature environment or heater to avoid battery damage.
- 2. Read all the instructions carefully before you use the ISMOD NANO. Keep the User Guide for future reference. When using the ISMOD NANO, follow the manufacturer's instructions to avoid the possibility of injuries. The warnings and safety instructions in this User Guide cannot include all the possibilities and situations that may occur. Be cautious when you use or maintain any personal electronic product.
- 3. Only use compatible tobacco heat sticks.
- 4. ISMOD NANO contains lithium batteries, for their disposal, please follow the requirement of your local authority.

☆ LITHIUM BATTERY

- 1. If the product is kept at a high temperature for a long time, the degradation of the lithium battery will happen.
- 2. The battery will discharge when it is stored for a long time without operation. Please recharge the device before using it.
- 3. When you do not use the device for a long time, avoid storing the device in fully-charged status or under high temperature / humidity condition in order to avoid accelerated deterioration of the battery
- 4. Please do not put the battery into a fire to prevent the danger of explosion.

