



※ Please register your product at
www.vovo-us.com/pages/register
★ to receive full warranty benefit.★

ENGLISH
FRENCH
SPANISH



IMUNSEN AIR PURIFIER

Imunsen Air Purifier for Vehicle User Manual



Dear Customers

Thank you very much for purchasing the Imunsen air purifier.

Please read the manual carefully for correct and safe use.

This manual includes the warranty. Please note the date and the location of the purchase, and keep the manual at a safe place.

Table of Contents

Precautions

Precautions	03
-------------	----

Product Introduction

Basic Components	06
Part Names	07

User Guide

Assembling Guide	08
Installation Guide	12
Product Functions	13

Maintenance

Managing the Product	14
Cypress Wood Filter	17
Warranty Period	19

Product Information

Product Specification	20
FAQ	21
Warranty	26

Precautions

Precautions



Moving the product.

Please switch off the product and unplug the power cable before moving the product.



Installation

Do not install the product where there is a flammable gas leak or the possibility of a leak. Keep the product out of direct sunlight, excessive heat, and water. Do not install the product on uneven or inclined surfaces. Do not install the product where there is a lot of industrial oil, smoke or metallic dust. Install the product so the inlet and the outlet of the product is not completely blocked.

In the vehicle

Do not install the product in locations besides the vehicle cup holder. Fix the product firmly to the vehicle cup holder. Place the product firmly into the vehicle cup holder. Product fits into cupholders with 75mm diameter and 50mm height or more. Only available for vehicles with voltage of DC 5V.



When using

Do not let water or foreign objects inside the product. Do not touch the power cord with wet hands. Do not put foreign objects or fingers inside the air inlet and outlet. When used with heaters, it is necessary to ventilate in order to prevent carbon monoxide poisoning. Do not unplug the power cord while the product is running.

Precautions

Precautions

In the vehicle

When using the product, the proper temperature is 0 ~ 40 °C. Proper temperature for storing the product is -10 ~ 70 °C. Be careful not to spill liquids such as water or drinks on the bottom of the cup holder. Do not place the product in direct sunlight.



When using

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they do not play with the appliance.
3. The instructions for appliances having a part of a class III construction supplied from a detachable power supply unit shall state that the appliance is only to be used with the power supply unit provided with the appliance.
The instructions for class III appliances shall state that it must only be supplied at safety extra-low voltage corresponding to the marking on the appliance.

Precautions

Precautions



Restrictions on use

In the event of anomalies such as strange smells, sounds, high temperatures, or irregular winds from the product, please immediately stop using the product. If the product is submerged in water, contact the service center. Do not let the moisture emitted from the humidifier directly exposed to the product. Do not use in places with high temperature or high humidity. Do not disassemble, repair or remodel the product. Do not place heavy objects on the product or subject it to a shock.



Cleaning

Please make sure to switch off the product before cleaning. Do not spray water on the product or wipe it with benzene, thinner, alcohol, acetone, etc. Do not disassemble and clean the insides of the product.

READ AND SAVE THESE INSTRUCTIONS


- Power related arbitrarily change or extend the power line.
- Do not bend or pull the power plug forcibly.
- Do not install the product where gas may leak.
- Use it while the plug is fully inserted for the power plug not to be shaken.
- Avoid direct skin contact, such as putting a nose on the filter to smell it or touching the filter that in use

Product Introduction

Basic Components



Main Body




Cypress Wood Filter (1)



Circular filter




User Guide,
Warranty



C type Charging Cable
USB Car Charger Adapter

Product Introduction

Part Names



User Guide

Assembling Guide



1. Please remove the vinyl cover from the base.



2. Pull off the protection film on the cypress wood filter.



3. Please connect the USB cable into the product.

User Guide

How to Separate Cypress Oil Capsule from the Device (optional)



Scan here to purchase the diffuser pod!



1. Turn the bottom part of the device counter-clockwise to separate the filter.



2. Find the capsule holder on the upper side of the filter and pull it out.



3. Separate the Cypress Oil Capsule from the capsule holder.



4. Peel off the protective film from the capsule.

Insertion of the capsule follows the same process.

Guide d'utilisation

Comment séparer
la capsule d'huile
de cyprès de l'appareil
(en option)



Scannez ici pour
acheter la dosette
de diffuseur !



1. Tournez la partie inférieure de l'appareil dans le sens inverse des aiguilles d'une montre pour détacher le filtre.



2. Recherchez le support de la capsule sur le côté supérieur du filtre et retirez-le.



3. Retirez la capsule d'huile de cyprès de son support.



4. Enlevez le film protecteur de la capsule.

**Insérer la capsule en suivant
le même processus.**

Guía del usuario

Cómo separar
la cápsula de aceite
de ciprés del dispositivo
(opcional)



¡Escanee aquí para
comprar la cápsula
difusora!



1. Gire la parte inferior
del aparato en sentido
contrario a las agujas
del reloj para separar
el filtro.



2. Encuentre el
portacápsulas en la
parte superior del
filtro y sáquelo.



3. Separe la cápsula
de aceite de ciprés del
portacápsulas.



4. Retire la película
protectora de la
cápsula.

La introducción de la cápsula
sigue el mismo proceso.

User Guide


Installation Guide

Indoor Use



Do not install on bumpy or inclined floors

In the vehicle,



The product fits into cupholders with 75mm/2.9inch diameter and 50mm/1.9inch height or more.

User Guide

Product Functions



Power

Power on / Power off

Press the button for more than 1.5 seconds to turn it ON / OFF.



Wind Speed (3 Levels)

Press the button to adjust the fan speed

Low > Medium > High level in order.

Low  Medium  High 



Filter Replacement Indicator

Automatic Filter Replacement Indicator

LED indicator will blink for 5 seconds to let you know to replace the filter when the device is turned on.

After replacing the filter, push the power button for 3 seconds and the LED light will stop blinking.

Maintenance

Managing the Product



Scan here to purchase the True HEPA filter!

Exterior Cleaning

1. Use a vacuum cleaner to remove the dust from the air inlet and outlet.
2. Use a soft cloth to gently wipe the exterior.



Filter Cleaning

1. Remove the pre-filter from the product.
2. Use a vacuum cleaner to remove large dust from the pre-filter.



Do not wash with water, if so, filter life will be reduced



Remove the circular filter by holding the base and the upper part and turning them in the opposite direction.

Recommended replacement cycle for the circular filter is 1 year.

Guide d'utilisation

Fonctions du produit



Alimentation

Marche/Arrêt

Appuyez sur le bouton pendant plus de 1,5 seconde pour l'allumer ou l'éteindre.



Vitesse du ventilateur (3 niveaux)

Appuyez sur le bouton pour modifier la vitesse du ventilateur

Niveau Bas > Moyen > Haut dans l'ordre.

Bas  Moyen  Haut 



Indicateur de Remplacement du Filtre

Indicateur Automatique de Remplacement du Filtre

Lorsqu'il est temps de remplacer le filtre, le voyant LED commencera à clignoter pendant 5 secondes.

Veuillez appuyer sur le bouton d'alimentation pendant 3 secondes après avoir remplacé le filtre pour arrêter le clignotement.



Guía del usuario

Funciones del producto



Power

Encender / Apagar

Pulse el botón durante más de 1,5 segundos para encender / apagar.



Potencia del ventilador (3 niveles)

Pulse el botón para ajustar la velocidad del ventilador

Nivel bajo > medio > alto, en ese orden.

Bajo Medio Alto



Indicador de sustitución del filtro


Indicador de reemplazo automático del filtro

Cuando sea el momento de reemplazar el filtro, el indicador LED comenzará a parpadear durante 5 segundos.

Presione el botón de encendido durante 3 segundos después de reemplazar el filtro para detener el parpadeo.

Maintenance

Cypress Wood Filter



Knots



Texture
difference



Dent or
damage



Warp

**Following cases are not qualifiable
for return or exchange.**

- Products made by processing solid wood may have knots.
- Occasional scratches caused during the production are not defective.
- Colors and wood texture may vary due to the nature of the wood and may differ from the photo due to lighting.
- Solid wood absorbs and expands in summer, and it shrinks in winter.

Maintenance

Cypress Wood Filter

Following cases are not qualifiable for return or exchange.

Temperature change causes expansion and contraction in the cypress wood filter. This is a natural phenomenon with solid wood that stabilizes after repeated expansion and contraction.

· With time, you may have a size change of about 1~2mm/0.03~0.07inches or split wood. This is a natural phenomenon with natural materials.

When exposed to direct sunlight, the color or shape may change, so keep the product under the shade.

Avoid hot or humid places because it is sensitive to temperature and humidity.

Do not place heavy objects on the product. It may bend or split.

After a period of use, even if the scent is minimal, the effect of cypress wood remains.

Maintenance

Warranty Period

Warranty

One year from the date of the purchase

This warranty does not apply to the following

1. Unauthorized repair, misuse, collision, negligence, accidental liquid damage, modification, disassembly, using third party components, or destroying them, or changing labels and anti-counterfeiting markings.
2. If the mentioned warranty has already been expired.
3. Unforeseeable damage caused by natural disaster or any events out of the company's control.

**Note: Please keep the packaging for about
1 month for safe transportation.**

Warranty card is at the back of the manual.

Product Specification

Specifications



Model Name

- Air Purifier for Vehicle(M-003 W / M-003 R / M-003 B)
(M-003TW / M-003TR / M-003TB)

Product Size - 68mm x 68mm x 172mm

2.6 in x 2.6 in x 6.7 in

Product Weight - About 300g / 0.6lb (including the filter)

Voltage - DC 5V

Power Consumption - 2.5W

Cable - C type Charging Cable , USB Car Charger Adapter

Color - White / Red / Black

Certification - FCC, CE, CB, RoHS, PSE

Country of Origin - South Korea

Filter

Circular Filter: Pre Filter + HEPA Filter +

Deodorization Filter (Replacement Cycle: Approx. 1 year)

Cypress Wood Filter

Troubleshooting

FAQ

Symptoms · The power does not turn on.

Things to check · Is the USB plug connected properly?
· Is the LED indicator at the front turned on?

Possible Solutions · Properly connect the product with USB plug.
· Please push and hold the power button for 1.5 seconds to turn on the device.

Symptoms · Filter replacement indicator is still blinking after replacing the filter

Things to check · Did you push and hold the power button for more than 5 seconds after replacing the filter?
· Is the filter properly assembled?

Possible Solutions · Push and hold the power button for more than 5 seconds.
· Properly assemble the filter.

Troubleshooting

FAQ

Symptoms

- The shape of the Cypress wood filter has changed.

Things to check

- Cypress wood filter is sensitive to temperature and humidity (water)

Possible Solutions

- Please refer to page 17 for more details.

Symptoms

- The wind is not coming out.
- The wind power is weak.
- The level for wind speed doesn't change.

Things to check

- Is the filter properly assembled?
- Is the filter contaminated? (contamination may affect the airflow and the power)

Possible Solutions

- Please check if the filter is properly assembled.
- Please clean the filter.

Troubleshooting

FAQ

Symptoms

· Air outlet has a strange odor.

Things to check

· Was the product used in areas where many people smoked, or in kitchen areas cooking food?
· Was the product brought from a different location?

Possible Solutions

· Filter has the tendency to absorb odor, thus temporarily could emit odor. This will eventually fade away.
· The product may still emit odors from the previously used locations.

Symptoms

· Filter does not have the cypress scent anymore.

Things to check

· The filter may lose its scent, but the effect of cypress wood remains.

Possible Solutions

If you desire stronger cypress scent, please purchase Cypress wood oil capsule separately from our website and simply replace it. It only applies when the model of the air purifier is either M-003DW/DR/DB.

Inquiries

Customer service center

Hours of Operation: 9:00 am – 17:00 pm (PST)
(Closed on Saturday, Sunday and Holidays)

(888) 601-0177
support@imunsen.com

www.vovo-us.com

Imunsen Air Purifier Warranty

Model Name	<input type="checkbox"/> M - 003W <input type="checkbox"/> M - 003R <input type="checkbox"/> M - 003B <input type="checkbox"/> M - 003TW <input type="checkbox"/> M - 003TR <input type="checkbox"/> M - 003TB
Date of Purchase	1 year from the date of the purchase
Serial Number	
Warranty Period	Year Month Day
Customer Address	
Customer Name	
Notes	

Warranty Content

1. If there is an issue with the product within the mentioned warranty period and you want to receive A/S, please contact the service center for assistance.
 2. Even during the warranty period, repairs will be charged if:
 - If you lose your warranty.
 - If the warranty contains false information or has any changes made.
 - If the damages or losses were caused by user negligence or misuse.
 - Failure or damage due to fire, natural disasters, pollution, salt damage, gas damage, abnormal voltage.
 - Failure or damage due to fixing, installation, etc.
 3. Please note that shipping and service fees may be incurred even during the warranty period
 4. Please note that all parts removed for repair will be taken by our team.
 5. This warranty cannot be re-issued.
- Thank you for your understanding.

