



Top



Smart Functions



Power

Turning on and off the power.


Night mode and power save mode recommended for night usage.



Auto

Operates automatically depending on the air quality.


Automatically changes function levels according to the air quality, thanks to the 2.5pm dust sensor situated at the back of the purifier.



Wind power (3 levels)

Operates when manually set.

Operates under 3 different modes (low-moderate-strong) set by the user.



Sleep mode.

Operated automatically during night time.

The fans speed automatically reduces, making less noise and using minimum energy.



Cyclone

Purify the air efficiently with full power.

Most efficient when used while cleaning, after ventilating, or after cooking.

* Automatically transits to auto mode after 20 minutes of operating under cyclone mode.



Power Save

Converts to the power save mode.

The wind speed decreases to reduce the power usage.



Ambient light sensor

Automatically changes mode based on the brightness of the room.

Automatically operates the night mode when in dark areas, and returns to auto mode once the area brightens up.

How to use



Sleep & Eco Mode

Power saving mode is recommended to use when you go to sleep. It will reduce the fan speed when this mode is active, which is suitable when sleeping.



Turbo Mode

Quickly and efficiently purifies the air with full power of motor fan. It is most effective during cleaning, cooking, and ventilating the room. Turbo mode automatically switches to Auto mode after 3 minutes.



High Mode

Operated by selection in manual mode. High mode can give you the fresh air more quickly than low mode.



Low Mode

Normally low mode operates when the air quality is good.



Auto mode

Operates automatically depending on the air quality. Automatically change the fan speed according to the air quality, thanks to the dust sensor situated at the back of the purifier.



Power

Turning on and off the power. Press & hold the power button for 2 seconds to turn ON/OFF the device. When powered on, the device will start in the previously used mode.




Ambient light sensor (For Auto mode only)

Automatically changes mode based on the brightness of the room. Automatically operates the night mode when in dark areas, and returns to auto mode once the area brightens up.

How to use

Top



Power

Power on / Power off

Press the button for more than 1.5 seconds to turn it ON / OFF.



Wind Speed (3 Levels)

Press the button to adjust the fan speed

Low > Medium > High level in order.



Front



Filter Replacement Indicator

Automatic Filter Replacement Indicator

LED indicator will blink for 5 seconds to let you know to replace the filter when the device is turned on.

After replacing the filter, push the power button for 3 seconds and the LED light will stop blinking.