



# OPERATING MANUAL OES-BAS-i5 Black





# FEATURES

000 000 000 Password






Oes-Bas-i5 Black Color- Black Please scan the QR code for reference video

## **OPERATING INSTRUCTIONS FOR BAS SAFE**

Ozone Bas safe is designed to help you protect your valuables against theft.

Please install the safe in a cupboard or on a wall/floor and keep the emergency key in a safe place.

Keep the safe in a secret place for paramount security.



### Accessories Include:

- 1) 2 Keys
- 2) 2 Mounting Bolts
- 3) 4x1.5V AA Batteries
- 4) Floor Carpet
- 5) Manual/Warranty Card

## Specifications:


Model	External Size	Weight	Volume
	(HxWxD)mm	(Kg.)	(Ltr.)
OES-BAS-i5 BLACK	200x300x200	5.9	7.8

**NOTE:** 1) Kindly change the User Password before operating the Digital Safe.

2) Please do not keep the Emergency Keys inside the safe!

## HOW TO OPEN A SAFE FOR THE FIRST TIME

#### OPEN THE SAFE USING THE EMERGENCY KEY




## **INSTALLING THE BATTERIES**

Open the safe door, remove the battery case cover and insert new AA batteries (4x1.5V) according to '+' '-' polarity.

Low Battery Indication - If the red indication blinks in that condition we need to change the batteries.

**NOTE:** In case of battery drain, please replace all the existing batteries with new ones.



# **HOW TO CHANGE THE PASSWORD**

Existing user password is (1234).

- a) The safe door must be in open position.
- b) Press the reset button (given inside of the door), the buzzer will beep twice.
- c) Enter your new user password (3-8 digits) and press "#" button to confirm, the buzzer will beep twice and yellow indicator goes out, now the user password is changed successfully.

**Note:**-If the yellow beeps flashes along with 3 buzzer beeps, then it indicates that code registration has been ineffective and you need to try again.

## TO LOCK THE SAFE



Close the door



Rotate the knob Anti-clockwise and close the safe


## TO OPEN THE SAFE



Enter your 3-8 digits password




Press "#" Button



Rotate the Knob clockwise and open the safe

- 1. Shooting Bolts
- 2. Reset Button
- 3. Battery Box
- 4. Mounting Hole
- 5. Batteries



# **INSTALLING THE SAFE**

Safe can be easily install in wardrobe or on wall.


Fix the safe in the place which is not easy to move.


Drill holes for expansion bolts (or clamping screws)in the right place.

Turn the expansion bolts counter clockwise to separate.

Use the expansion bolts (or clamping screws) to secure the case to the wall.

Make sure the case is mounted in place as required and then tighten all screws.





Do's	Don'ts	
1) On receipt of the safe, install it properly	1) Don't leave the safe in open position	
2) Keep mechanical override key (Emergency Key) at a Safer place	2) Don't Share your password with anyone	
3) Always reset the User password after installation of the safe	Don't put any extra force on knob while opening or closing the safe	

OZONE DIGITAL SAFE- CHECK LIST			
MODEL NO.:	SERIAL NO.:		
DATE:	DATE OF DELIVERY:		
CONTENTS:-			
1. EMERGENCY KEY			
2. PANEL KEY			
3. DRAWER KEY			
4. BATTERIES			
5. ADAPTOR			
6. RFID CARD			
7. FASTNER			
8. MANUAL			
9. OPERATION CHECK			
10. BODY DAMAGE (IF ANY)			

**CUSTOMER / DEALER SIGNATURE & SEAL** 

**INSPECTED BY:-**

E-Mail: Info@ozonesecutech.com | Website: www.ozonesecutech.com Customer Care: 9310012300