

Delta Children Connect

with SmartLink

Mobile App User Guide



WARNING

Read all instructions BEFORE assembly and USE of product. KEEP INSTRUCTIONS FOR FUTURE USE.

CAUTION - This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference. (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

MPE Reminder: To satisfy FCC / IC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended.

Index

Downloading App/ Delta Children Connect	4
Registering Account/ Delta Children Connect	6
Pairing Devices to App/ Delta-WIFI	7
Delta-WIFI Device/ Operation	13
Pairing Devices to App/ Delta-BT	15
Delta-BT Device/ Operation	18
Controlling Devices/ With App	20
Linking App to/ Alexa Skill	22
Linking App to/ Google Home	25
Controlling Delta- WIFI Device/ Amazon Echo & Alexa Devices	29
Voice Commands/ Amazon Echo & Alexa Devices	31
Controlling Delta-WIFI Device/ Google Home	33





Downloading App/ Delta Children Connect with SmartLink

1. Downloading App Delta Children Connect with SmartLink

- For the best experience, download the Delta Children Connect app by scanning the QR code below or on your devices.



- The App can also be downloaded by searching for Delta Children Connect on the Apple® App Store or Google Play®.



Note: If you already use the Delta Children Connect app, make sure that you are using the latest version. To find out if an update is available, go to the app store and search for Delta Children Connect.



2. Registering Account Delta Children Connect with SmartLink

* Click on areas marked on each screen


Open the Delta Children Connect app
and click "Register" to start the
registration process

1




Enter your email
and click "Get Verification Code"

2



Enter the verification code
you received from your email


3



Set your Delta Children Connect
password

4





Pairing Device to App/ Delta-WIFI


How to Check Your Smartphone WiFi Connection Band

NOTE:

To find out whether you need to connect to a different Wi-Fi network to set up your device, go to Settings > Wi-Fi (or Wireless & Networks) on your smartphone.


I see only **one** network:

If you only see one Wi-Fi network name that belongs to you, you can proceed by setting up this device with this Wi-Fi connection. (See image below)



I see **more than one** network:

If you see more than one Wi-Fi network name from your smartphone's wireless settings page, look for a 2.4 on the Wi-Fi network list.



A **2.4 GHz** network may have ("24G," "2.4," or "24") appended to the end of the network name.

A **5 GHz** network may have ("5G" or "5") appended to the end of the network name.

Pairing Note:

There are 2 ways to pair your bassinet to the Delta Connect App: EZ mode and AP mode. See image below on where to switch between modes. Instructions follow on [Page 11 \(AP\)](#) and [Page 13 \(EZ\)](#)




Pairing Device To App Delta-WIFI (AP Mode)

* Click on areas marked on each screen


Click "Add Device" or the "+" icon on the top right corner of the screen

1




On the left sidebar, choose "WiFi Devices" and locate your device on the list, or choose Auto Scan

2



Select your WiFi network and set the password (5GHz Wi-Fi is not compatible with the Delta-WIFI Module)

3



Tap on the mode selection in the top right corner. Choose AP Mode. If your device is plugged in and displaying a slow green blinking light (1 blink every 3 seconds), you can confirm the connection

4



*Make sure to have your WiFi network and password ready on hand


Click "Confirm" and "Next" to continue setup

Pairing Device To App Delta-WIFI (AP Mode)

* Click on areas marked on each screen


On the next screen, follow the guide on how to locate your **SmartLife-XXXX** device hot spot, once ready, tap on: **Go To Connect**.

5




On the Wi-Fi selection screen, look for the **SmartLife-XXXX** device hot spot and select it. Once the device is added successfully. Click on "Done" to complete pairing.

6




Adding device. Ensure that the Wi-Fi signal is good

7



Device added successfully. Click on "Done" to complete pairing.


8




Pairing Device To App Delta-WIFI (EZ Mode)

* Click on areas marked on each screen


Click "Add Device" or the "+" icon on the top right corner of the screen



On the left sidebar, choose "WiFi Devices" and locate your device on the list, or choose Auto Scan



Select your WiFi network and set the password (5GHz Wi-Fi is not compatible with the Delta-WIFI Module)



*Make sure to have your WiFi network and password ready on hand

Pairing Device To App Delta-WIFI (EZ Mode)

* Click on areas marked on each screen

If your device is plugged in and displaying a fast green blinking light (2 blinks per second), you can confirm the connection


5



Click "Confirm" and "Next" to continue setup


Adding device.
Ensure that the Wi-Fi signal is good

6




Device added successfully.
Click on "Done" to complete pairing.

7



Delta-WIFI Device Operation



- Press Auto Glide button (↔) to start 60 minute cycle of auto glide.
- Press again to stop auto glide.
- Auto glide speed can be adjusted with two speed buttons **1** & **2** on the top of the music module.
- Activate bassinet light by pressing LIGHT button (💡) on the top of the music module.
NOTE: Light will stay on in 60 minute cycles, unless button is pressed before 60 minutes are up.
- Press MUSIC button (🎵) on top of the music module to activate MUSIC. Press button multiple times to cycle through eight (8) music melodies & white noise.
- Volume can be adjusted with UP/DOWN buttons on the top of the music module.

Resetting Delta-WIFI Device

When do I need to reset the Delta-WIFI device?

- When the device is plugged in but not displaying a green blinking light.
- If the green light is not behaving as described, you have to reset the device (Use a small pin provided with the device to push the reset button for 5 seconds.)

If the green light is not blinking (2 blinks per second), you have to reset the device first. Use the small pin provided with the device to push the reset button for 5 seconds.

1




*

The indicator should start rapidly flashing. If it doesn't, repeat the process until it does, and then click "Confirm"


Adding device.
Ensure that the Wi-Fi signal is good


2



Adding device.
Ensure that the Wi-Fi signal is good

3






Pairing Device to App/ Delta-BT

Pairing Device To App

Delta-BT

If necessary, turn on the bluetooth feature your smart phone, then allow bluetooth to start scanning devices

1



If your device is plugged in and displaying a flashing night light, you can click "Search" to start the pairing process.

Note: If the night light is not flashing, see reset instructions on page 17.


2



* Click on areas marked on each screen


Click "Add Device" or the "+" icon on the top right corner of the screen

3



On the left sidebar, choose "WiFi Devices" and locate your device on the list, or choose Auto Scan

4




Pairing Device To App Delta-BT

* Click on areas marked on each screen


Bluetooth Search process
should detect your device

5




Select device to Add,
by clicking on the "+" button.

6




Device added successfully.
Click on "Done" to complete
pairing.

7



Delta-BT Device Operation



- Press Auto Glide button (↔) to start 60 minute cycle of auto glide.
- Press again to stop auto glide.
- Auto glide speed can be adjusted with two speed buttons **1** & **2** on the top of the music module.
- Activate bassinet light by pressing LIGHT button (💡) on the top of the music module.
NOTE: Light will stay on in 60 minute cycles, unless button is pressed before 60 minutes are up.
- Press MUSIC button (🎵) on top of the music module to activate MUSIC. Press button multiple times to cycle through eight (8) music melodies.
- Volume can be adjusted with UP/DOWN buttons on the top of the music module.

Resetting Delta-BT Device

When do I need to reset the Delta-BT device?




- When the device is plugged in but not displaying a green light.
- If the green light is not behaving as described, you have to reset the device (Use a small pin provided with the device to push the reset button for 5 seconds.)

If the night light is not flashing, you have to reset the device first. Use the small pin provided with the device to push the reset button for 5 seconds.

Select device to Add, and then click on the + button.

Bluetooth Search process should detect your device -click on the device to add.


Adding device. Ensure that the Wi-Fi signal is good



The night light should start rapidly flashing. If it doesn't, repeat the process until it does, and then click "Confirm".


Controlling Devices/ With App

Controlling Devices With App



Clicking the icon opens the function settings

Clicking the text turns the device ON or OFF



Click the edit icon to customize the name of your device & adjust settings.

Click the light icon to adjust the brightness level.

Click "Night Light" to turn on the function. (Icon will turn white when on.)

Click Icon to adjust the duration of the Music, Night Light and Auto Glide.

Click Icon to turn on the function. (Icon will turn white when on.)

Click the music icon to adjust the volume level.

Click "Music" to turn on the function.
NOTE: Switch songs by clicking "Music" ON & OFF. (Icon will turn white when on.)

Click the auto glide icon to adjust the bassinet speed.

Click "Auto Glide" to turn on the function. (Icon will turn white when on.)

Make sure to click the "ON" button to power on the functions.
NOTE: The button will turn white when powered on.


Linking App To/ Alexa Skill

NOTE: The Delta Children Connect Alexa skill only works with the Delta-WIFI device.

Linking App To Alexa Skill


NOTE: The Delta Children Connect Alexa skill only works with the Delta-WIFI device.

Download the Amazon Alexa App
from: (Android, ios or Amazon app market)




* Click on areas marked on each screen

In the "Skills & Games" section, **search** for "Delta Children Connect" skill



Enable "Delta Children Connect" skill and provide your credentials in order to link Alexa to your "Delta Children Connect" app account



Linking App To Alexa Skill

NOTE: The Delta Children Connect Alexa skill only works with the Delta-WIFI device.

* Click on areas marked on each screen

Enter the email and password used on the Delta Children Connect app and click Link Now

4

Please allow page to load

5

Click "Authorize" to complete the process.

6

Delta Children Connect has been successfully linked. Close this window to discover smart home devices you can control with Alexa.

7

*Make sure to have your Delta Children Connect email address and password on hand.

Linking App To/ Google Home





Linking App To Google Home

* Click on areas marked on each screen

Download the Google Home App
from: (Android, ios or Amazon app market)

In the "Skills & Games" section, **search** for "Delta Children Connect" skill

Enable "Delta Children Connect" skill and provide your credentials in order to link Alexa to your "Delta Children Connect" app account




Linking App To Google Home

* Click on areas marked on each screen


Enter the email and password used on the Delta Children Connect app and click Link Now

4




Please allow page to load

5



Click "Authorize" to complete the process

6



Delta Children Connect has been successfully linked. Close this window to discover smart home devices you can control with Alexa.

7




Linking App To Google Home

* Click on areas marked on each screen


Enter the email and password used on the Delta Children Connect app and click Link Now

8




Click "Authorize" to complete the process.

9




Delta Children Connect has been successfully linked. Close this window to discover smart home devices you can control with Alexa.

10



Controlling Delta-WIFI device/ Amazon Echo & Alexa Devices

Controlling Delta-WIFI device/ Amazon Echo & Alexa Devices



1. Once the Alexa skill is connected to your Delta Children Connect account, you can start to control your Delta-WIFI device with Amazon Echo or Alexa Devices.

2. To start controlling your Delta-WIFI device with Amazon Echo or Alexa Devices, refer to the voice commands on page 19.

NOTE: When controlling the Delta-WIFI device with Amazon Echo, you will still have the ability to control this device with your smartphone.

Voice
Commands
Pg. 31

Voice Commands Amazon Echo & Alexa Devices

Note:

Below are the voice commands with default names. You can change the default names from within the Delta Connect app before discovering them with Alexa, or change their names in the Alexa settings. In these examples, the default names are stated in the quotes.

Turning (Delta-WIFI) On & OFF

"Alexa, turn on Delta-WIFI"

"Alexa, turn off Delta-WIFI"



Music Function

"Alexa, turn on the music "

"Alexa, set the music to 25%"

"Alexa, turn off the Music"



Voice Commands Amazon Echo & Alexa Devices

Note:

Below are the voice commands with default names. You can change the default names from within the Delta Connect app before discovering them with Alexa, or change their names in the Alexa settings. In these examples, the default names are stated in the quotes.

Night Light Function

"Alexa, turn on the night light"

"Alexa, set the night light to 25%"

"Alexa, turn off the night light"



Auto Glide Function

"Alexa, turn on the auto glide"

"Alexa, set the auto glide to 25%"

"Alexa, turn off the auto glide"



Controlling Delta-WIFI device/ Google Home

Voice Commands

Google Home

Note:

Below are the voice commands with default names. You can change the default names of the locations from within the Google Home app.

- In these examples, the default names are stated in the quotes.
- The levels of the music function can be adjusted from 1-100%

Turning (Delta-WIFI) On & Off

"Hey Google, turn on Delta-WIFI"

"Hey Google, turn off Delta-WIFI"



Music Function

"Hey Google, turn on main bedroom bassinet music"

"Hey Google, set main bedroom bassinet music to 25%"

"Hey Google, turn off main bedroom bassinet music"



Voice Commands

Google Home

Note:

- Below are the voice commands with default names. You can change the default names of the locations from within the Google Home app.
- In these examples, the default names are stated in the quotes.
 - The levels of the night light and auto glide function can be adjusted from 1-100%

Night Light Function

"Hey Google, turn on main bedroom bassinet night light"

"Hey Google, set main bedroom bassinet night light to 25%"

"Hey Google, turn off main bedroom bassinet night light"



Auto Glide Function

"Hey Google, turn on main bedroom bassinet auto glide"

"Hey Google, set main bedroom bassinet auto glide to 25%"

"Hey Google, turn off main bedroom bassinet auto glide"



DELTA CHILDREN

Designed in New York.

Delta Children's Products Corp.

For customer support please visit: www.DeltaChildren.com

or contact us at: gcs@DeltaChildren.com

114 W 26th St, New York, NY 10001