


Double-Handle Lavatory Faucet Installation

INSTALLATION MANUAL Tools You will need









Adjustable Wrench

Allen key

Philips Screwdriver


Teflon Tape

Before the Installation


- 1. Check the package and confirm all parts are included. If any part is missing or damaged, please contact us.
- 2.Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory.
- 3. Shut off the main water supply prior to beginning installation.
- 4.Do flush the water supply lines to remove any dirt and debris before installation (IMPORTANT).
- 5.Make sure to connect the hot/cold inlet pipe correctly. If standing in front, connect hot water pipe to the left and cold water pipe to the right.
- 6. After the installation, check for leaks and make sure every joint is safely sealed.

Cleaning and Maintenance


- 1. Rinse with clean water and dry with a soft cloth.
- 2.Do not use any detergent, acid, polisher, abrasives, or harsh cleaners.
- 3.Do not use cloth with a coarse surface.




1.Holes size for the built in control valve: Ø35mm,the distance between the holes is 100mm.




2.Despatch the parts and fixed on the counter and screw it.



3.Connect the pipe of spout and two handles



5.Fix the Hot/Cold water supply.



5.Attach flexible hose to water supply.

