



It's a pleasure to meet you ;)

Whether Deem is your first pleasure product or you've lost count of how many you have, there's a way to find pleasure in it for everyone.
Trust us!

Let's get started!

If Deem is your first:

Don't be startled by the power of Deem when you turn it on. You'll find it surprisingly gentle once it's in place. **If this is your first time using a product like this, we recommend that you stick to the first vibrating option.** It's a constant pattern that doesn't vibrate too strongly and will help you familiarize yourself with it.

If you've used pleasure products before:

We like to think of Deem as **small but mighty**, which means that you can amp up the vibrations and experiment with the patterns to find something familiar or entirely new and exciting for you.

Using Your Deem



Please fully charge your Deem before using it.

There is one button on your Deem, which is used both for power and for alternating between vibrating intensities.

Hold down for a few seconds to turn on and off.

Press to change between these 8 vibrating speeds and intensities.

Deem is a clitoral vibrator and is not intended to be used for insertion.




Charging Your Deem

Your Deem charger is a magnetic USB charging cable. To charge, connect the magnetic pins of the charger to those on the bottom of your Deem.

When it's charging, the charging light will be flashing.

Only use the original charging cables provided by Mauj.



Caring for Your Deem

Your Deem has a waterproof rating of IPX7, which means you're free to play around with it in your bathtub ;)

It also means that cleaning it is simple, as it can safely be washed under running water.

Always clean Deem before and after every use, using either soap and water or a water-based sex toy cleaner and patting it dry with a lint-free cloth or towel.



Do not clean Deem with products containing alcohol, petroleum, or acetone. Do not boil, bake, microwave, or clean Deem in the dishwasher. Do not overbend it.

Store Deem separately from other toys, and away from extreme heat or cold.



Using Lubricant

Using lubricant with your Deem can help enhance your experience. However, do not use silicone-based lube as it can affect the material of the product.

Warranty

Our products are non-returnable, unless they are faulty, meaning that they were received damaged or that a manufacturing fault occurred within one year of your order. Products that are damaged as a result of normal wear and tear are not considered faulty.

If you think your Deem might be faulty, please reach out to us and we'll guide you through the process of

returning it. Once we've received your Deem, we'll inspect it and let you know if it qualifies for replacement or refund. You'll need to do that within a year of receiving your product.

For more on this process and what qualifies as a defective product, please check out terms and conditions.

Have more questions?

E-mail support@mauj.me or WhatsApp us on +1 (929) 301-7871 and we'll be there to answer your questions.

© 2023 BEAUTY BOX LLC. ALL RIGHTS RESERVED.
MANUFACTURED IN CHINA
WEBSITE: WWW.MAUJ.ME



Arabic customer
service

موج
mauj