

# INSTALLATION INSTRUCTION



If you have any questions, please feel free to contact us via Amazon.

### **STEP 1 Attach the TV Brackets**



### **Safety Caution**


Please read this instruction carefully before installation.

If you do not understand these instructions or have doubts about the safety of the installation, assembly or use of this product, please contact us.


- This product is designed for use in wood stud or solid concrete wall.
- DO NOT install into drywall alone.
- The wall must be capable of supporting five times the weight of the TV and mount combined.
- Incorrect installation may result in product damage or body injury.

**WARNING:** This product contains small items that could be a choking hazard if swallowed. Before starting assembly, verify all parts are included and undamaged. If any parts are missing or damaged, do not return the damaged item to your dealer; please contact our customer service team. Never use damaged parts!

### **Must Check Before Getting Started**




### Extra Tools You Need (Not Supplied)





### STEP 1 (Continued)

#### 1-3 Attach the TV Brackets



## **Supplied Parts and Hardware**







NOTE: Not all parts and hardware included will be used.

# STEP 2 Attach Wall Plate to Wall











### STEP 2 (Continued)





**CAUTION:** To avoid potential personal injury or property damage:

All 4 lag bolts A MUST BE firmly tightened to prevent unwanted movement of the wall plate assembly. Ensure the wall plate assembly is securely fastened to the wall before continuing on to the next step.

To prevent the TV falling down, the Arrow Must Keep UP at this step!!




Install wall plate using lag bolts and washer with Socket Wrench, NO Electrodrill.




CAUTION: Do not use in drywall or wood.


# 6


### STEP 2 (Continued)





### STEP 2 (Continued)





**CAUTION:** To avoid potential personal injury or property damage:


All 4 lag bolts A MUST BE firmly tightened to prevent unwanted movement of the wall plate assembly. Ensure the wall plate assembly is securely fastened to the wall before continuing on to the next step.


To prevent the TV falling down, the Arrow Must Keep UP at this step!!




Install wall plate using lag bolts, washer and anchor with Socket Wrench, NO Electrodrill.

# STEP 3 Adjustments






**Option:** To keep TV in vertical position, please use two M4 screws MA to insert the holes on two brackets respectively (as shown in below image).




## STEP 4 Hang and Secure TV to Wall Plate


### 4-1 Wall Plate Installation Integrity Test



### 4-2 Hang and Secure TV to Wall Plate



# Take down the TV from the Mount (If necessary)



### **Product Dimensions**

