
INSTALLATION INSTRUCTION

LDT04-022_US1.0



If you have any questions, please feel free to contact Customer Service via Amazon before returning.

Safety Caution

BEFORE ASSEMBLY

- Please check and make sure all necessary accessories are included and undamaged. If any
 parts are missing or damaged, do not return the damaged item to your dealer; contact Customer
 Service. Never use damaged parts.
- Please read and understand this manual carefully before installation.

WARNING

- This product contains small items that could be a choking hazard if swallowed.

 KEEP AWAY FROM CHILDREN UNDER 3 YEARS OLD. ADULT SUPERVISION IS REQUIRED.
- Improper installation, such as using the product for monitor over its load capacity or for any
 purpose not explicitly specified, may cause damage or serious injury. We would not be liable for
 any damage or injury caused by improper mounting or inappropriate use.


CAUTION AND MAINTENANCE

- Never allow children to climb, stand, hang, or play on any part of monitor or stand.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

Check that the bracket is secure and safe to use at regular intervals (at least every three months).

Must Check Before Getting Started

1. Verify Your Monitor Specifications:




VESA Pattern (W × H): 75mm × 75mm / 3" × 3" 100mm × 100mm / 4" × 4"




MARNING

DO NOT exceed the maximum weight indicated. This mounting system is intended for use only within the maximum weights indicated. Use with products heavier than the maximum weights indicated may result in failure of the mount and its accessories, causing possible damage or injury.

2. Verify Your Desk Specifications:




















φ0.39~2.36 (Φ10~60mm)

2











3-2







5

4 Hang Monitor









5 Adjustments

Tilting Adjustment

- 1. Loosen the tilting bolt.
- 2. Adjust monitor to your desired tilt angle.
- 3. Retighten the tilting bolt to fix the intended angle.



Switch screen horizontally and vertically



360° Rotation

This function works better for monitors with the center of gravity.


Note: To ensure stability, the tightness of the rotating axis has been preset, so it would be kind of difficult to rotate the VESA plate.

Suggestion: Please attach the monitor first, then hold the two sides of it with both hands, and rotate vigorously. If that doesn't work out, please do not hesitate to ask for our help via Amazon.

5 (Continued)


Cable Management


Run cables through the wire clip. Store Allen keys in wire clip or storage tray for



Set the desired position of the monitors

Please keep the two arms in balance.





6