



Kids Dresser "City" Size L







Dresser without doors







Total parts: 16 pcs.



Box assembly



Use part 9-01 to attach the dresser to the wall

Door assembly

