



BusyWood Model 21 Floor 75x54





name	length	quantity
1	75,0	1
1-01	75,0	1
1-02	75,0	1
2	38,3	1
3	24,8	4
4	18,5	45
4-01	18,5	1
4-02	18,5	1
5	53,6	2
5-01	53,6	2
6	27,0	1
6-01	27,0	1
7	16,8	5
7-01	16,8	1
7-02	16,8	1
8	40,6	1
8-01	40,6	1
8-02	39,0	2
9	10,0	1
10	4,3	1
11	75,0	1
12	7,3	1
13	9,6	1

Customer Service E-mail:
support@busywood.com




You need:




Total wooden parts: 77

Assembling the base



Assembling the door



Roof and chimney assembly

