Legal Liability

Juice® Airphones can only be used with compatible products. Please read your devices instructions to determine whether this product matches your devices requirements. The manufacturer will not be liable for any damage to your electronic equipment during the use of this product. Juice will not be held responsible for any equipment or accessories not suitable for use with these earphones. The manufacturer will not be held liable for damage caused by misuse or damage incurred by the buyer or the third party rising from any intentional or unintentional use of this product.









30% of the material on this product is made from recycled post consumer waste plastic.

Designed in the UK. Ethically made in China. Please retain packaging & instructions for future reference. Design & specification may be subject to change without prior notice. Juice®Airphones Groove is part of the ©Juice®brand.



WASTE ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE, PLEASE BECYCLE WHERE FACILITIES EXIST. CHECK WITH YOUR LOCAL AUTHORITY FOR RECYCLING ADVICE.

customerservices@juice.co.uk Unit 10 Haslemere Way. OX16 5RW. UK. Juice®

Box 133, 3 Lombard Street East, Dublin 2, D02 HC78, Ireland, Helpline number: +35315256712



Charging case

- USB Type-C charge cable
- Instruction booklet

display Touch area LED indicator USB Type-C Touch area

Specifications

Bluetooth® Version	V5.3
Bluetooth® Range	10 Metres
Bluetooth® profile support	A2DP, AVROP, HFP, HSP
Audio CODEC support	SBC
Battery life	Up to 4.5 hours, additional 13.5 hours with charging case
Charging time (case)	2 hours
Charging time (buds)	1.2 hours
Water resistance rating	IPX5

Pairing device

1. Take the earbuds from the charging case.

2. Select 'Juice Airphones Glass' on Bluetooth® device list to pair the earbuds automatically. Once completed, you can use the earbuds.

*To reset, when power on status, press the touch pad on each earbud 7 times

Power on/off earbuds

Remove the earbuds from the charging case to power on automatically. Place back in the case to power off, or long press each bud for over 5 seconds.

How to use



One-press: Music - Play/pause (L/R)

Incoming call - Pick/hang up call

Two-press: Next song (R).

Start of song / Previous song (L)

Long-press: Reject call (L/R), Activate Siri



Charging your case


To charge your case, insert the provided USB Type-C cable into a power adapter or computer and plug in to the USB Type-C port on the base of the case. A completed charge time from empty battery is 2 hours.

Charging your earbuds

To charge your earbuds, simply place them into their corresponding slots within the case. The case holds up to 3 charges.

LED indicators

Charging case




Light off

White solid

C Light off

Earbuds



Precautions

1. Please do not put the earbuds under heavy pressure, or expose them to heat or wet conditions

2. Keep away from WiFi routers or others high frequency transmitting equipment to prevent interruption of signals receiving.

3. Please use the earbuds within 10 metres of your device.

4. Keep the device away from heat sources, direct sunlight, humidity and exposure to water. Do not operate the device if it has been exposed to water, moisture or any other liquids to prevent against electric shock explosion and/or injury to yourself and damage to the device. Do not use the device if it has been dropped or damaged in any way. Do not puncture or harm the exterior surface of the product in any way.