Juice 4. 12,000mAh powerbank

with you in mind. Speed is important when charging and when on the go, the Juice*#4 will charge your device at a speedy 3A and will allow around 4 full charges of an average mobile. This handy charger will also charge THREE devices at the same time, ready for when you need it most.


- Micro USB and USB C Input ports
- 2 x USB A Charging ports Output (2.4A)
- USB C Charging port Output (3A)

Contents

Juice®#4 power bank, Micro USB to USB cable (for charging) and User Manual

Overview

- USB A output charging port 1
- 2. Micro-USB input port
- 3. LED indicators
- Power button
- USB C input/output
- charging port 6. USB A output
 - 5. USB A output
- charging port 2



How to charge the Juice[®]#4 power bank

Ensure to fully charge the Juice"#4 power bank before first use, the LED will display four lights. Do this by charging and draining the power bank 3 to 4 times, this will ensure the Juice"#4 is fully optimised. To charge the Juice"#4 simply connect the supplied Mircu USB cable into the power bank and the other end into your computer or to a mains plug (plug not supplied). The LED will fash when charging, the LED will turn white when fully charged.

Checking the remaining charge

Charge Time : 6-7 hrs (DC5V, 2A input)

To check the energy levels press the button on the side, the LEDs will indicate the remaining power

Note: It is normal for the Juice^{##4} and your device to get warm during charging. They may get even warmer if you use your device to play videos or for gaming while charging.

Charging your gadgets

Always check the voltage your device can except before charging with any Juice product, this will ensure full compatibility

1. Connect your device via the cable to the USB A or USB C port. You are able to charge from both output ports at the same time but the speed of charge will decrease for optimum safety. For original cable that was supplied with your device, this will ensure original cable that was supplied with your device, this will ensure original cable that was supplied with your device, this will ensure original cable that was supplied with your device, this will ensure original cable that was supplied with your device, this will ensure original cable that was supplied with your device, this will ensure that you can charge. Your device is fully charged or you want to stop charging disconnect the cable. We have to charge the same that was the order to charge. These come included as standard when purchasing most devices. Plug the device's standard USB A end in to the Juice"44, then jug the other end of the cable into the device you what to charge, 5. Once charged, simply unplug your device as ad store your Juice"44 power bank fully ovaer ready to use it again, ensure to charge the power bank fully every 3 months to ensure it is kept in optimum condition.

NOTE: Mobile and gadget device manufacturers have different requirements to charge their products, they may also use different cables to charge their devices. These manufacturers may also introduce other charging methods on their new products, therefore we can not guarantee that the Juice³⁴ power bank will be able to charge all devices. Juice³ always suggests that you use the original charging cable included with your device to charge.



Lets get techy

Input	Micro USB - DC5V/2A USB-C - DC5V/3A
Output	2 x Outputs USB A: DC5V/2.4A
	Output USB C:
	DC5V/3A
	Max Output at any time: 3A (15W max)
Dimensions	91 x 62 x 22.5 mm
Net Weight	193g
Capacity	12,000 mAh / 46.2Wh (Lithium polymer battery cell)

Legal liability

The Juice[®]#4 can be used only with compatible products. Please read your equipments compatibility instructions to determine whether this Juice[®]#4 matches your equipment. The

whether this Juice"#4 matches your equipment. The manufacturer will not be liable for any damage to your electronic equipment during the use of this product. Juice will not be held responsible for any equipment or accessories not suitable for use with the Juice"#4 The manufacturer will not be held liable for damage caused by misuse or damage incurred by the buyer or the third party rising from any intentional or unintentional use of the Juice"#4, Average charge amounts shown (4 charges for the Juice"#4, Average charge amounts shown (4 charges for the Juice"#4, Development and the short of the Juice" and Jower bank are estimated on charging an Phone 12mobile

Safety notes

IMPORTANT: Read all information and warnings before using the Juice*#4. Improper use of this product may lead to the product being damaged and you (the buyer, not the dealer) will be held responsible for damages such as over heating, the release of toxic fumes, fire or explosion.

 Do not attempt to charge the Juice #4 by using any other method other than a USB charger or computer. Do not modify or disassemble the battery. • Do not dismantle or modify the Juice #4 in any way. • Do not use this charger in bathrooms etc. • Do not expose the Juice"#4 to moisture or immerse it in liquid. • Keep the product dry at all times. • Do not keep the Juice®#4 in an including environment that has excessively high temperatures intense sunshine. • Do not throw this product into a fire or leave in a hot environment. Avoid dropping or any other impact or friction to this product. • Do not place the Juice #4 on flammable to this product. • Our not place the suice "# of that makes materials, such as bedding or carpets during charging. • Do not touch the Juice"#4 with wet hands. • Disconnect the cable from the Juice"#4 once you have charged the device. • Only use this product within the following temperatures: 0° to 40°. • Do not connect input and output in reverse. • Do not charge the Juice®#4 in excess of the rating suggested. If any issue arises when using the Juice #4, disconnect the cable from the computer port and contact your dealer. In the unlikely event that any liquid from the inside of this product gets into your eyes, do not rub them. Wash your eyes immediately with clean water and consult a physician. All Juice[®]#4's have been tested comprehensively to ensure • All JUICE" #4 \$ have been tested completies hvery to ensure quality. If you encounter any unusual heat, discolouration or product distortion during charging or storage, please stop using it immediately and contact the dealer. These issues may cause leakage, heat, smoke or ignition of the Juice"#4, • The Juice"#4 is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities (or lack of experience and knowledge) unless they have been given supervision or instructions concerning the use of the Juice"#4 by a person responsible for their safety. Children should be supervised to ensure that they do not play with the Juice #4, this is not a toy. WASTE ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE. ALI ELECTRONIC PRODUCTS WITH THE WEEE LOGO MUST BE COLLECTED AND SENT TO APPROVED ELECTRONIC PROJECTS WITH THE WEELE COLUMN BECALE AND SET AND S DESIGNATED COLLECTION FACILITIES (DCF) WHERE CONSUMERS MAY DISPOSE OF THEIR WEEL FREE OF CHARGE.

Designed in the UK. Product made in China. Please retain packaging for future reference. Design & specification may be subject to change without prior notice. Juice*#4 is part of the ©Juice* brand.

