
juice bassed wireless speaker

Package Contents

- · Juice®BassGo portable Wireless speaker
- · Micro USB to USB-A cable
- Instruction booklet

Overview



Functionality

- 1. Power button: power on/off, siri, reset.
- 2. Wireless button: switch the playing mode.
 3. Play button: play, pause, answer call, TWS.
- 4. -: Volume down button: previous song,
- decrease the volume.
- +: Volume up button: next song, increase the volume.
- 6. Indicator light.
- 7. Micro USB charging port.
- 8. TF/Micro SD card slot.
- 9. AUX IN port.

Specifications

Model No.	Juice@BassGo	Output Power	5W
Power Capacity	800 mAh	Input Voltage	DC 5V / 1A
Playback Time	5 hours	Operating Distance	Up to 10m
Water Res.	IPX7 Rating	Charge Time	3 hrs
Dimensions	116x70x43mm	Net Weight	192g
Bluetooth® Version		Bluetooth® 5.0	

How to charge your Juice®BassGo

- Connect the Micro USB connector from the cable to the Juice®BassGo.
- 2. Plug the USB-A connector to a USB compatible wall charger or computer.
- The LED indicator light will blink white & red while charging, until fully charged.
- It is recommended that you charge for 10 minutes before use if you haven't used it in over a week.

Note: A full charge takes approximately 3 hours.

Power on/off

Power on: Long press the power button for 3 seconds to turn the speaker on, the Wireless indicator light will alight, ready to connect.

Power off: Long press the power button for 3 seconds to turn off the speaker.

Note: The speaker automatically turns off after 10 minutes of inactivity.

Playing audio from your Bluetooth® device

- The Juice®BassGo will automatically enter BT mode when turned on.
- Go into the Bluetooth® settings on your music source and search for Bluetooth® devices.
- 3. Connect to "Juice Bass Go".
- The Wireless indicator light will go solid blue when connected.

Note: Only one Bluetooth® device can be connected at any time, disconnect the paired device to connect a different device.

Disconnecting from your Bluetooth® device

Long press the "M" button for 3 seconds to disconnect your device from the **Juice®BassGo**.

Reconnecting the speaker

Some Bluetooth® devices support automatic reconnection, with those devices, the speaker will automatically reconnect. For devices that don't have this feature, long press the Wireless button for 3 seconds to reconnect the device.

Playing mode

Short press the "M" button to switch between BT mode & AUX mode.

Playing from a Micro SD card

Insert your Micro SD card and turn on the speaker.

Playing through wired connection

Turn on the speaker, connect your device to the speaker's AUX IN port with a 3.5mm AUX cable.

Siri functionality

Short press the power button to activate Siri (iOS), also supports Huawei intelligent voice assistant.

Play/Pause button functionality

During music playback:

Short Press - Play/pause music

Long Press – Enter/exit TWS speaker pairing mode

Incoming/during call:

Short Press – Answer the call/hang up the call. Long Press – Reject the call Double Press – Call back

Volume buttons functionality

During music playback:

Increase volume – Short press the "+" button Decrease volume – Short press the "-" button

Next song – Long press the "+" button Previous song – Long press the "-" button

Pairing Juice®BassGo speakers with TWS

- Turn on both speakers.
- Long press the Play/Pause button on one of the speakers until you hear a "beep" – this is now your primary speaker.
- 3. After releasing the Play/Pause button, wait for the speakers to connect to each other. Once connected, check the Wireless indicator light on each speaker to establish which is connected to the Left & Right channels. The left channel – and primary speaker – is identified by a flashing blue light, whereas the right channel will show a solid blue light.
- Go into the Bluetooth® settings on your music source and connect to "Juice Bass Go". The two speakers are now combined under one name.

To unpair your speakers, long press the Play/Pause button on either speaker until you hear the "beep".

Reset functionality

Hold the power button for 8 seconds to reset the speaker.

Troubleshooting

The speaker doesn't turn on

Ensure the speaker is charged.

The speaker doesn't turn off or respond Reset by holding the power button for 8 seconds.

There is no sound

Adjust the volume. Ensure your BT device is within range. Check for obstacles that could be blocking or disturbing the BT signal. Check your device is still connected.

There is poor sound quality

Move your BT device closer & check for obstacles.

Can't connect your device to the speaker

Disconnect other connected devices & try again. Try and force disconnection by moving out of the 10m BT range.

To preserve product performance, charge the Juice®BassGo every 2-3 months regardless of use.

Safety Instructions

Read all instructions

Only charge with mains plugs rated & marked with 5V to avoid damaging the speaker. Do not open up the speaker, it voids the warranty & may damage the product. Rechargeable batteries have a finite lifespan and a limited number of charge cycles, varied by use and settings. Do not place the speaker close to high temperature heat sources. To keep the warranty valid, do not attempt to repair the product yourself.

This product is designed with full attention for safety performance. To ensure safe operation, please observe the following guidance:

- please observe the following guidance:

 1. Place the speakers in a stable position.
- 2. Do not drop, disassemble, open, crush, puncture or burn the speaker.
- 3. Do not use in close proximity to a heat source.
- 4. Switch off the power before wiping dust or cleaning the speaker.
- 5. Keep the volume at a reasonable level to avoid ear damage.

Legal Liability

Juice® speakers can only be used with compatible products. Please read your devices instructions to determine whether this product matches your devices requirements. The manufacturer will not be liable for any damage to your electronic equipment during the use of this product. Juice will not be held responsible for any equipment or accessories not suitable for use with this speaker. The manufacturer will not be held liable for damage caused by misuse or damage incurred by the buyer or the third party rising from any intentional or unintentional use of this product.

Designed in the UK. Ethically made in China. Please retain packaging & instructions for future reference. Design & specification may be subject to change without prior notice. Juice®BassGo is part of the @Juice® brand.

WASTE ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE. PLEASE RECYCLE WHERE FACILITIES EXIST. CHECK WITH YOUR LOCAL AUTHORITY FOR RECYCLING ADVICE.

1-YEAR WARRANTY

Register your product at juice co.uk to activate your free 1-year warranty. Caution: If the batch code is removed from the product, the warranty will be void.





customerservices@juice.co.uk Unit 10 Haslemere Way. OX16 5RW. UK Juice® Box 133, 3 Lombard Street East, Dublin 2, D02 HC78, Ireland. Helpline number: +35315256712