
20.000mAh nowerbank

UICE MAX Juice® has built the Juice®MAX power bank with you in mind. Speed is important when charging and when on the go, the Juice®MAX will charge your device at super fast 20W and will allow around 7 full charges of an average mobile. This handy charger will also charge THREE devices at the same time, ready for when you need it most.

- USB C Input port
- 2 x USB A Charging ports Output (18W)
- USB C Charging port Output (20W)

Contents

Juice@MAX power bank, USB-C to USB cable (for charging) and User Manual



te: Click the OFF/ON b r on Double Click to t

How to charge the Juid power bank

Ensure to fully charge the **Juice®MAX** power bank before first use, the LED will display four lights. Do this by charging and draining the power bank 3 to 4 times, this will ensure the Juice@MAX is fully optimised. To charge the Juice@MAX simply connect the supplied USB-C cable into the power bank and the other end into your computer or to a mains plug (plug not supplied). The LED will flash when charging, the LED will turn white when fully charged.

Checking the remaining charge

Charge Time: 6.2hrs (DC5V, 3A input)

To check the energy levels press the button on the side, the LEDs will indicate the remaining power.

Note: It is normal for the Juice@MAX and your device to get warm during charging. They may get even warmer if you use your device to play videos or for gaming while charging

Charging your gadgets

Always check the voltage your device can accept before cha rging with any Juice product, this will ensure full compatibility 1. Connect your device via the cable to the USB A or USB C nort You are able to charge from three output ports at the same time but the speed of charge will decrease for optimum safety. For other devices and Apple devices you will need to use your original cable that was supplied with your device, this will ensure compatibility.

 Press the power button to turn the Juice®MAX on, now you can charge. Your device will show you when it is being charged via a sound or on the screen. The number of it LEDs will decrease to show that power is being transferred from the power bank to your device

3. When your device is fully charged or you want to stop charging, disconnect the cable

In order to charge your device(s), you will need a cable compatible with your device. These come included as standard when purchasing most devices. Plug the device's standard USB A end in to the Juice®MAX, then plug the other end of the cable into the device you wish to charge.

5. Once charged, simply unplug your device and store your Puice®MAX power bank until you are ready to use it again, ensure to charge the power bank fully every 3 months to ensure it is kept in optimum condition

NOTE: Mobile and gadget device manufacturers have different requirements to charge their products, they may also use different cables to charge their devices. These manufacturers may vary the specifications of how to charge a device and they may also introduce other charging methods on their new products, therefore we can not guarantee that the Juice®MAX power bank will be able to charge all devices. Juice® always suggests that you use the original charging cable included with your device to charge.



Lets get techy

Č Š	
Input	USB-C - DC5V/3A, 9V/2A, 12V/1.5A
Output	2 x Outputs USB A: DC5V/3A, 9V/2A, 12V/1.5A(max.18W) Output USB C: DC5V/3A, 9V/2.22A, 12V/1.67A(max.20W)
Dimensions	140 x 68 x 26.5 mm
Net Weight	342g
Capacity	20,000 mAh / 3.7V / 74Wh (Lithium polymer battery cell)

Legal liability

The Juice@MAX can be used only with compatible products. Please read your equipments compatibility instructions to determine whether this Juice@MAX matches your equipment. The manufacturer will not be fable for any damage to your electronic equipment during the use of this product. Juice will not be held responsible for any equipment or accessories not suitable for use with the Juice@MAX The manufacturer will not be held lable for damage caused by misuse or damage incurred by the buyer or the third party rising from any intentional or unintentional use of the Juice@MAX Average charge amounts shown (7 charges for the Juice@MAX ower bank) are estimated on charging an iPhone 12 mobile.

Safety notes

IMPORTANT: Read all information and warnings before using the Juice@MAX. Improper use of this product may lead to the product being damaged and you (the buyer, not the dealer) will be held responsible for damages such as over heating, the release of toxic fumes, fire or explosion.

 Do not attempt to charge the Juice@MAX by using any other method other than a USB charger or computer. • Do not modify or classsemble the battery. • Do not dismantle or modify the Juice@MAX in any way. • Do not use this charger in bathrooms etc. • Do not excose the Juice@MAX to moisture or immerse it in liquid. • Keep the product dry at all times. • Do not keep the Juice®MAX in an environment that has excessively high temperatures, including a hot environment. Avoid dropping or any other impact or friction to this product. • Do not place the Juice@MAX on flammable materials, such as bedding or carpets during charging. • Do not touch the Juice@MAX with wet hands, • Disconnect the cable from the Juice@MAX once you have charged the device. • Only use this product within the following temperatures: 0' to 40'. • Do not connect input and output in reverse. • Do not charge the Juice®MAX in excess of the rating suggested. • If any issue arises when using In excess of the rating suggested. • If any ssue arises when using the Juice@MAX, disconnect the cable from the computer port and contact your dealer. • In the unlikely event that any liquid from the inside of this product gets into your eyes, do not rub them. Wash your eyes immediately with clean water and consult a physician All Juice®MAX's have been tested comprehensively to ensure quality, If you encounter any unusual heat, discolouration or product distortion during charging or storage, please stop using it immediately and contact the dealer. These issues may cause leakage, heat, smoke or ignition of the **Juice@MAX** • The **Juice@MAX** is not intended for use by persons (including children) with reduced nhysical sensory or mental capabilities (or lack of experience and knowledge) unless they have been given supervision or instructions concerning the use of the Juice®MAX by a person responsible for their safety. Children should be supervised to ensure that they do not play with the Juice®MAX, this is not a toy.

WASTE ELECTRICAL PRODUCTS SHOULD NOTE E DROSED OF WITH HOUSEHOLD WASTE ALL ELECTRION (FRODUCTS WITH THE WEEK LOG MUSTE E CULCETE AND SHIT TO APPROVED OFERATORS FOR SAFE DISFORM OR RECYCLING, PLASE RECYCLE WERE FACILITES DIST MANY ELECTRICAL ELECTRICAL EQUIPMENT REALES FACULTATE "DOTINIDATION TAKE BACK SCHEME" OF HOUSEHOLD WEEK CHEMENT MICH AND SHOT OF THE HEALES FOR PERFORMANCE" TO HAVE CHEMENT AND SHOT OF THE HEALES FOR THE FOR HAVE



Designed in the UK. Product made in China. Please retain packaging for future reference. Design & specification may be subject to change without prior notice. Juice@MAX is part of the @Juice@ brand.

