
juicepodssport



Package contents

- Juice®Pods sport earphones
- · USB-C charge cable
- Instruction booklet



Functionality

- 1. Turn on/off, plav/pause, answer call
- Volume down, previous sona
- Volume up, next song
- 4. Charging port

LED indicators

Juice®Pods on	Flashing Red and Blue Light
Low battery	Flashing Red light
Connecting	Flashing White Light

Charging

Before using your Juice®Pods, charge them using the included USB-C charging cable plugged into an AC adapter or computer.

Note: Use a 5V charging adapter (1A) for best results, a high voltage fast charger could be liable to damaging the product.

Pairing device

1. Turn on the Juice®Pods by holding the () button for 3 seconds, until the LED lights Red & White. The Juice®Pods will automatically enter Bluetooth® pairing mode.

2. Enable the Bluetooth® function on your desired device for pairing.

3. Select 'Juice Earphones Pods Sport' from the list displayed on your Bluetooth® device and wait for the earphones to connect.

Your Juice®Pods will reconnect automatically when turned on once your device is paired.

Functions

Button

Turning on/off Press and hold () button for 3 seconds to turn on, repeat the action to turn off.

Play/pause Press (b) button once to play/pause.

Incoming call

Press () button once to answer an incoming call, press again to end the call.

Voice Mode

Triple-press (b) button to change the sound to voice mode

Button +

Volume Press + button to increase the volume.

Next track

Press and hold + button to skip to next track.

_ Button

Volume

Press - button to decrease the volume.

Previous track

Press and hold - button to revert to previous track.

Specifications

Bluetooth® Version	V5.3
Bluetooth® Range	15 Metres
Battery Type	3.7/110mAh
Charging Time	2 hours
Playing Time	10 hours
BT Profiles	HFP, A2 DP, AVRCP
Frequency Range	2.402 GHZ ~ 2.480 GHZ
Stand-by Time	250 hours
Microphone	-42 dB \pm 3dB
Audio Range	20HZ – 20KHz
Speaker Size	Φ10mm/32Ω

Precautions

1. Please do not put the earbuds under heavy pressure, or expose them to heat or wet conditions.

2. Keep away from WiFi routers or others high frequency transmitting equipment to prevent interruption of signals receiving.

3. Please use the earbuds within 15 metres of vour device.

4. Keep the device away from heat sources. direct sunlight, humidity and exposure to water. Do not operate the device if it has been exposed to water, moisture or any other liquids to prevent against electric shock explosion and/or injury to yourself and damage to the device. Do not use the device if it has been dropped or damaged in any way. Do not puncture or harm the exterior surface of the product in any way.

5. Press and hold the power button for 9 seconds to reset your Juice®Pods Sport.

Legal Liability

Juice® earphones can only be used with compatible products. Please read your devices instructions to determine whether this product matches your devices requirements. The manufacturer will not be liable for any damage to your electronic equipment during the use of this product. Juice will not be held responsible for any equipment or accessories not suitable for use with these earphones. The manufacturer will not be held liable for damage caused by misuse or damage incurred by the buyer or the third party rising from any intentional or unintentional use of this product.



Caution: If the batch code is removed from the product, the warranty will be void.



Designed in the UK. Ethically made in China. Please retain packaging & instructions for future reference. Design & specification may be subject Juice®Pods is part of the ©Juice®brand.



WASTE ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE, PLEASE RECYCLE WHERE FACILITIES EXIST. CHECK WITH YOUR LOCAL AUTHORITY FOR RECYCLING ADVICE.

customerservices@juice.co.uk Unit 10 Haslemere Way. OX16 5RW. UK. Juice®

Box 133. 3 Lombard Street East. Dublin 2. D02 HC78. Ireland. Helpline number: +35315256712