

LORENZI 4 LIGHT KITCHEN ISLAND PENDANT CHANDELIER LL-P12



LORENZI 4 LIGHT KITCHEN ISLAND PENDANT CHANDELIER

LL-P12

REMOVE ALL PARTS FROM PACKAGE, BE CAREFUL NOT TO DAMAGE ANY COMPONENTS.



- Measure area and determine desired hanging height. Product comes with two (2) sets of three (3) 12", one (1) 8" and one (1) 4" hard stems [A] for adjustable hanging height. Determine the stems you will use to achieve desired height. Threads are removable from the stems and thread removal may make it easier to thread wire.
- 2. Thread wire [E] from frame [B] through one side only of the light fixture through the first stem [A]. Continue to add stems on that side, threading the wire and screwing each stem together and repeat as necessary to achieve desired hanging height.
- On non wire side, continue to add stems, screwing each stem together. Repeat as necessary to achieve desired hanging height.
- 4. Detach mounting plate [C] from canopy [D].
- 5. Locate two (2) canopy stem connectors [G]. Remove nut [H], lock washer [I] and washer [J] from both connectors.
- **6.** Screw the finished side of the canopy stem connector [G] into stem assembly on each side, threading wire through the connector on the appropriate side.
- 7. Thread wire [E] through canopy [D] on one side.
- Place canopy holes over stem assembly threads. Place washer [J], then lock washer [I] over thread. Secure with nut [H]. Be sure to thread wire through washers and nut on wired side. Repeat on second side.
- Install light to ceiling. Linea Lighting recommends installation by a qualified electrical professional. Canopy screws [F] are used to tighten light to ceiling.
- 10. Install bulbs 60W max (included).

