

UpSki Extrahug HD Installation & User Guide

Thanks!

By purchasing UpSki bike products you are supporting small business and US manufacturing. Your bags were designed and built in our Carbondale, Colorado shop by avid bicycle enthusiasts.

Installation Instructions

Instructions are for attaching bag to XtraCycle® Heavy Duty Panier V-Racks and standard V-Racks.

1) Attach bag to top bar of V rack



- 1) Leave the V-Rack on the bike
- 2) Locate the bag on the rack
- 3) Wrap the short strap over the bar & insert into plastic keeper. Repeat for all 4 upper attachment loops



2) Bottom Rear strap

Thread strap as shown and tie off loose end with overhand knot.



3) Bottom Front strap

Repeat the same process as for bottom rear strap



4) Side bar attachment

Loop the side bar strap around the bar and thread through buckle



5) Buckle Strap attachment

Girth hitch the straps around the bar.



Traditional Use:

Open Top

For open top or "grocery style" flip the top down inside the bag



Roll top

Roll the top towards or away from the bike and buckle closed



See www.UpSki.com for additional images and ideas for alternative closure methods

Maintenance & Care

Store your bike & bags out of the sun whenever possible for best longevity. Bags can be cleaned with water, brush, and mild soap. Periodically inspect your bags for wear especially where it meets the bike (rear derailleur, rear wheel skewer, etc.)