



MOCCAMASTER

HANDMADE

Repairing your Manual-Adjust Drip-Stop Brew Basket: A Step-by-Step Guide

1. Remove the **arm with the steel spring** by pressing a screwdriver into hole **A**, then **B** on the brew basket, releasing the locking pins.
2. Remove the **slider**.
3. Remove the **arm with the rubber stopper**.
4. Place your new **arm with rubber stopper** into the brew basket. The flat rubber side is positioned towards the basket, flush with the hole inside the brew basket.
5. Slide the **slider** onto the basket with the wide lip pointed towards the top of the brew basket. The grooves on either side of the **slider** slide in over the edge of the brew basket.
6. Find the small ledge under the pointed **rubber stopper**. Place the metal lip of the **arm with steel spring** onto the ledge, then push down on the plastic piece to snap the steel spring into position. Make sure that both locking pins are visible in holes **A & B**.

To watch a video of this repair process, visit our Help Center at support.moccamaster.com and search for **brew basket repair**.

Contact our Consumer Support Team at support@moccamaster.com, or call us toll-free at 855.662.2200.

