

SHIATSU NECK MASSAGER PILLOW

With Vibrating Mat









support@belmint.com



1 (844) 423-5646





SHIATSU NECK MASSAGER PILLOW

With Vibrating Mat





Congrats on your purchase!

You're on your way to have an Awesome Experience

You can now enjoy professional-quality massage whenever and wherever you want with the **Belmint** Shiatsu Neck Massager Pillow.

Select to isolate massage to your neck, back, lumbar or leg areas for a focused massage with the intensity of your preference. With the optional heating function, you can further improve the soothing and pampering massage to your tired and aching muscles. Whether you want to relax at home or you want to relieve the tension in your muscles during a stressful day at work, the **Belmint** Shiatsu Neck Massager pillow is your go-to stress relief.

All Belmint products are designed by Belmint engineers and crafted from high quality, durable materials to ensure maximum comfort. So just relax and let the Shiatsu Neck Massager pillow melt away the aches and pains of your muscles.

Now, getting a full-service massage for your neck, back area has never been this easy!

To celebrating your comfort,

The Belmint Team

Sometimes peace is hard to find

But good service shouldn't be

At Belmint, we strive to provide our customers with the ultimate self-care experience. If you encounter any issues with the performance of your device, our authorized service personnel are here to help. Check back cover for information.

Parts & Features

1 Power Cord







1 User Manual

1 Controller



1 Neck & Back Massger Mat

Technical Details

Model
BEL-NMM

Voltage
12V DC 2.5A

Power Consumption

30 W



Control Functions





Before you tap into bliss...

To prevent potential injury or property damage, please read this entire manual before operating your device. Keep it on file for future reference.

Getting Started

Using your device

- 1. If using at home, you can use the strapping system to fasten the massager to the bed to prevent it from sliding off.
- 2. Connect the AC adapter to the plug.
- 3. Connect the adapter end of the plug to the unit outlet.
- 4. Plug your Device into the appropriate outlet. DO NOT alter the plug in any way.
- 5. Turn the unit ON by pressing the POWER button.
- **6.** Use the controller to select the massage intensity, massage mode, heat function or massage location as preferred.
- 7. Turn POWER OFF by pressing the POWER button.

Efficiencies

Using 1 OR 2 TIMES PER DAY will relax the muscles and improves the circulation

Five Massage Modes

1. Pulsate

2. Tapping

3. Rolling

4. Kneading

5. Auto Mode (Auto mode will automatically change through various massage modes while in use)

Three Intensity Levels

L for low Intensity massages

M for medium Intensity massages

H for high Intensity massages

 \mathcal{I}



Safety Tips

Caution- For your safety, please read the following prior to using:

Keep this and any electrical products out of reach of children. Basic safety precautions should always be observed.

To reduce the risk of electrical shock: ALWAYS unplug the appliance from the electrical outlet immediately after using and before cleaning.

DO NOT operate in a wet or moist condition.

DO NOT use pins or any metallic fasteners on the massager. This massager is NOT INTENDED FOR MEDICAL USE.

CONSULT your doctor prior to using if you are pregnant, have a pacemaker, have had recent surgery, suffer from blood clots or have any other medical condition.

DO NOT use, especially in heated setting, for more than 15 minutes at a time.

- Extensive use may lead to the massager's excessive heating and may shorten the life of the unit
- If the massager temperature is too high for your personal preference, discontinue use and allow unit to cool.

DO NOT use the massager as a substitute for medical attention.

Cleaning & Storing

CLEANING YOUR UNIT

- To clean the outer shell of your massager, use a soft, slightly damp sponge.

- Do not allow water or any liquid to come in contact with the unit.
- DO NOT use any chemicals or harsh abrasives such as cleaners, brushes, gasoline, kerosene, glass/furniture polish or paint thinner to clean.
- NEVER immerse your massager or any electrical appliance in water.
- Never clean when the unit is on.
- Make sure the massager is turned off and unplugged from the adapter before cleaning.

STORING YOUR UNIT

- Unplug the cord from the power source.
- Loosely roll the massage mat.
- Place the massager, along with the cord, in its box or in a safe, dry and cool place.
- AVOID contact with sharp edges or pointed objects.

Keep the Peace

Troubleshooting Guide

Problem	Cause	Possible Solution
	Unit may be Unplugged	Check that the unit is plugged into the appropriate outlet or power source.
		Check that the unit is plugged into the adapter.
Unit stops working	You may have accidentally pressed the POWER	You may have inadvertently pressed the POWER button for 3 seconds, thus turning it off.
	button and turned the massager OFF.	Press the POWER button again to see if it turns back on.
	Unit may have overheated.	Unplug the unit from the outlet and let it cool before using again.

6