

**Belmint**  
PRESS ESCAPE™

PORTABLE  
**PURE FOOT &  
CALF SPA**



▼  
**PORTABLE  
PURE FOOT &  
CALF SPA**  
▲



**Belmint**  
PRESS ESCAPE™

▶ **PORTABLE  
PURE FOOT &  
CALF SPA**

User Guide

**User Guide**

For the Belmint Portable  
Pure Calf & Foot Spa

**Model**

BEL-FSWH

**Voltage**

AC 110V

**Power**

500 W

**Frequency**

60Hz

**Congratulations on your purchase of a  
Belmint Foot & Calf Spa Massager w/ Heater**

With just the touch of a button, our multifunctional foot spa massager delivers a relaxing massage, bubble bliss and thermotherapy to your achy soles, heel, and toes. The multiple water jets create thousands of oxygenated bubbles to relieve pressure, athletes foot and burning sensation. The integrated heat function along the bubble feature, you can benefit of improved blood flow and circulation as this may soften old calluses and hard areas of your feet, so you can just easily cleanse dead skin & calluses on your feet and have them feel like brand new.

The Complete Resort Experience For Your Home! For the brave men and women who work tirelessly on their feet all day long, you can kick back and receive a relaxing spa retreat that helps unwind your body and soul and recover from the hectic life of the daily grind. Belmint knows what you need for soothing your tired muscles and even more, enjoy every moment as you feel great relief from tensions, swells, and stiff. Our Foot Spa Massager is a truly pampering appliance to have around as it is integrated with all the best features of acupressure, heat, hydrotherapy to revitalize your feet and improve your overall body condition.

Relax overworked feet after a long day! Your feet have never looked or felt better once using this pedicure footbath massager! With six motorized node rollers, this foot massage machine is designed to provide a kneading massage to your tired and aching feet. This foot spa features three different massage modes that can be adjusted on the LCD screen and provide exceptional functions from heating to bubbles to improve blood circulation, relieve fatigue, and gain a softer skin.

To celebrating your comfort,

**The Belmint Team**



## ► Important

Complete the information below and retain for your records.  
You may need this information when calling Belmint  
Customer Services at:

**1 844 - 423 - 5646**

**Model Number**

BEL-FSWH

**Purchased at**

**Date Purchased**

## BEFORE YOU GET STARTED

### WHAT'S IN THE BOX?

Let's do a quick check of what's included in your purchase. You should have the following items:



- 1x Foot & Calf Spa Massager
- 1x User Manual


## PRODUCT DETAILS

### Caution

All servicing of this massager MUST be performed by authorized BELMINT service personnel ONLY. If the item has been tampered with in anyway the warranty will be voided.

### Note

The Portable Pure Calf & Foot Spa will automatically shut off after 10 minutes for your safety unless the timer is changed up to 60 minutes.



## OPERATING MANUAL

The PORTABLE PURE FOOT & CALF SPA user manual provides detailed product specifications, operations & warning information.

Please read this manual and understand it thoroughly before installation and operation.

Keep this manual for future reference.

## ALL ABOUT THE PRODUCT

### THE PORTABLE PURE FOOT & CALF SPA

The Portable Pure Foot & Calf Spa soaks away your tension with deep water massage. You and your feet will be energized with shiatsu massage from the large underwater massage hands. The rollers have 3 auto programs to work perfectly on the reflex zones of your feet.

The six underwater rollers combine with invigorating air bubbles to provide a soothing professional spa-like experience. Set the timer from 10 to 60 minutes with an interval of 10 minutes and relax. The product is completely safe to use and operate. Plugs into an AC outlet.

Enjoy the wonder Product! You will feel so smooth and beautiful afterward.

### PRODUCT SPECIFICATIONS

- Heating: 95°F - 118.4°F
- 6 rollers massage your feet
- 3 Auto programs
- Default Rolling Massage Time: 15 Minutes
- 2 Bubble Holes
- Timer: 10 - 60 Minutes, with 10 Minutes Interval
- Default Time: 30 Minutes
- Heating and Cooling keys to adjust temperature
- Electronic, Easy to use and operate
- Ergonomically designed for your legs and feet
- Power: 110V/60Hz, 500W

## **SAFETY NOTES**

### **READ & SAVE IMPORTANT SAFETY INSTRUCTIONS**

Read the following safety instructions carefully before installing and using the spa

#### **ATTENTION:**

Never turn on power nor operate this spa without water in the spa bucket

#### **ATTENTION:**

This spa is designed for personal and home use only, not for medical or commercial use. Children should not use this spa as a toy.

## **CAUTION**

- Never turn on the power nor operate this spa without water in the container.
- Do not immerse the spa in water or other liquids for cleaning.
- Do not plug or unplug the power source while your feet are in the water-filled spa.
- Always unplug the power source when you fill water or move the spa.
- Do not stand on the cover or floor of the spa. Use it only when you seat on a chair or sofa.
- Do not plug or unplug the power source if your hands are wet. Do not touch the control panel if your hands are wet.
- Do not use the spa if you have wound on legs or feet, do not use it after surgery and if you are not yet fully recovered.
- Do not use the spa continuously for more than 60 minutes at a time. The spa has preset working time of 30 minutes. It'll automatically turn off when the time is up.
- Do not use this product while you are sleeping and avoid falling sleep while the product is operating.
- It is recommended not to use the spa 30 minutes before and after meal.
- DO NOT use this product as a substitute for medical attention or treatment.
- Always remove the plug from the power outlet after use and before cleaning it.
- Never leave this spa unattended while power is connected.
- Never use the spa close to heater, fireplace, stove or other heating source.
- Supervise operating if sick, or disabled or elderly person is using this spa. This spa is not for children under age 18.
- Never use the spa if the plug or wire is damaged, always keep plug and powerline dry.
- Do not use this spa in sauna room or bathroom, or in the area with high humidity or wet floor.
- If the spa was not used for a long time, check both interior and exterior before use.
- Extensive use will lead to the product's excessive heating and shorten product life cycle.  
Always unplug the power source and allow the spa to cool before operating again.
- This product is designed for home use only.
- Unauthorized person is not allowed to repair or replace any components of this spa.

# Belmint

PRESS ESCAPE™

# Belmint

PRESS ESCAPE™

1. To avoid excessive stimulation of skin, the spa massage time should not exceed the recommended 60 Minutes at a time. (Default Time is 30 Minutes)
2. Consult your doctor before using this spa, if you have any medical concerns.
3. Foot massage should not feel unpleasant. If pain or discomfort happens, turn off the spa immediately, and consult with your doctor.
4. Overextended massage can hurt your skin and muscles. Maximum time for using the spa is 60 Minutes per day, 4-5 times a week.
5. If you are sick, or you are not able to feel the hot water temperature, or you're undergoing medical treatment, please do not use this spa.
6. Do not operate the spa after taking pain killers, sedatives or alcohol.
7. A person with heart issue, or other serious medical issues should consult with your doctor before using this spa.
8. A person with skin allergy, open wound in the leg and foot should not use the spa.

## WARNINGS PREVENTION

### PREVENTION AND REDUCE RISK OF BURNS, FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS:

1. This spa should not be left unattended when plugged in. Unplug from outlet when not in use.
2. Use spa only for its intended use as described in this manual.
3. Never operate this spa if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the product to service center for examination and repair. Never try to repair this spa by yourself.
4. Do not pull this spa by the supply power cord or use the power cord as a handle.
5. Turn all controls to OFF, before removing plug from outlet.


### ATTENTION:

- Each and every one of our Foot spas are tested before they are sold. If there are a few water droplets still left inside, it is normal. Please rinse out the foot spa and refill for use.
- To speed up the heating time, it is OK to fill warm water in the spa bucket. DO NOT fill it with water exceeding 113°F.
- Always drain water after each use.

### ATTENTION

Any issues that occur during the use of this item due to a personal situation are on your own risk.

## THE CONTROL PANEL



**Belmint**  
PRESS ESCAPE™

CONTROL BUTTONS	FUNCTION	DEFAULT	SELECTION
ON/OFF	Turn on or off power		
TEMP + / -	Increase or decrease water temperature	95°F	95°F to 118.4°F
TIMER	Set up foot spa time	30 Minutes	10, 20, 30, 40, 50, 60 Minutes
MASSAGE	Turn on or off rolling massage	15 Minutes	Slow, Fast rolling speed
RED LIGHT	Turn on or off red light	Off	Red Light
LED SCREEN	Constantly displays current water temperature inside water container		

### INSTALLATION AND OPERATION INSTRUCTIONS:

You must fill in water before turning on the spa. Do not operate this spa without water in the spa bucket.



1.	<b>INSTALLATION</b>	<ul style="list-style-type: none"> <li>• Check and make sure there is no damage on power cord and the product when you open the package case.</li> <li>• The spa comes with 4 wheels. Two of them have brakes, insert these two in the holes on the bottom of spa near the drain pipe. The other two shall be inserted in opposite side.</li> <li>• To install the wheels, simply push the metal stick into the holes in the bottom of spa corners directly.</li> </ul>
2.	<b>STABILIZE THE SPA</b>	<ul style="list-style-type: none"> <li>• Place the spa on flat and dry floor where you want to use.</li> <li>• Make sure the 4 wheels on the bottom of the spa are stabilized so that the spa will not move around during use.</li> <li>• Make sure you are seated on a chair or sofa before starting.</li> <li>• Do not plug in power cord to an outlet now.</li> </ul>
3.	<b>FILLING IN WATER</b>	<ul style="list-style-type: none"> <li>• You must fill in water before turning on the foot spa. Never try to operate this spa without water in the bucket.</li> <li>• Filling in water with a water bucket or a clean pot. Do not have your spa under faucet directly to fill water.</li> <li>• Be careful NOT to spill water on the control panel.</li> <li>• To speed up water heating, you can fill in warm water but the warm water temperature shall be lower than 113°F.</li> </ul> <p><b>WATER LEVEL:</b></p> <ul style="list-style-type: none"> <li>• It is recommended to fill in water up to 50%-60% (just about over half full) of the entire bucket.</li> <li>• The maximum water level is 70% of the water container.</li> </ul>
4.	<b>ON / OFF</b>	<ul style="list-style-type: none"> <li>• Press ON/OFF button once to turn on power, the two-digit LED display immediately shows the current water temperature inside water container.</li> <li>• The default spa massage time is 30 minutes once the power is turned on. You can use <b>TIMER</b> to increase spa massage time. ( up to 60 Minutes)</li> <li>• The default maximum water heating temperature is 95°F once the power is turned on.</li> <li>• <b>HEATING</b> Function is ON automatically if the current water temperature is lower than its default 95°F.</li> <li>• Plug in power cord to the power outlet.</li> </ul>

5.	<b>HEATING</b>	<p><b>AUTOMATIC WATER TEMPERATURE BALANCING SYSTEM:</b></p> <ul style="list-style-type: none"> <li>• The default maximum water heating temperature is 95°F once the power is turned on.</li> <li>• If the just-filled-in water temperature is lower than 95°F, the heating function will be turned on automatically and stopped when its water temperature reaches 95°F.</li> <li>• Heating function will be turned on automatically and stopped when its water reaches 95°F. When its water temperature cools down below 95°F, the heating function will be turned on automatically again, and so on.</li> <li>• When the water temperature reaches its default maximum temperature of 95°F, the <b>KEEP WARM</b> function takes effect.</li> </ul> <p>Note: The heating function will not be on if your fill-in water temperature is already higher than its default maximum 95°F.</p> <ul style="list-style-type: none"> <li>• If you prefer to change its default maximum water temperature to be higher than 95°F, you can press the TEMP + / TEMP - to reset the maximum water heating temperature.</li> <li>• The highest heating temperature you can set is 118.4°F.</li> <li>• The lowest heating temperature you can set is 95°F.</li> </ul>
6.	<b>TEMP + / -</b>	<p><b>WHEN TO USE TEMP (+/-) :</b></p> <ul style="list-style-type: none"> <li>• The Temp +/- button can be used to change maximum water heating temperature under any massage modes.</li> <li>• Press TEMP+/- to increase water heating temperature you want (such as 107.6°F). After 3 seconds, your just-set temperature will disappear from LED screen, and its LED display will switch back to show its current water temperature.</li> <li>• Press TEMP+/- to decrease water heating temperature (such as 96.8°F). After 3 seconds, your just-set temperature will disappear from LED screen, and its LED display will switch back to show its current water temperature.</li> <li>• To protect the heating spa, it is recommended NOT to set the temperature to the maximum level (118.4°F).</li> </ul>

		<p><b>MINIMUM AND MAXIMUM WATER TEMPERATURE :</b></p> <ul style="list-style-type: none"> <li>The highest heating temperature you can set is 118.4°F.</li> <li>The lowest heating temperature you can set is 95°F.</li> <li>If you do not press the TEMP +/- button to adjust the default heating temperature, the water temperature will stay at 95°F (default setting).</li> <li>The Automatic Water Temperature Balancing System will be initiated to turn on/off the heating function automatically to keep water temperature at 95°F.</li> </ul>
7.	<b>TWO-DIGIT DISPLAY</b>	<ul style="list-style-type: none"> <li>When the power is turned on, the LED screen displays its current water temperature inside the water container and its default working time (30 Minutes).</li> </ul>
8.	<b>RED LIGHT</b>	<p><b>PRESS RED LIGHT BUTTON TO TURN ON RED LIGHT:</b></p> <ul style="list-style-type: none"> <li>Press red light button once: RED LIGHT is ON.</li> <li>Press red light button twice: RED LIGHT is OFF.</li> </ul>
9.	<b>MASSAGE</b>	<ul style="list-style-type: none"> <li>Press MASSAGE button to turn On/Off rolling massage function.</li> <li>Default time for rolling massage is 15 Minutes.</li> <li>Massage Mode: 3 modes to choose for slow or fast rolling massage speed.</li> </ul>
10.	<b>TIMER</b>	<ul style="list-style-type: none"> <li>Default spa massage time is 30 Minutes.</li> <li>Press TIMER button to choose 10, 20, 30, 40, 50, 60 Minutes.</li> <li>It is recommended NOT to use the spa for more than 60 minutes continuously. Always take 10 to 15 minutes break after each cycle.</li> </ul>
11.	<b>TURN OFF POWER</b>	<ul style="list-style-type: none"> <li>Press the ON/OFF button turn off power completely.</li> <li>Unplug the spa from outlet.</li> </ul>
12.	<b>SPA</b>	<ul style="list-style-type: none"> <li>Bubble is located inside the water container.</li> </ul>

13.	<b>WATER DRAINAGE</b>	<ul style="list-style-type: none"> <li>This spa has static water drainage.</li> <li>You MUST unplug the spa from outlet before drainage.</li> <li>After each use, before trying to drain out water, always turn off all functions on control panel before drainage.</li> <li>Drain the spa in bathroom or put a water bucket under the water drainage pipe; make sure no water will spill to floor.</li> <li>Release the drainage pipe to the case after finishing drainage.</li> <li>Lock back the drainage pipe to the case after finishing drainage.</li> </ul> <p><b>ATTENTION :</b></p> <ul style="list-style-type: none"> <li>There may have a small amount of water left inside the water container after drainage. Use a dry towel to clean up.</li> <li>Never try to pour out water by lifting the water container.</li> </ul>
14.	<b>CLEANING</b>	<ul style="list-style-type: none"> <li>Make sure your hands are not wet unplugging the power cord from the outlet.</li> <li>After each use, before trying to clean up the container with a dry towel, always turn off power on the control panel and unplug the power cord from the wall outlet first.</li> <li>Allocate power cord properly to make sure not to immerse water.</li> <li>Do not use the power cord as a hanger to pull or drag away the spa.</li> <li>Use only soft, dry towel to clean up the control panel or the water container.</li> </ul>

### CLEANING AND MAINTENANCE

- Before cleaning, you must turn off the spa and unplug the power cord from the electric outlet.
- Make sure the water drainage valve is closed and the power cord is properly stored onto the back of the case.
- It is recommended always drain out water using the water drainage valve; do not pour out water over the control panel or cover.
- Clean the water container only with a soft, dry towel. Never use strong abrasives, detergents or cleaning agent for cleaning.
- Do not immerse the spa in water or under faucet to do cleaning or filling in water.

## STORAGE

- Unplug the spa from electric outlet and allow it to cool down and dry.
- Store it in its box or in a clean, dry place.
- Do not drag or hang the spa with the power cord.
- This spa appliance is designed for INDOOR USE ONLY.
- Do not put the spa massager close to fireplace or other heating sources.

### NOTE

This product is not intended to treat, cure, or prevent any disease.

## TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTIONS
Heating NOT Working	Heating function is turned off. It may reach the preset maximum water temperature. The adjusted highest water temperature may be too low. The current water temperature in the bucket is already higher than your preset water temperature.	Press the TEMP+ to adjust the preset highest water temperature.
	Preset working time is up (maximum is 60 Minutes).	Try to unplug the power source completely for a while and plug in the power again
Spa STOPS Working	Auto shut off for protection when using for very long time.	
	Water drainage valve is not closed.	Check and make sure the water drainage valve is closed.
	The water temperature is higher than your preset highest temperature.	Try to fill in cold water to cool down the water temperature. Or, reset to the highest water temperature.
	Rolling massage is over-used.	Turn off the spa completely and let it cool down for a while before using it again.