

# 3-in-1 WIRELESS CHARGE PAD

To begin charging, a Type-C cable must be connected to the chargepad and a power supply. Ensure your device needing to be charged is placed flat on the appropriate chargepad.

Simply remove your device from the chargepad when needed. It is safe to remove a device at any time from the chargepad.

## Note for watch charge pad

Only compatible with Apple Watches.

When charging watches, do not set the angle to 30 degrees.

Charging may be interrupted or not possible at this angle.

## Note for earbuds charge pad

Works with TWS Earphones that support wireless charging.

## SPECIFICATIONS

charge port	USB-C
input	9V-2A, 12V-2A
mobile output	5W/7.5W/10W/15W
watch output	2.5W
earphones output	3W

Only works with Smartphones that support wireless charging.

Only works with TWS Earphones with wireless charging.



Only supports Apple Watches. Does not support other smart watches.



## 3-in-1 WIRELESS CHARGE PAD

### Charging

Connect the included charge cable to a USB port on a USB charge adaptor or PC port. Confirm orientation and connect the Type-c connector to the port on the chargepad.



Phone Charger  
15W Magnetic Fast Charge



Watch Charger  
Only works with Apple Watch



Earphones Charger