

# Hydrophobia® Rain Cover EP-S Eyepiece Attachment

1. Remove the camera's eyepiece by sliding it upward and off the viewfinder.



2. Align the groove on the EP-S with the rails on the camera's viewfinder.




3. Firmly slide the EP-S down on the viewfinder rails until fully seated.



# Hydrophobia® Rain Cover EP-NSI Eyepiece Attachment

1. (a) Remove the camera's eyepiece by flipping the viewfinder shutter lever to the "closed" position.  
(b) Unscrew the eyepiece by turning it counter-clockwise.



2. Screw the Nikon eyepiece onto the EP-NSI.



3. Screw the EP-NSI into the camera until snug.



# Hydrophobia® Rain Cover EP-N Eyepiece Attachment

1. Remove the camera's eyepiece by sliding it upward and off the viewfinder.



2. Align the groove on the EP-N with the rails on the camera's viewfinder.



3. Firmly slide the EP-N down on the viewfinder rails until fully seated.



# Hydrophobia® Rain Cover EP-15 Eyepiece Attachment

1. Remove the camera's eyepiece by sliding it upward and off the viewfinder.



2. Align the groove on the EP-15 with the rails on the camera's viewfinder.



3. Firmly slide the EP-15 down on the viewfinder rails until fully seated.



# Hydrophobia® Rain Cover EP-20 Eyepiece Attachment

1. Remove the camera's eyepiece by sliding it upward and off the viewfinder.



2. Align the groove on the EP-20 with the rails on the camera's viewfinder.



3. Firmly slide the EP-20 down on the viewfinder rails until fully seated.



# Hydrophobia® Rain Cover EP-NZ Eyepiece Attachment


1. Remove the camera's eyepiece by sliding it upward and off the viewfinder.



2. Align the groove on the EP-NZ with the rails on the camera's viewfinder.



3. Firmly slide the EP-NZ down on the viewfinder rails until fully seated.



# Hydrophobia® Rain Cover EP-F Eyepiece Attachment

1. Remove the camera's eyepiece by sliding it upward and off the viewfinder.



2. Align the groove on the EP-F with the rails on the camera's viewfinder.



3. Firmly slide the EP-F down on the viewfinder rails until fully seated.



# Hydrophobia® Rain Cover EP-SP Eyepiece Attachment

1. Remove the camera's eyepiece by sliding it upward and off the viewfinder.



2. Align the groove on the EP-SP with the rails on the camera's viewfinder.



3. Firmly slide the EP-SP down on the viewfinder rails until fully seated.





# Hydrophobia® Rain Cover EP-NZP Eyepiece Attachment

1. Remove the camera's eyepiece by sliding it upward and off the viewfinder.



2. Align the groove on the EP-NZP with the rails on the camera's viewfinder.



3. Firmly slide the EP-NZP down on the viewfinder rails until fully seated.

