INSTRUCTIONS



SEEDLING HEAT MAT COMMERCIAL 60" X 21"



DIRECTIONS

- 1. 1. Place the mat on a stable dry surface this side up.
- 2. 2. Plug the mat into a 120V grounded outlet only.

SPECIAL NOTES - PLEASE READ BEFORE OPERATING

This heat mat MUST be used with a temperature controller. Failure to do so will result in undesirable root zone temperature. We recommend the Hydrofarm Digital Temperature Controller for Heat Mat (item# MTPRTC). A total of (4) units may be plugged into the Hydrofarm temperature controller.

*WARNINGS:

- Fire or electric shock may result from improper use
- Make sure that the surface under the mat is free of sharp points or objects which might puncture or damage the mat
- . DO NOT place the mat inside the propagation tray or cover it directly with soil or any other growing medium
- · DO NOT immerse in water
- DO NOT place any heat insulating materials over the mat as this could cause it to overheat
- COVER THE 120V PLUG WITH THE CAP WHEN NOT IN USE

SPECIFICATIONS:

- Size 60" L x 21" W
- Voltage 120 VAC
- Wattage 140 Watts

MTMDU Instructions - rev 4.27.15

