

	シャープ		ソニー		パナソニック		東芝		LG		その他		
43V			KJ-43W870C	●	TH-43CS650	●	43J20X	●	43UH7500	●			
43V			KJ-43X8500C	●	TH-43D300	●	43G20X	●	43UH6500	●			
43V			KJ-43X8300D	×	TH-43D305	●	43J10	●					
43V			KJ-43W730E	●	TH-43DX750	●	43Z700X	●					
43V			KJ-43X8000E	×	TH-43EX750	●	43C310X	●					
43V			KJ-43X8500C	●	TH-43FX750	●	43M520X	●					
43V			KJ-43X8500F	●	TH-43E300	●							
43V					TH-43FX600	●							
42V	LC42DR9	×	KDL42W650A	×	TH-L42G3	●	42C7000	●	42LA6400	●	HITACHI	L42C07	●
42V	LC42DS3	●	KDL42W800B	×	TH-P42S3	●	42C8000	●	42LA6600	●	HITACHI	L42V09	●
42V	LC42DS5	●	KDL42W802A	●	TH-42AS600	●	42CV500	●	42LA8600	●	HITACHI	L42XP03	×
42V	LC42DS6	●	KDL-42W800B	×	TH-42AS650	●	42H7000	●	42LB57YM	×	HITACHI	L42XP035	×
42V	LC42DX1	●			TH-42PX300	×	42H8000	●	42LB5810	×	HITACHI	L42XP05	×
42V	LC42ES50	●			TH-42PX500	×	42H9000	●	42LE8500	●	HITACHI	L42XP07	●
42V	LC42EX5	●			TH-42PX600	×	42HE1	●	42LM5800	●	HITACHI	L42XP08	●
42V	LC42GX3	●			TH-42PX80	×	42J8	●	42LM6600	●	HITACHI	L42ZP05	×
42V	LC42GX4W	●			TH-42PZ700	×	42R1	●	42LM7600	●	HITACHI	P42GP08	●
42V	LC42GX5	●			TH-42PZ700SK	×	42RE1	●	42LW5700	●	HITACHI	P42HP03	●
42V	LC42RX1W	●			TH-42PZ750SK	×	42Z1	●	42LW6500	●	HITACHI	P42HP05	●
42V	LC42XJ1	●			TH-42PZ80	×	42Z2	●	42LB6700	×	HITACHI	P42HP06	●
42V	PN-E421	●			TH-42PZ800	×	42Z3	●	42LB5810	×	HITACHI	P42HP06	●
42V	LC42GX3W	●			TH-42PZ85	×	42Z3500	●	42LE8500	●	HITACHI	P42HR01	×
42V					TH-42PZR900	×	42Z7	●	42LE5500	●	HITACHI	P42HR02	×
42V					TH-L42D2	●	42Z7000	×			HITACHI	P42HV01	×
42V					TH-L42DT5	●	42Z8	●			HITACHI	P42XP03	●
42V					TH-L42DT60	●	42Z8000	×			HITACHI	P42XP035	●
42V					TH-L42E5	●	42Z9000	×			HITACHI	P42XP05	×
42V					TH-L42E60	●	42ZG1	●			HITACHI	P42XP07	●
42V					TH-L42ET5	●	42ZG2	●			HITACHI	P42XP500CS	●
42V					TH-L42FT60	●	42ZH7000	●			HITACHI	P42XP700CS	●
42V					TH-L42G3	●	42ZP3	●			HITACHI	UT42XP03	×
42V					TH-P42G1	●	42ZS1	●			HITACHI	UT42XP770	×
42V					TH-P42G2	●	42ZT3	●			HITACHI	UT42XP770	×
42V					TH-P42GT3	●	42ZV500	×			HITACHI	UT42XP800	×
42V					TH-P42GT5	●					HITACHI	UT42XV700	×
42V					TH-P42PA20	×					HITACHI	W42PH8000	×
42V					TH-P42PX500	×					Pioneer	PDP434HD	●
42V					TH-P42PX70SK	×					Pioneer	PDP427HX	●
42V					TH-P42R1	●					Pioneer	PDP-433HD-U/S	●
42V					TH-P42R2	●					Pioneer	PDP436HD	●
42V					TH-P42RT2B	●					Pioneer	PDP-A472HX	×
42V					TH-P42S2	●					Pioneer	PDP-428HX	●
42V					TH-P42S3	●					HITACHI	P42H01-2	×
42V					TH-P42ST3	●							

