

OWNERS MANUAL





WELCOME

*Welcome to the world of clean
air with the Filter Queen and
Captiva Filtration.*

Having become the proud owner of the most efficient and state-of-the-art home cleaning equipment available, you are one of the millions who have placed their trust in the Filter Queen name. Your new Filter Queen combines the most advanced engineering and construction with maximum reliability and trouble free, long-lasting performance. The Filter Queen is manufactured in the United States using progressive manufacturing methods and techniques, under a rigorous total quality control program.

This manual contains explanations and illustrations of the Filter Queen's many home cleaning features. Please take a few moments to read all the sections in this manual and familiarize yourself with the Filter Queen. If you need any additional information or service, please contact your Local Authorized Distributor, or call:

1-800-344-1840

*for the Distributor nearest you. Thank you for
choosing Filter Queen.*

HMI Industries Inc.



Safety	3
Healthier Living	4
Five Levels of Filtration.....	5-6
Installing Cellulose Filter Cone.....	7
Installing Enviropure	7-8
Installing Flat Disc Filter.....	9
Air Scenting Chamber.....	10
Filter Queen Parts	11-12
Pow-R-Nozzle	13-14
Circuits	15
Headlight	15
Caution Light	15
Other Attachments	16-18
Brushes	17-18
Crevice Tool	18
Limited Warranty	19
Service and Loss by Fire Policy.....	20
Warranty Summary	21
Maintenance Chart	22

When using an electrical appliance, basic precautions should always be followed, including the following:

Read all instructions before using Filter Queen

WARNING—To reduce the risk of fire, electric shock, or injury:

1. Do not leave Filter Queen plugged in. Unplug from outlet when not in use and before servicing.

2. Do not use outdoors or on wet surfaces.

3. Do not allow to be used as a toy. Close attention is necessary when used by or near children.

4. Use only as described in this manual. Use only manufacturer's recommended attachments and scents.

5. Do not use with damaged cord or plug. If Filter Queen is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, bring it to an Authorized Service Center.

6. Do not pull or carry by cord, use cord as handle, close a door on cord, or pull cord around sharp edges or corners. **Do not** run Filter Queen over cord. Keep cord away from heated surfaces.

7. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.

8. Do not handle plug or Filter Queen with wet hands.

9. Do not put any object into openings. **Do not** use with any opening blocked; keep free of

dust, lint, hair, and anything that may reduce airflow.

10. Keep hair, loose clothing, fingers and all parts of body away from opening and moving parts.

11. Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.

12. Do not use without filters in place.

13. Turn off all controls before unplugging.

14. Use *extra care* when cleaning on stairs.

15. Do not use to pick up flammable or combustible liquids such as gasoline or use in areas where they might be present.

16. The hose contains electrical wires. **Do not** use if damaged, cut, or punctured. Avoid picking up sharp objects.

17. Always turn off the Filter Queen before connecting or disconnecting either the hose or motorized nozzle.

18. To reduce risk of electric shock, your *Filter Queen* has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. **Do not** change the plug in any way.

SAVE THESE INSTRUCTIONS

Your Filter Queen is intended for household use only.

1. Asthma and Allergies

Removing pollen, mold spores, dust, dust mites, bacteria and other pollutants at the source in your home is the mission of the **Filter Queen**. The five levels of filtration in the **Filter Queen** ensure that 99.98% of contaminants at 0.1 microns are removed. This provides real relief to allergy and asthma sufferers.



2. Odor Removal and Air Freshening

The **Enviropure** in your **Filter Queen** helps remove over 300 toxic gases and odors from your indoor environment to keep your air smelling clean and fresh. Or, use your **Filter Queen Scents** as per instructions on page 10, to create a pleasant, fragrant atmosphere throughout your home.



3. Common Cold Sufferers

Even common cold sufferers may find relief with the use of Oil of Eucalyptus in the **Air Deodorizer**. Allow the Eucalyptus scent to circulate in the bedroom/nursery before the cold sufferer goes to sleep.



Filter Queen with Captiva™ Filtration.

The cross section below illustrates how the famous cyclonic action of your **Filter Queen** assures *sustained air flow*. As the incoming dirt and airstream enters the dirt container, it strikes the inlet guide. This creates centrifugal force which throws the dirt to the sides of the container, away from the **Cellulose Filter Cone**. This means that the air does not have to push its way through the accumulated dirt and filth, but is drawn through 5 levels of filtration where it is returned to the room filtered and cleared of many toxic gases and odors that create an unhealthy home environment.



home with clean air to breathe.

The Filter Queen with Captiva features Five Levels of Filtration:

Five levels of filtration help remove dirt, allergens, dust, gases and odors from your indoor air. The **Filter Queen** removes pollutants from the air with a combination of **Cyclonic Action**, the **Cellulose Filter Cone**, the **Medi-Filter Cone**, the **Enviropure Cone**, and the **Flat Disc** filter. These 5 levels are so efficient that they remove 99.98% of particles at 0.1 micron.

During cleaning, the larger particles are first separated from the air by **cyclonic action**. The air then passes through the **Cellulose Cone** where the 2-ply cellulose fibers block more of the particles. After this, the air passes through the electrostatic **Medi-Filter** cone. The **Medi-Filter** has a permanent electrostatic charge, which attracts the smallest particles like a magnet. With the **Medi-Filter** in place, the **Filter Queen** captures particles at an efficiency level greater than HEPA. This means that more of the pollen, dust, mold spores, bacteria and viruses are

removed from your air.

The air then passes through the **Enviropure Activated Charcoal** cone which helps to remove over 300 toxic gases and odors from your indoor environment. With the **Enviropure** in place, your **Filter Queen** is highly effective in helping remove not only tobacco smoke, but also many of the 4700 chemicals released during smoking. The activated charcoal in the **Enviropure** also traps organic gases released by furniture polish, hair spray, paints, detergents, dry cleaned clothing, insect repellent, moth balls and hundreds of other household products. **Enviropure** also helps to remove unpleasant odors from cooking, pets or other sources, from your air, leaving it fresh and cleaner smelling. The air then passes through a final filter, the **Flat Disc** filter, which also acts as motor protection, should your other filters be installed improperly.

About once a month (or when **Dirt Container** is full) empty your **Filter Queen** and insert new **Filter Cone**. NOTE: DO NOT REUSE THE FILTER CONE. To do this:

1. Unplug **Power Cord**.
2. Release **Side Clamps** and lift off **Filter Queen Power Unit**.



3. Remove **Enviropure**. Replace every 3 months or when odors reappear.



4. Remove **Medi-Filter** cone. Replace every 6 months or as needed.
5. Empty **Dirt Container** into a large, open garbage bag. Allow used cone to fall as well. The **Dirt Container** and **Gasket** may be washed and

dried to remove any dust and odors.



6. Open new genuine HMI Industries **Cellulose Filter Cone**, insert point of cone into cone locator at bottom of the **Dirt Container**. Be sure that all edges of the cone are even with the **Gasket** of the **Dirt Container**.



7. Place the **Medi-Filter** cone inside the cellulose filter cone.
8. Place the **Enviropure** cone inside the **Medi-Filter** cone making sure that the ribbon in the **Enviropure** is aligned with the printing on the cellulose cone and the inlet of the **Dirt Container**. (See diagram A). Then center all the cones by placing your forefinger at

How to Change the Enviropure Filter

the point of the *Enviropure* cone and moving it into position on top of the *Medi-Filter* cone. (See diagram B.)

9. Replace the power unit and lock the side clamps in place. **Be sure all three tabs of Cone show outside of Power Unit.**



REMEMBER:


For proper installation be sure to align:

- The ribbon and seam of the Enviropure.
- The printing of the cellulose cone.
- The suction inlet of the dirt container.

Do not align the folds in the three cones. This will ensure proper seating of the filters.



A



B

ENVIROPURE FILTER

How to Change the Flat Disc Filter

Your **Flat Disc Filter** acts as a safeguard to prevent motor damage. Check the **Filter** every three months (when you change your **Enviropure Filter**) to make sure it is clean. Change the **Flat Disc Filter** once a year, or earlier if it appears dirty.

1. Unlock **Clamps** on **Power Unit** and expose the **Cone Guard**. Remove the **Cone Guard** by twisting off the **Thumb-Screw** in a counter-clockwise direction.



2. After removing **Cone Guard**, the **Flat Disc Filter** is fully exposed. To remove it, pull back the plastic **Retainer Ring** with your finger and lift out. The **Filter** may now be discarded.



3. Place new **Flat Disc Filter** over center section of screen. Place plastic **Retainer Ring** on the **Filter**, squeezing it slightly to make sure that the **Ring** and **Filter** are held in place.
4. When replacing **Cone Guard**, be sure outer edge is seated on rubber lip of **Power Unit**. Replace **Thumb-Screw**.

Using the Air-Scenting Chamber

NOTE: Disconnect *Electric Hose* from *Power Unit* before using *Air-Scenting Chamber*.

1. Remove *Exhaust Cap* on top of *Filter Queen* with slight turn to the left and lift off.



2. Place a few drops of *Filter Queen Oil of Eucalyptus, Pine, Rose or Lemon* on grey felt *Air-Scent Pad* located on the bottom side of *Cap*.



CAUTION: Do not saturate or use perfume or other liquid not sold by *HMI Industries Inc.* Use of other liquids could cause damage to your motor and void the warranty. (To replace felt *Air-Scent Pad*, twist clamp to the left and lift off; insert new *Pad*. Replace clamp, lock in position.)

3. Close *Air-Scenting Chamber* by replacing *Cap* and locking with slight turn to right until it clicks into place.
4. Press *Starter Switch*. Within minutes you will notice the effects of your *Filter Queen Air-Scenting Chamber* throughout the room.



WARNING:

Electric Shock could occur if used outdoors or on wet surfaces



CAUTION: DO NOT LEAVE FILTER QUEEN UNATTENDED WHILE MOTOR IS RUNNING.

If you are interrupted while cleaning with the Filter Queen Pow-R-Nozzle, (e.g. phone calls, unexpected visitors, etc.), be sure to first turn off power by pressing Starter Switch on the Filter Queen. This also automatically turns off the Pow-R-Nozzle. Failure to do so may result in overheating of motors and subsequent damage to the Filter Queen System and/or floor coverings.

1. Pow-R-Nozzle with Edge Cleaner

For cleaning rugs and carpets. Motor-driven **Revolving Brush**. Soft vinyl **Bumper** on three sides protects furniture from accidental bumps, nicks and scratches.

2. Caster set

Rubber Ball Casters roll smoothly on rugs or hard surfaces. Always align your front **Caster Wheel** directly under your **Suction Inlet** to prevent tipping.

3. Suction Inlet

Designed to impart "Cyclonic Action" to incoming air and dust.

4. Outlet

Receptacle for plugging in Electric Hose.

5. Attachment Crown

High-impact ABS holds five most essential cleaning attachments within easy fingertip reach.

6. Caution Light

When lit, this indicates that the **Motor** in the **Power Unit** has overheated. **Motor** will automatically stop running to prevent damage. Press down on your **Starter Switch** to turn your Unit "OFF," remove **Power Cord** from the wall outlet immediately. Let **Unit** cool. This condition may be caused by obstructed air flow. Check for a blockage in the **Attachments, Hose, or Wand**. The filters may also need to be replaced. If you have checked for the above, and the condition persists, take the **Unit** in to your local authorized **Service Center**.

7. Air-Scenting Chamber

Place **Filter Queen Scent** on **Felt Pad** under **Exhaust Cap**, replace **Cap** and run **Unit** to freshen your air.

8. 6-Inch Nozzle & Brush

Removes imbedded dirt from overstuffed furniture, mattresses, drapes, curtains, auto upholstery, walls and wood paneling.

9. Crevice Tool

For reaching hard-to-get-at places.

10. 10-Inch Brush

For cleaning hard-surfaced floors.

11. Top Exhaust Cap

Opens with a slight twist to the left to convert your **Filter Queen** into an efficient blower.

12. Round Brush

For all dusting operations; eliminates the dust cloth.

13. Starter Switch

Press down to start or stop **Filter Queen**.

14. HI-LO Power Switch

Adjust suction power to easily clean the daintiest curtains without fear of snagging (LO power) yet permits use of full power for regular "deep-down" cleaning (HI power).

15. Side Clamp

Opens with a flick of your finger. Keeps **Power Unit** locked in place.

16. Stainless Steel

Metal Wand

Air-tight, lock-tight single piece assembly.

17. Electric Hose Assembly

P.V.C.-covered, current carrying wire reinforced Hose with **Pistol-Grip Handle** and convenient **Pow-R-Nozzle "ON-OFF" Switch**.

How to Attach Pow-R-Nozzle

POW-R-NOZZLE

1. Slide **Rubber Sleeve** on **Wand**, over **Nozzle Swivel Neck**, until it locks into place. The **Wand** swivels more than 90 degrees, allowing it to lie flat on the floor for cleaning under low furniture.



2. Join male plug end of **Cord** extending from **Nozzle** with lower end of **Wand Cord** by firmly pushing together. Attach **Electric Hose** to other end of **Wand** by pushing handle-end of **Hose** over **Wand** until **Locking Pin** snaps into place.



3. Plug short length of cord extending from **Wand** into female connector on handle-end of **Hose**.



4. Attach other end of **Hose** to **Filter Queen Power Unit** by lining up white arrow of **Hose** over top pin of **Suction Inlet**. Lock with slight turn to right.



5. The "ON/OFF" markings on your new Filter Queen Majestic Triple Crown feature the international symbols of "I" for **ON** and "O" for **OFF**. Also note that the switch on the hose handle that controls the **Pow-R-Nozzle** has been designed for safety to have two **OFF** positions and one **On** position. To turn the **Pow-R-Nozzle ON** press the switch to its most forward position. Returning the switch to either the middle or the rear position will turn the **Pow-R-Nozzle OFF**.

6. Height of nozzle from rug is adjusted by knob in back of **Nozzle**. For short nap rugs, pointer on knob should be set at "Lo." With higher napped rugs and carpeting, advance pointer clockwise to proper **Nozzle** height.

NOTICE: THIS HOSE CONTAINS ELECTRICAL WIRES.

Clean with the Pow-R-Nozzle

Attach **POW-R-NOZZLE** to the **Filter Queen** as shown on page 13. Adjust height of **Nozzle** rollers to type of rug or carpeting you are cleaning ("LO" for short nap; "HI" for shag or sculptured carpeting.) After you've used your **Pow-R-Nozzle** a few times, you'll know which adjustment gives the best cleaning results. Use long, slow strokes. When cleaning thicker rugs, use a criss-cross pattern to raise nap and give them a fluffier appearance.

To clean edge: When you come to the edge of wall-to-wall carpeting, turn **Nozzle** at a 90-degree angle to the wall. This allows powerful air flow from edge of **Nozzle** to clean right up to baseboard.

To clean stairs: Disconnect **Wand Cord** from **Pow-R-Nozzle**. Detach **Wand** from **Hose**. Connect **Hose** directly to **Pow-R-Nozzle**; reconnect male plug from **Nozzle** into female plug at **Hose**. **Pow-R-Nozzle** may be used to clean stairs, carpeting, overstuffed furniture, mattresses, etc. On narrow steps and risers, use **6-Inch Nozzle** attached directly to **Hose** instead of **Pow-R-Nozzle**.

STORAGE: Avoid sharp bends in **Electric Hose** by removing **Hose** from the **Unit** before storing.

How to care for your Pow-R-Nozzle: Periodically remove top cover and check **Belt** for tension and wear. To remove cover, unfasten four screws marked "To remove Top." To adjust or replace **Belt** or **Brush**, see instructions on label attached inside baseplate. To remove **Bottom Plate**, unfasten two screws marked, "To Remove Bottom Plate" and unhook from lip of **Nozzle**. Remove any lint, nap, or other debris that may have accumulated in motor compartment or



behind **Brush Roller** by cleaning with **Crevice Tool** attached to **Hose**. Also remove debris buildup on end of **Brush**. Be sure to re-insert fiber and steel washers. Replace plate by securely hooking under front lip of **Nozzle**; replace two screws. Replace top cover and four screws.

POW-R-NOZZLE

Resettable Circuit Breaker:

Your **Pow-R-Nozzle** is equipped with a resettable **Circuit Breaker**. The **Circuit Breaker** will protect your **Motor** from damage if the **Pow-R-Nozzle** should become clogged or the **Revolving Brush** stalls. (This could be caused by picking up a strand of rope or large object, such as a sock.)

If for any reason the **Circuit Breaker** stops the **Pow-R-Nozzle**, unplug the **Cord** and correct the problem by removing foreign object from **Brush**. Then press red **Reset Button** located on the back of the **Pow-R-Nozzle** and start **Unit** in usual manner.

**How To replace Headlight:**

Disconnect **Filter Queen Power Cord** from electrical outlet and disconnect **Plug** from lower end of **Wand** to **Pow-R-Nozzle**. Detach **Wand** from **Pow-R-Nozzle** by pressing down on the rubber button and pulling apart. Remove top cover by unfastening the four screws which are marked. "To Remove Top." To remove **Bulb**, press inward and twist to the left. Replace with a **15 watt Bulb** (Sylvania 15 T7 DC or equivalent). Push new **Bulb** into **Socket** and lock into position

by twisting to the right. Replace top cover and four screws.



Caution Light: When lit, this indicates that the **Motor** in the **Power Unit** has overheated. **Motor** will automatically stop running to prevent damage. Press down on **Starter Switch** to turn Unit "OFF." Remove **Power Cord** from wall outlet immediately. Let **Unit** cool. This condition may be caused by obstructed air-flow. Check for blockage in the **Attachments, Hose or Wand**. The **Filters** may need to be replaced. If you have checked all of the above, and the condition persists, bring the **Unit** to your local Authorized Service Center.

**How to Replace Caution Light:**

It is recommended that replacement of **Caution Light** be done by an Authorized Service Center.

Cleaning With Other Attachments

1. Leave **Electric Hose** attached to **Power Unit**. Unplug **Power Cord** from outlet on **Power Unit Dome**.



2. Unplug **Wand Electric Cord** from wand-end of **Hose**, and detach **Wand** and **Pow-R-Nozzle** from **Hose**. Unplug **Wand Cord** at **Pow-R-Nozzle**-end, and detach **Pow-R-Nozzle** from **Wand**.



You may use the **Round Brush**, **Crevice Tool** or the **6-Inch Nozzle and Brush** from end of the **Wand**, or from end of **Hose**.

3. Disconnect **Wand** from **Hose**, or **Wand** from **Pow-R-Nozzle**, by pressing down on rubber button and pulling apart. Your **Hose**, or your **Hose** with **Wand**, is now ready to use with any attachment.



4. To attach cleaning tool to **Hose** or to **Wand**, line up metal button on tool with rubber button on **Hose** or **Wand** and press together until they click in place.



5. Press **Starter Switch** on **Power Unit**.



10-Inch Brush Cleans Hard Floors, Walls 6-Inch Brush Cleans Upholstery

BRUSHES

10-INCH BRUSH

Clean an entire 10-inch area in one stroke. Ideal for hard-surfaced floors such as tile, linoleum, wood and even concrete. Also cleans walls, screens, ceilings, shades or any flat surface. To attach **Brush**: First unplug **Pow-R-Nozzle Cord** from **Wand**. Remove **Pow-R-Nozzle** from **Wand** by depressing coupling button and pulling apart. Next, insert metal end of **Brush** into rubber end of **Wand** and use in same manner as **Pow-R-Nozzle**.

NOTE: When cleaning wall surfaces, work in a straight line from the bottom up; overlap each succeeding brush stroke.



After each use, remove lint, threads, etc., by rubbing **Brush** with open end of **Hose** while your **Power Unit** is "ON". If **Brush** is soiled, rinse in mild soap solution and let dry

before using on light-colored walls or ceilings.

6-INCH NOZZLE & BRUSH

Cleaning overstuffed furniture, mattresses, fabrics: To remove deeply imbedded dirt in heavy fabrics, use the **6-Inch Nozzle** without **Brush**. Use the **Brush** when fabric is covered with threads, lint, etc. When cleaning mattresses, upholstered furniture, clothing and other off-the-floor objects, attach **Nozzle** directly to the **Hose**.



Going over curtains, drapes: Attach **Wand** to **Hose**. For heavy drapes, attach **6-Inch Nozzle** only directly to **Wand**. Delicate curtain material should be cleaned by adding the **Slide-On Brush**. **Brush** prevents delicate material from being drawn into the **Nozzle**.

Use the Round Brush for Easy Dusting

Do all your general dusting with the **Round Brush**. Use on highly polished furniture, the most delicate cloth lampshades, or any surface where dust accumulates.

To use **Brush**: Assemble **Filter Queen** for cleaning with other Attachments.



For general room dusting: Attach brush directly to Hose. Clean with gentle short strokes; do not press down hard as this will seal the opening and cut off your cleaning power. Use on tables, window sills, ledges, lampshades, statuary, woodwork, books, bookshelves, ashtrays, drawers, radio and TV grills, etc.

To dust moldings, door jambs, etc: Use **Wand** and the **Round Brush**.

To Clean Brush: Run open end of **Hose** over bristles of **Brush**. (You will find this method convenient for keeping all kinds of brushes clean.) If you have been dusting grimy or very sooty surfaces, remove

bristle assembly from rubber socket, wash in warm soapy water; let dry before replacing.

Use the Crevice Tool for Hard-to-Reach Places

Assemble **Filter Queen** for cleaning with other attachments.

Use **Crevice Tool** for removing dust and dirt behind cushions in upholstered furniture; mattress tufts and bindings; bed springs; radiators; and any place where other attachments cannot reach.



BRUSHES-CREVICE TOOL



LIMITED WARRANTY

HMI Industries Inc. warrants the Filter Queen Home Sanitation System unit and motor to be free of defects in materials and workmanship for five years from the date of purchase and all accessories, (includes hose, attachments and power nozzle) for two years. This warranty does not cover: **1-** use of the Filter Queen for commercial, institutional, professional, rental or other non household purposes; **2-** Ordinary wear items including brushes, belts, seals, floor polishing felt pad and filters; **3-** Damage occurring through misuse or negligence; **4-** Damage caused by use on a current or voltage other than stamped on the nameplate; **5-** Damage resulting from service work performed by other than HMI Industries Inc. or its authorized distributors; **6-** Cost of transportation, pick-up, delivery, house or service calls.

HMI Industries Inc. will repair or replace any defect or defective part under this warranty provided the Filter Queen or the defective part is returned, transportation prepaid, with proof of purchase date, to the authorized Distributor from whom it was purchased or to Quality Assurance Department, HMI Industries Inc., 3631 Perkins Ave, Cleveland, Ohio 44114, or, with written authorization from HMI Industries Inc., to any person authorized to perform warranty service. Information regarding other persons authorized to perform warranty service can be obtained by writing to the Customer Relations Department, HMI Industries Inc., at the above address or by calling 1-800-344-1840. If the Filter Queen or part is found on inspection to be defective in material or workmanship, it will be repaired or replaced at the option of HMI Industries Inc. and returned to the sender, freight or postage collect. No reimbursement will be made for replacement of defective parts or service performed during the warranty period if done by anyone other than the authorized Distributor from whom the Filter Queen was purchased or by HMI Industries Inc., without having obtained written authorization from HMI Industries Inc.

This warranty is null and void and of no effect unless Filter Queen was purchased from an authorized Distributor; and the manufacturer's serial number for the Filter Queen has not been changed, defaced or removed.

Any repair or replacement of a defect or defective part under this warranty will be warranted for one year or until the end of the original warranty period, whichever is longer.

There is no express warranty applicable to your Filter Queen. Implied warranties, including warranties or merchantability and fitness for a particular purpose, are limited in duration to the period of the time during which the express warranty given herein is in effect. All consequential or other damages resulting from breach of this warranty are excluded from coverage under this warranty.

Some states do not allow limitations on how long an implied warranty lasts, or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

Neither HMI Industries Inc., nor its Distributors, assumes or authorizes anyone to assume for any of them any additional liability.

This warranty gives you specific legal rights and you may have other rights which vary from state to state.

HMI Industries Inc. agrees to replace the Filter Queen canister motor at any time after expiration of the original warranty period, subject to the terms and conditions set forth below:

1. The Filter Queen must be in the possession of the original owner, must have been used only for household purposes, and must be accompanied by proof of purchase. This service policy does not apply to any Filter Queen used for commercial, institutional, professional, rental or other non-household uses.
2. The Filter Queen must be returned, transportation prepaid, to the authorized Filter Queen Distributor from whom it was purchased, or to the Quality Assurance Department, HMI Industries Inc., 3631 Perkins Avenue, Cleveland, Ohio 44114. The owner must pay return transportation charges.
3. The maximum charge for replacing the motor of the Filter Queen canister will be \$59.50, which will include the cost of all parts and labor necessary to replace the Filter Queen canister motor. A charge will be made at the then-current prices for any parts missing from the Filter Queen at the time it is delivered for motor replacement, if such parts are necessary to restore the Filter Queen to correct operating condition and for any parts needed or requested other than the motor of the canister.
4. If there is a defect in material or workmanship in the motor, the Filter Queen canister motor will be replaced again at no charge, provided the Filter Queen is returned within two years of the prior rebuilding to HMI Industries Inc. or the authorized Distributor who performed the rebuilding, transportation prepaid. Proof of the prior motor replacement must accompany the Filter Queen.
5. If the Filter Queen and/or attachments are destroyed or damaged by fire while in the home of the original owner within three years from the date of original purchase, HMI Industries Inc. will replace, repair or rebuild the Filter Queen for the original owner so as to place the machine in correct operating condition. To take advantage of this fire rebuilding policy, the fire-damaged remains of the Filter Queen must be sent within 90 days of the fire, transportation prepaid, to HMI Industries Inc., 3631 Perkins Ave., Cleveland, Ohio 44114 along with a check in the amount of \$100.00 and an affidavit that the Filter Queen was damaged or destroyed by fire while in the home of the original owner.
6. This service agreement is void and inapplicable unless all of the following conditions are met:
 - a) The Filter Queen was purchased from an authorized Distributor;
 - b) Proof of Purchase must accompany the unit;
 - c) The manufacturer's serial number for the Filter Queen has not been changed, defaced or removed;
 - d) Damage to the power plant did not occur by reason of misuse, negligence, use on a current or voltage other than that stamped on the nameplate or by use of Other than genuine Filter Queen cones.

HMI Industries Inc. (the "Manufacturer") warrants that your Filter Queen canister, Pow-R-Nozzle and related accessories have been thoroughly inspected and have met all factory quality requirements. Upon purchase, a Warranty Registration Card is automatically returned to the Manufacturer. When received, the Manufacturer warrants your Filter Queen equipment, subject to the detailed limited warranties contained elsewhere in this Manual, as follows:

- A.** A basic warranty covers the Filter Queen unit and motor for a period of 5 years and all accessories for a period of 2 years from the date of purchase,
- B.** Extended Motor Protection covering the unit motor replacement at a fixed price for the lifetime of the original owner;
- C.** Loss by fire protection should the Filter Queen and/or its attachments be damaged by fire while in the home of the original owner for a period of three (3) years.

Should you have any questions about your Filter Queen, or need the name of the Authorized Distributor nearest you, call toll free to our Customer Service Representatives at:

1-800-344-1840

or see back cover for your Local Authorized Filter Queen Distributor.



Use of imitation Filter Cones can cause serious damage to your Filter Queen System! Genuine Filter Queen Cones are imprinted "Genuine Product of HMI Industries Inc." Be sure this trademark is on every Filter Cone you use in your Filter Queen.





Filter Queen
FRONT

OUTLET FOR POWER NOZZLE MODELS 96 AND MP
BORTIE POUR BALAIS MOTEUR MODELES 96 ET MP

Majestic

TRIPLE CR

HMI

INDUSTRIES INC.

3631 PERKINS AVENUE
CLEVELAND, OHIO 44114
216-432-1990