

KIDS FUN & GLITTER

SHOE SIZE	WIDTH	HEIGHT	SIZE NAME
29	23,5	29,5	NORMAL
30	24,5	30,5	NORMAL
31	25,5	31	NORMAL
32	26,5	32	NORMAL
33	27,5	33	NORMAL
34	28,5	34,5	NORMAL
35	29,5	36	NORMAL
35	28	39	SLIM-TALL
36	30,5	37,5	NORMAL
36	29	41	SLIM-TALL
37	31,5	39	NORMAL
37	30	44	SLIM-TALL
38	32	41	NORMAL
38	31	46	SLIM-TALL
39	33	43	NORMAL
39	32	47	SLIM-TALL
40	33	48	SLIM-TALL
41	34	49	SLIM-TALL

SOFT CHAP COMFORT

	SIZE		WIDTH	HEIGHT
KIDS	KIDS-X-SMALL	K/XS	28 - 32	32
	KIDS-SMALL	K/S	29 - 33	34
	KIDS-MEDIUM	K/M	30 - 34	36
	KIDS-LARGE	K/L	31 - 35	38
	KIDS-X-LARGE	K/XL	32 - 36	40
	X-SMALL-TALL	XS/T	32 - 36	43
SMALL	SMALL	S	33 - 37	42
	SMALL-WIDE	S/W	35 - 39	41
	SMALL-TALL	S/T	33 - 37	45
	SMALL-X-TALL	S/XT	33 - 37	47
MEDIUM	MEDIUM	M	34 - 38	44
	MEDIUM-WIDE	M/W	36 - 40	43
	MEDIUM-TALL	M/T	34 - 38	47
	MEDIUM-X-TALL	M/XT	34 - 38	49
LARGE	LARGE	L	35 - 39	46
	LARGE-WIDE	L/W	37 - 41	45
	LARGE-TALL	L/T	35 - 39	49
	LARGE-X-TALL	L/XT	35 - 39	51
X-LARGE	X-LARGE	XL	36 - 40	48
	X-LARGE-WIDE	XL/W	38 - 42	47
	X-LARGE-TALL	XL/T	38 - 40	51

*Please check our measurement guide, if necessary.