



- + Size: 4-5/8" x 3-5/8" x 2-1/8" (1590BB enclosure)
- + Top Mounted Jacks
- + True Bypass (Soft switch with relay) + Tap Tempo Switch
- + Power & Polarity: 9V DC, center negative (standard).
Power supply not included. Pedal does not have a Battery slot.




Time Lapse Product Manual

O/I:
Use this switch to activate the pedal.

TAP:
The tap tempo switch uses the space between your last two tap to override the time knob with your desired tempo.

MIX:
This knob adds the desired amount of wet signal to your dry analog signal.

CHARACTER, TIME & FEEDBACK:
Use the chart below to determine the action of each knob.



MODE	DESCRIPTION	KNOBS			TAP SW
		CHARACTER	TIME	FEEDBACK	
DELAY	Standard 1/4 Note Delay	Tone Of Repeats	Delay Time	# Repeats	Tap Tempo
DOTTED 8TH	Dotted 8th Note Delay	^	^	^	^
TAPE	Tonal Degrade + Wobble	Depth of modulation	^	^	^
DOTTED 8TH TAPE	Same as Above + Dotted 8th	^	^	^	^
REVERSE	Reverse Delay	Tone Of Repeats	^	^	Max Feedback
INERTIA	Cascading Octave Up + Warped Speed	^	^	^	^
REACTOR	Arpeggiated Repeats (Octave Up, 5th, Unison)	2nd Repeat Octave/5th	^	^	2nd Repeat Octave
HOLD	Hold Drone Sound & Play Dry Signal Overtop	/	Release Time	4 Pole Filter	Hold

NOTE: Light does not blink below 200ms

WARNING: DO NOT EXCEED 9V DC.

Our four-year manufacturer warranty begins at the purchase date marked inside each enclosure. After four years the warranty has expired but you may still contact Thimble Wasp Effects for repair services and/or advice.

To begin a warranty repair order contact info@thimblewasp.com. Each pedal is subject to a basic wear and tear inspection by Thimble Wasp Effects to determine if the pedal circuitry has been altered, if the purchase date has been altered, or if the pedal has been abused beyond reasonable care. You should reference our "Reasonable Care of Your Pedals" blogpost for more information. The honoring of your warranty is subject to the opinion of the Thimble Wasp Effects warranty inspector.