

[Customer Service](#) [Watch Instructions & Manuals](#)

## *SECONDARY NAVIGATION*

# CUSTOMER SERVICE

[Check Order Status](#) [Shipping Information](#) [Returns Information](#) [Instruction manuals](#) [Warranty & Repair](#) [Frequently Asked Questions](#) [Promotional Details](#)

## HOW CAN WE HELP?

For any questions or support [click here](#)

# INSTRUCTION MANUALS

## CARE AND PRECAUTION

Each Teslar watch is designed and manufactured to exceed the highest of standards. To ensure optimal performance and longevity from your timepiece, please review the simple guidelines for care and precautions of your Teslar watch.

### CARE

Your watch should be cleaned with soft cloth and water only. Do not submerge your watch. Your timepiece should be rinsed clean and dried with a soft cloth after any saltwater use. To maintain the “new look” of metal bracelets, we recommend periodic cleaning of the bracelet.

Dip a soft brush in warm soapy water and gently rub bracelet clean. We advise having your timepiece serviced every 24 months to ensure long use and trouble-free operation.

### PRECAUTIONS

Your timepiece is a complex integration of parts and components brought together by skilled craftsmen.


There are certain actions or environmental situations that may damage or impede your timepiece’s ability to perform optimally.

It is important to avoid the following conditions: extreme heat or cold, as well as prolonged periods of exposure to direct sunlight, exposure to extreme heat or cold, as well as prolonged periods of exposure to direct sunlight, exposure to wet conditions that exceed your timepiece’s water rating.

Never operate any of the function buttons or crown when timepiece is in contact with water.

Your timepiece should not be affected by magnetic fields generated by household items such as televisions and stereos, but avoidance of other strong electric fields static electricity, which may interrupt mechanism, is suggested. It is also important to avoid extreme shock or impact.


## QUARTZ WATCH



### SETTING THE TIME

- Pull out the crown to position 2, turn it until the desired time is reached, push it back to position 1.

## QUARTZ CHRONOGRAPH WATCH



### SETTING THE TIME

- Pull out the crown to position 3, turn it until the desired time is reached (please note that at every passing of midnight the date changes), return the crown to position 1.
- To set the hour hand only (i.e., time-zone change), pull out the crown to position 2 and turn it until the correct time is displayed.

### **CORRECTING THE DATE**

- Pull out the crown to position 2 and rotate it: at every passing of midnight the date will change. Once the correct date has appeared, return the crown to position 1.
- Note: do not leave the crown in position 2 longer than 20 minutes (time could be lost).

### **ADJUSTING THE CHRONOGRAPH HANDS TO ZERO POSITION**

- Pull out the crown to position III (all three chronograph hands are in their correct or incorrect zero position).
- Keep pusher 2 and 1 depressed simultaneously for at least 2 seconds (the center stop-second rotates by 360° - corrective mode is activated).
- Press pusher 2 to single step the center stop second hand. Press and hold pusher 2 to advance the center stop-second hand quickly. Press pusher 1 to advance the next hand.
- Press pusher 2 to single step the hour counter hand. Press and hold pusher 2 to advance the hour counter hand quickly. Press pusher 1 to advance to the next hand.
- Press pusher 2 to single step the minute counter hand. Press and hold pusher 2 to advance the minute counter hand quickly.
- Return the crown to position I.

### **USING THE CHRONOGRAPH**

Before each time measurement operation, make sure that the chronograph counters are set to zero.

To return the 30 minutes counter to a zero setting, pull out the crown to position 2 and press pushbutton B. To restore the 60 seconds counter to a zero setting, pull out the crown to position 3 and press push-button A; to set the 1/10 second counter to zero, press push-button B (crown in position 3). Note: for a quick correction, press the pushbuttons mentioned. Return the crown to position 1.

#### **1. TIMING MODE**

- Crown in position 1.
- Start: press push-button A to start timing.

- Stop: press push-button A to stop timing and read the elapsed time. By pressing push-button A it is possible to start and stop timing repeatedly: the accumulated measured time is shown.
- Reset: press push-button B to set the counters to zero.

## 2. INTERMEDIATE TIMING MODE

- Crown in position 1.
- Start: press push-button A to start timing.
- Reading the intermediate time: press push-button B to stop timing and read the intermediate time.
- Press push-button B once more to restart timing and catch up the time elapsed during the interruption.
- By pressing push-button B again, further intervals or intermediate times can be displayed.
- Stop: press push-button A to stop timing. Final time is displayed.
- Reset: press push-button B to set the counters to zero.

For any questions: [info@teslarwatches.com](mailto:info@teslarwatches.com)

To view or print our warranty and instructions manual, please [click here](#).