



# RIGID CORE GLUE-DOWN FLOORING CARE & MAINTENANCE

---

## INTRODUCTION

Rigid Core Glue-down Flooring is known for its durability, water resistance, and easy installation. This guide aims to provide you with essential care and maintenance instructions to protect your investment.

## GENERAL CLEANING GUIDELINES

### Daily Cleaning

- Sweep or vacuum regularly to remove loose dirt and debris.
- Use a damp mop for general cleaning.
- Follow a pH-neutral cleaner recommended by the manufacturer.
- Clean the floor with a well-wrung damp mop and a mild cleaning solution.
- Avoid excessive water; wipe up any excess liquid promptly.

### Avoid Harsh Chemicals

- Avoid using abrasive cleaners, wax, or polish.
- Do not use harsh chemicals that may damage the flooring surface.

## PREVENTIVE MAINTENANCE

### Furniture Pads

- Use furniture pads under the legs of heavy furniture to prevent scratching.
- Lift furniture when moving instead of dragging.

### Mats and Rugs

- Place mats or rugs at entry points to trap dirt and prevent abrasion.
- Use rugs with non-staining backings.

### Avoid High Heels and Sharp Objects

- Avoid walking on the floor with high-heeled shoes.
- Keep sharp objects, such as pet claws and high-heeled shoes, in good condition to prevent damage.

## SPECIAL CARE INSTRUCTIONS

### Rigid Core Glue-down Flooring in Wet Areas

- Ensure proper installation in wet areas like bathrooms and kitchens.
- Clean and dry the floor promptly if water is spilled.

### Sunlight Exposure

- Use window coverings to minimize direct sunlight exposure.
- Rearrange furniture periodically to ensure even exposure.





# RIGID CORE GLUE-DOWN FLOORING CARE & MAINTENANCE

---

## Avoiding Excessive Moisture

- Use a humidifier in dry conditions to prevent excessive contraction.
- Wipe up any standing water promptly.

## REPAIR & RESTORATION

### Repairing Scratches

- Use a touch-up kit for minor scratches.
- Consult the manufacturer for specific repair products.

### Professional Restoration

- If significant damage occurs, consult a professional for restoration.
- Follow the manufacturer's recommendations for professional services.

## ADDITIONAL TIPS

### Regular Inspections

- Conduct regular inspections for any signs of damage or wear.
- Address issues promptly to prevent further damage.

### Temperature and Humidity Control

- Maintain a stable indoor climate to prevent expansion and contraction.
- Follow the recommended temperature and humidity levels.