


Montessori Shelves Assembly Instructions

Thank you for purchasing Montessori Shelves from The Montessori Room! If at any point you have questions or concerns, please contact us:

contact@themontessoriroom.com
866-901-4696



Included pieces:

- | | |
|---|-----------------|
| A. 1 and 2 Shelf Top and Bottom (interchangeable) | C. Middle Shelf |
| B. 1 and 2 Shelf Sides (interchangeable) | D. Back |

Please note:

- There are 3 height options for the middle shelf. You can decide on the shelf height at the end of assembly and easily change it at any time by changing the height of the shelf pins.

WARNING: Never allow children to climb the shelves.
Make sure it seems safe and is sturdy and contact us if you have any concerns.

ASSEMBLY STEPS:

1. Take A1 and stand it up against the long, thin flat side.
2. Take B1 and slide it into A1. Ensure shelf pin holes are on the inside.
3. Take A2 and slide it into the other side of B1.
4. Slide B2 into the other side of A1 and A2.
5. Screw back piece (D) onto the back of the shelf, using the provided screws. Make sure that the pre-drilled holes line up.
6. Insert the shelf pins (provided) into the holes on the inside of B1 and B2. Choose from one of three possible height options.
7. Place the middle shelf (C) onto the shelf pins.