ATTENTION: Your Rico ceiling fan has been manufactured with utmost care and under strict quality control. If, for any reason, you are not satisfied, please contact your local dealer or the Rico Customer Relations Department for immediate action on your query / problem at:

Customer Relations Department

Rico Appliances Pvt. Ltd. Sapphire Building, 8th floor,

Sapphire Building, 8th 1100r,

SV Road, Khar (W),

Mumbai, Maharashtra-400 052, India

Tel.: (91-22) 2600 2926

Website: www.rico.in, Email:service@rico.in

Please ensure that the Warranty Card is filled in by the dealer at the time of purchase. Detach the card below and mail it within 7 days of purchase to Rico.

POST CARD




Rico Appliances Pvt. Ltd.

Sapphire Building, 8th Floor, S.V. Road, Khar (West) Mumbai, Maharashtra - 400 052, India.


















INSTRUCTION MANUAL WITH WARRANTY CARD

Dear Customer

Thank you for selecting Rico.

You have just brought yourself one of the finest home product in the form of Rico Ceiling Fan.

Your Rico Ceiling Fan has been manufactured for you under the most stringent quality procedures.

You are assured of the best quality, performance and after sales service. If, however, for any reason, you feel something is lacking, we are always there at your service.

A list of Rico service centre's is also enclosed separately. If you require any further assistance, please do not hesitate to contact us, for immediate action on your query/problem, at

Customer Relations Department

Rico Appliances Pvt. Ltd.

Sapphire Building, 8th floor, SV Road, Khar (W), Mumbai, Maharashtra-400 052, India Tel.: (91-22) 2600 2926
Website: www.rico.in, Email: service@rico.in

Thank you once again for buying Rico

C. Thakur

Chairman,

Rico APPLIANCES PVT. LTD.

24 Months Warranty



(To be retained by the purchaser)

Important: Before mailing the warranty card, please read all the terms and conditions of the warranty

Rico Produ	et:CEILING FAN	J"
Serial No.	D	ate of Purchase
Dealer's N	ame & Address :	
and mail to	Rico within 7 days o	d, cut along the dotted line, of purchase
		J"
Serial No.	D	ate of Purchase
Dealer's N	ame & Address :	
Address:_		
City:	Pin Code:	State/Country:
Email:	Tel/Mobile:	
(Please make	sure your dealer comple	tes this card at the time of purch

24 Months Warranty

(This portion is to be mailed to Rico) You can also register warranty card online at www.rico.in



HOME APPLIANCES WARRANTY CARD

WARRANTY CONDITIONS & SERVICE PROCEDURE

Please preserve this warranty card the cash memo and ensure that it is duly stamped (with the date stamped) and signed by the dealer. A warranty card or cash memo which is not stamped and signed by the dealer will be treated as invalid.

Kindly ensure you post the half portion of the warranty card, to Rico Head office or update your details on our website www.rico.in.

Conditions of the Warranty:-

Your Rico product is warranted against manufacturing defects for 24 months from the date of purchase. The product is guaranteed against manufacturing defects only. This product is designed for domestic use only.

This warranty does not apply to

- Normal Wear and tear of parts or surface coating
- Faults which may be due to wrong usage, faulty handling, damage in transit, usage of spurious parts, neglect or accident are not covered by this warranty
- Damages resulting from accidents, mishandling or negligence on the part of the customer and fluctuation in supply voltage.
- Surface Coating, body aesthetics, plastic parts, neon lamps, bakelite parts, rubber/nylon parts, push buttons & bulb.
- Damages resulting due to usage of power supply other than specified 220/230 Volts, AC, 50 Hz. eg: inverters generators etc.
- For humming noise generated due to usage of electronic fan regulators of any make.

Should the your Rico product become un-operational during the warranty period, Kindly contact your nearest authorized Rico Dealer / Service Centre. (List is also available www.rico.in)

Subject to the above - The defective part will be repaired / replaced free of charge for labour or materials, at our discretion & option, provide that:

- The unit is returned at your cost to our Authorized Service Centre along with the stamped and signed Cash Memo and Warranty Card.
- The unit is installed, used and maintained strictly in accordance with the instructions provided.
- The unit is not opened or tampered with by anyone except our Authorized Service Centre or technician.

CONSEQUENTIAL DAMAGE

Liability for consequential loss or damages is neither accepted nor is it implied. The warranty extended herein is in lieu of all implied conditions and warranties under the law and is confined to the repair or replacement of defective parts and does not cover any consequential or resulting liability, damage or loss. The warranty in no case shall extend to payment of any monetary consideration whatsoever or the replacement or return of the products as whole, liability for consequential loss or damage is neither accepted nor is implied.

4. SERVICE AND REPAIRS


 $Please\ get\ the\ product\ repaired\ only\ from\ our\ nearest\ Office, Dealer\ or\ Customer\ service\ centre.$

This warranty is confined to the repair or replacement of defective parts. Any expenses incurred on collecting and returning the product to the customer and/or on the service personnel who will visit the customer, such as to and fro conveyance, incidentals etc., shall be borne by the customer.

Please note that this warranty is issued subject to the jurisdiction of the competent courts in Mumbai INDIA only.

To avoid unnecessary repairs, please study the instruction manual carefully before operation.

ASSEMBLY INSTRUCTIONS





IMPORTANT:

- The diagrams of the fan are just the general representation of a ceiling fan.
- Read the instruction carefully. Open the packing and arrange the fan parts as per the numbers marked on diagrams.
- Assemble & install fan as per the assembly, wiring diagrams and written instructions.
- Check the assembled fan, ensure proper installation before switching ON fan.

ASSEMBLY & INSTALLATION: FAN

- A. Place the motor on the thermocole.
- B. Pass the connection wires through slit hole at the bottom end of down rod (3) and remove them from the top end of down rod.
- C. Insert the bottom end of down rod (3) with slits on spindle (6) and insert bolt (7). Place the spring washer (8) and fully tighten nut (9) insert the split pin (10) in the small hole on the bolt end and open the ends, so that it does not fall off. The assembly of bolt (7), spring washer (8) nut (9) split pin (10) is separately packed with hanger assembly (11).
- D. Connect the wires to terminal block.
- E. Insert the condenser bottom cover (4) from top end of down rod and place it in position. Ensure minimum 3 to 4 mm gap between condenser cover (4) and motor body and tighten the screw which is provided on condenser cover.
- F. Insert canopy (5) from top end of the down rod (3).
- G. Fix the blade (1) with the screws (2) already provided on motor body H. Remove the split pin (15), nut (14), spring washer (13), and bolt (12) at the bottom end of hanger assembly (11).
- I. Place hanger assembly (11) in ceiling hook in such way that rubber reel (16) rests on the ceiling hook.

Rico

- J. Insert the top end of down rod (3) between the steel clamps of hanger assembly (11). Match the holes with holes in down rod. Insert bolt (12). Place spring washer (13), and fully tighten nut (14). Insert the split pin (15) in the small hole on bolt end and open the ends. So that it does not fall of.
- K. Lift the canopy to cover hanger assembly and tighten the screw (5a) provided on canopy.
- L. Each Fan is provided with a speed regulator designed to give uniform speed regulation at each step. The regulator has 5 running positions and one off.

