

COMMAND BUTTONS & LED LIGHT INDICATORS

1. Command buttons





system & bluetooth

Start	(1)	tight press 0.2s
Shutdown		tight press 0.2s
Switch language of sound notifications - (English-French)		long press
Battery level - (sound notification % of battery)		2x short press
Turn device in pairing mode		long press
Empty Bluetooth paired devices		long press

surrounding management

Activate / deactivate ANC mode - «Active noise cancelling mode»

Noise Reduction

Maximum noise-reduction - Increases ANC to maximum level

Customized noise-reduction - Slowly increases ANC level

Aware

Maximum transparency - Decreases ANC to minimum level

Customized transparency - Slowly decreases ANC level

Aware +

Enter / exit "Face-to-face conversation" mode - Only if no active call ongoing

Push ↑ short press

press down ↓ and fast release

press down and maintain ↓

lift ↑ and fast release


lift and maintain ↑


telephony

Single Call		
Answer call - When call is incoming	>	short press
Reject call - When call is incoming	>	long press
Hang up - When call is active	>	long press
Twin call		
Reject twin call - When call is active & twin call is incoming	>	long press
Accept twin call & end active call - When call is active & twin call is incoming		long press
Accept twin call & hold active call - When call is active & twin call is incoming	>	short press
Swap call - When several calls are active	•	long press
Hang up current call - When several calls are active	>	long press
Mute / Hold		
Mute / unmute without the boom-microphone - When call is active		short press
Mute / unmute with the boom-microphone - When call is active		short press
Call on hold - When call is active		short press

media manageme	ent
Music	
Play / pause music	short pres
Next track	long press
Previous track	long press
Volume	
Volume increases by 1 step	short pres
Volume decreases by 1 step	short pres
Vocal commands	
Activate Apple Siri or Google Assistant	long press

2. LED light notifications







power led light

- blinking	SYSTEM: device is booting
steady	BATTERY : strong battery - Device ON
· slow blinking	BATTERY : charging complete - Device OFF & USB-C plugged
steady	BATTERY : moderate battery < 35% - Device ON
· slow blinking	BATTERY : charging ongoing - Device OFF & USB-C plugged
steady	BATTERY: low battery < 10%, needs charging - Device ON
- blinking	SYSTEM : device shutdown
-—- is blinking (≃3 minutes)	BLUETOOTH : device in pairing mode
steady (~3 seconds)	BLUETOOTH : pairing success
steady	UPDATE MODE: update mode active - Waiting for action from the user
- blinking	UPDATE MODE : update is being processed - Shall not be interrupted
steady (1 second)	SYSTEM: USB-C plugged - Event

ear pads led lights

steady on both pads
 ⇒ steady on both pads
 ⇒ steady on both pads
 ⇒ blinking on both pads
 ⇒ 1 sec & device turns off
 ♠ SAFETY INTERLOCK: right cussion not recognized - Refer to troubleshooting
 ♣ SAFETY INTERLOCK: left cussion not recognized - Refer to troubleshooting

boom-microphone led light

steady TELEPHONY: busy light - Call ongoing or ready for a call