

AmazingAir™

USER MANUAL

AD3000E / air purifier



AmazingAir™

amazingair.eu

AD3000E / MNL / EU / 072922R6
SKU 90AZ01AP01





THANK YOU

Congratulations on purchasing the AmazingAir™ AD3000E Professional Air Purifier and your commitment to controlling the quality of your indoor air.

With the AmazingAir AD3000E, we provide UltraHEPA® filtration to purify the air and remove allergens. In addition, the AmazingAir AD3000E is equipped with an activated carbon filter to remove odor and VOCs. Get ready to experience cleaner air!

PLEASE NOTE: It is crucial that you read and follow all the instructions and safety warnings in this manual for optimal performance of your air purifier and your health and safety.



TABLE OF CONTENTS

SAFETY INSTRUCTIONS	2
PRODUCT BENEFITS	3
KNOWING YOUR AMAZINGAIR PROFESSIONAL AIR PURIFIER	4
Main Parts	4
PROPER USAGE	5
OPERATING YOUR AMAZINGAIR PROFESSIONAL AIR PURIFIER	6
Control Panel	6
Air Quality Monitor	7
MAINTENANCE	9
Maintaining the AmazingAir Professional Air Purifier	9
FAQ & TROUBLESHOOTING	9
FILTER WARRANTY	11

SAFETY INSTRUCTIONS

WARNING: RISK OF ELECTRIC SHOCK

Safety precautions should always be used when operating this or any electrical appliance. Decrease the risk of electrocution, electric shock, injury or fire by reading and following all the warnings below.

Use this product only as described in this AmazingAir professional air purifier owner's guide. To reduce the risk of electric shock, do not attempt to service the product in any way other than in the manner described in the "Maintenance" section of this guide.

- ⊙ Read all instructions before operating the AmazingAir professional air purifier.
- ⊙ This product operates at 220 to 240 Volt AC, 50 hz only.
- ⊙ Do not run the power cord under carpets or cover with throw rugs.
- ⊙ Do not operate the product in a greasy environment such as in the kitchen. This product is not intended to filter oil or grease from air.
- ⊙ Do not use the AmazingAir professional air purifier in bathrooms, near sinks or other wet & humid environments, near fireplaces or in areas where flammable or combustible vapors or products may exist.
- ⊙ Always unplug the power cord from the electrical outlet when the purifier is not in use, before cleaning, inserting or removing parts or before moving to another location.
- ⊙ Never run the AmazingAir professional air purifier unless it is fully assembled.
- ⊙ Always turn off all controls before unplugging the AmazingAir professional air purifier from outlet.
- ⊙ Attempting to service the AmazingAir professional air purifier in any way not described in this owner's guide will void the warranty and could cause serious personal injury to the user and/or result in considerable damage to the unit.
- ⊙ Do not place the cord near a heated surface.
- ⊙ Never operate the AmazingAir professional air purifier if the plug or cord is damaged or appears damaged. Only qualified service personnel should replace a damaged power cord.
- ⊙ Never use the power cord to pick up, carry, drag, pull or lift the AmazingAir professional air purifier. Do not pull the cord against or around sharp corners and edges. This could result in injury to the user or damage to the cord.
- ⊙ Always remove the plug from its power outlet by holding onto the plug itself and pulling gently. Never pull on the cord itself to unplug it from its power outlet.
- ⊙ Use care when operating the AmazingAir professional air purifier by keeping all foreign objects, fingers and other body parts, hair, loose clothing and jewelry away from openings.
- ⊙ Never touch the AmazingAir professional air purifier or its plug when your hands are wet.
- ⊙ The AmazingAir professional air purifier is an electrical appliance. Adult supervision is required when operating around children.
- ⊙ This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- ⊙ If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

PRODUCT BENEFITS

THE REVOLUTIONARY AMAZINGAIR PROFESSIONAL AIR PURIFIER CLEANS AIR WITH ULTRAHEPA FILTRATION.

The AmazingAir professional air purifier boasts many great features:


- ⊙ UltraHEPA filter removes microscopic particles from the air.
- ⊙ High quality carbon filter removes VOCs (Volatile Organic Compounds) and controls odors.
- ⊙ Effectively removes smoke, pollen, dust, animal dander, dust mites from the air.
- ⊙ Powerful and quiet fan has 4 speed settings so you can select the desired cleaning level.
- ⊙ Air Quality Monitor shows current air quality.
- ⊙ Auto mode automatically adjusts fan speed depending on air quality.
- ⊙ A 24 hour timer to set the time of operation, from 1 hour up to 24 hours.
- ⊙ Built-in ionizer revitalizes air.
- ⊙ Night mode dims the control panel light when you sleep.
- ⊙ Clean filter indicator light.
- ⊙ Low power consumption-energy efficient, Energy Star approved.



KNOWING THE AMAZINGAIR AD3000E PROFESSIONAL AIR PURIFIER

MAIN PARTS


1. Front Cover
2. Pre-Filter (Black Foam attached to Carbon filter)
3. Carbon/Gas Trap/VOC Filter
4. UltraHEPA Filter
5. Air-Outlet
6. Touch Control Panel
7. Air Quality Sensor Cover
8. Air Quality Sensor
9. Air Quality Monitor: The display will change color depending on air quality.



PROPER USAGE

Please note: make sure the UltraHEPA & Carbon/Gas Trap/VOC filters are properly installed before use.


1. Keep both sides of the unit more than 1 foot away from a wall.
2. Do not blow air from a fan or air conditioner directly into the air purifier.
3. Do not place the unit where the air inlet or outlet grill could come in contact with curtains or drapery.
4. Place the unit close to the source of air pollution to improve indoor air quality effectively.



OPERATING THE AMAZINGAIR AD3000E PROFESSIONAL AIR PURIFIER

Before first use, remove filters and remove plastic bag from filters, then reinstall filters. Then reinstall front cover.

Plug the unit into an electrical outlet. The unit will be ready to run. Read the following directions to select desired settings.



Air Quality Monitor

AIR QUALITY MONITOR

Air Monitor

The AmazingAir comes with an Air Quality Monitor that continuously monitors the quality of the air in the room. The LED light located on the front will light up according to the air quality. The Air Quality Monitor is able to show 3 air quality levels.

BLUE = Good air quality / **ORANGE** = Fair air quality / **RED** = Poor air quality


You can choose to set the AmazingAir to "Auto". This will enable the AmazingAir to adjust the Fan speed according to the Air Quality. In **Auto** mode, the fan speed will be adjusted as follows:

Good Air Quality = Low fan speed

Fair Air Quality = Medium fan speed

Poor Air Quality = High and Boost fan speed

CONTROL PANEL



1. Power Control

As soon as you press the power button , the AmazingAir will start in the **Auto** mode. As soon as the auto program has been activated it will start up in the high-speed mode, the sensor will start to detect the amount of particulate in the air. As the particles are detected, the AmazingAir will select the purification speed (fan speed) that is appropriate to the particulate contamination in the room.

In most cases we recommend that you leave the AmazingAir in the Auto mode, for other purification modes, see the next page.

OPERATING THE AMAZINGAIR AD3000E PROFESSIONAL AIR PURIFIER

2. Fan Speed Control

The AmazingAir has four different fan speed settings: Low, Medium, High, and Boost. Each mode has its own indicator light which lights up when the setting is chosen. The speed selected determines how rapidly you want to clean the air. The "**LOW**" and "**MEDIUM**" settings are great for everyday use. The "**HIGH**" setting is great for areas with more airborne contaminants (such as excessive smoke, pet dander, etc), or areas used frequently by allergy-sufferers. The "**BOOST**" setting is best used for shorter bursts of time when you want to rapidly purify the air.

3. Auto Mode

The AmazingAir is equipped with an air sensor to monitor the quality of your air. Simply press the **Auto** button to activate the air monitoring system. The monitor will test the air quality and automatically adjust the fan speed to remove the air contaminants. The front of the display is equipped with **LED lights** to notify you of the air quality. **RED** color is for poor, **ORANGE** for fair and **BLUE** for good quality air.

4. Dim Mode

If the LED lights are too bright, activate the "**Dim Mode**" to turn off the LED lights and the lighted display.

5. Timer Control

The AmazingAir air purifier can be programmed to turn off after a preset amount of time. Press the "**TIME**" button to program the timer. Each press will add one hour up to a total of 24 hours. Keeping the button pressed will automatically increase to 24 hours, 1 hour at a time.

6. ION Generator

Press the **ION** button to turn on the IONS. Press it again to turn the IONS off.

7. Clean Filter Indicator Light

The AmazingAir Clean Filter Indicator Light will turn on each time a filter needs to be replaced. To reset the filter indicator, **press the AUTO and DIM buttons together for 3 seconds**. The **CLEAN FILTER** light will flash 3 times and then turn off completely, indicating the unit has been reset.

8. 24-Hour Timer Display

Electrical Ratings

- 220 - 240 volt / 50 Hz
- Power consumption / 95 watts
- 12 month UltraHEPA® filter
- 6 month Carbon filter
- Model AD3000E

Replacement Filters

- UltraHEPA filter / ADF3001
- Carbon filter / ADF3002
- Pre-filter / ADF3003

MAINTENANCE

The AmazingAir professional air purifier is almost maintenance free! The high quality carbon/gas trap/VOC filter lasts up to 6 months and our UltraHEPA filter lasts up to 12 months, depending on use and environment conditions.


Before replacing the UltraHEPA or carbon/gas trap/VOC filter of your AmazingAir professional air purifier, turn off and unplug the unit from the electrical outlet and read all safety instructions and important warnings in this owner's manual.

REPLACING THE ULTRAHEPA & CARBON/GAS TRAP/VOC FILTERS

1. Make sure the unit is turned off and unplugged. With the front of the unit facing forward, pull the lid towards you at the upper end as shown and remove the front cover.
2. Remove the UltraHEPA and carbon/gas trap/VOC filters by lifting and pulling the tabs on both sides of the filters.
3. Insert new UltraHEPA and carbon/gas trap/VOC filters, then insert the bottom of the inlet grill first and then snap the upper part of the front cover back into position.
4. To close the front cover, first make sure the bottom hooks are properly in place before snapping it up to its upright and locked position.

CLEANING THE PRE-FILTER

1. Make sure the unit is turned off and unplugged. With the unit facing forward, pull the cover towards you at the upper end and remove the front cover.
2. Gently vacuum your Pre-Filter. You may do this monthly or as needed if there is more build-up.
3. After you've vacuumed your Pre-Filter, simply place the front cover back on your AmazingAir professional air purifier.



MAINTENANCE

CLEANING THE AIR QUALITY SENSOR

The AmazingAir is designed with an air quality sensor to track the quality of your air. Over time, the sensor can become dirty and may require cleaning. The main symptom of a dirty air quality sensor is the LED air quality monitor display that remains frozen on one light color. In order to clean it, you must use a vacuum cleaner to clear the sensor chamber.


1. Power off and unplug unit.
2. Locate and open the air quality sensor cover located on the side of the unit. (Fig. 1)
3. Use a vacuum cleaner hose to suction any dust or dirt that may have accumulated inside the monitor chamber. (Fig. 2)

SENSOR CLEANING MAINTENANCE

The lens of the air quality particle sensor may also need to be cleaned.

1. Power off and unplug unit.
2. Locate and open the air quality sensor cover located on the side of the unit. (Fig. 3)
3. Locate the lens of the air sensor located inside the air sensor. (Fig. 4)
4. Wet the one end of a cotton swab with water and wipe the lens to remove any debris. Then, dry the lens with the other end of the swab

Caution: Do not scratch the lens with a hard object.



FAQ & TROUBLESHOOTING

Before contacting our customer service department, please try the following solutions:

QUESTION	ANSWER
How often should I change the filters?	UltraHEPA - 12 months Carbon/Gas Trap/VOC - 6 months
Can I wash my filters?	It is important that you never wash your UltraHEPA or Carbon/VOC Filters. Doing so will damage your filters, making them unusable. Your Pre-Filter was designed to be reusable. Avoid washing your Pre-Filter as you do not want to introduce any moisture onto the filters. We recommend vacuuming your Pre-Filter monthly for best maintenance and to extend the life of your filters until the next filter change.
How long is the power cord?	The power cord is 6 feet long.

FAQ & TROUBLESHOOTING

Before contacting our customer service department, please try the following solutions:

QUESTION	ANSWER
How much electricity does the AmazingAir professional air purifier use?	The AmazingAir professional air purifier is highly energy-efficient, only consuming 11 watts on the low setting and 110 watts on the high setting. While utility costs vary across the country, the AmazingAir professional air purifier costs about \$30-40 per year to run on Auto-mode 24/7.
Why is the air sensor always red?	If you feel that the sensor is always running on red (always at a high speed) never goes back to blue, please try the following tests: 1. Turn your AmazingAir professional air purifier off, on the right side there should be a little panel door. This is the air sensor; open it. 2. Vacuum the air sensor following the air sensor test instructions on page 9. Test to see if this improves and there is a color change on the air quality monitor indicator light. If this did not help, please do the following to test your air sensor: 1. Move the AmazingAir professional air purifier into a small unused room like a closet or bathroom and make sure windows and doors are closed. Then turn the AmazingAir professional air purifier on the high-speed setting. 2. After you've done this, leave the unit running on Auto mode for 60 min. 3. Now check to see if the LED light has changed color 4. If the air sensor LED light did not change color, please contact customer service.
Why is the air sensor always blue?	The blue light indicates that the AmazingAir professional air purifier is maintaining healthy air quality. We recommend that you keep the unit in Auto mode as it will automatically adjust to the purification needs of the room. If you feel that the sensor is no longer working, please try the following tests: 1. Turn on the air purifier and let it run for two minutes. 2. Locate the air sensor on the left side of the air purifier. It's behind a small door. 3. Then, light up a match/candle and blow it out and make sure the smoke is directed towards the air sensor. You can also try to take an old pillow and fluff it next to the sensor. 4. After you've blown up the smoke near it, the light on your air purifier should turn orange/red within a minute or so. 5. If the air quality monitor LED light did not change color, please contact customer service.

FILTER WARRANTY

AMAZINGAIR VOC, HEPA AND PRE-FILTER LIMITED WARRANTY

AmazingAir particle filter (HEPA) and VOC (carbon) and Pre-filter is warranted to be free from defects in material and workmanship for 30 days from the original purchase date. The AmazingAir will replace a defective filter at no charge to you and cover any shipping charges. The limited warranty covers normal use only.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS PRODUCT, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD, AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THIS PERIOD.

Some states do not allow limitations on the duration of implied warranties, so the above limitation may not apply to you. While this warranty gives you specific legal rights, you may also have other rights which may vary from state to state.

Customer Service: +31 (0)24 202 21 95
whatsapp: +31 6 49 536 820

info@amazingair.eu

©2022 AirDoctor®, LLC, USA. All Rights Reserved.

AmazingAir™

AD3000E

AD3000E

AmazingAir™

AmazingAir™

12

13