
ASSEMBLY INSTRUCTIONS INSTRUCCIONES DE ENSAMBLE



Height: 70,3 in Alto: 178,7 cm Width: 27,6 in Ancho: 70,2 cm Depth: 11,8 in Fondo: 30 cm

LOT N°

BOOKCASE Biblioteca



IMPORTANT RECOMMENDATIONS

RECOMENDACIONES **IMPORTANTES**

Do not paint the cabinet.

No pintar el mueble.

The cabinet MUST be used exclusively indoors, do not expose to direct sun.

El mueble debe ser usado únicamente en interiores, no exponer al sol directo.

Clean metallic hardware with a dry cloth.

Limpiar los herrajes metálicos con un paño seco.

Do NOT overload the cabinet (see suggested loads). NO sobrecargar el mueble (ver las cargas sugeridas).

Do not hit or hammer the cabinet (just when indicated).

No golpear ni martillar el mueble (solo cuando se indique).

Clean with a slightly damp cloth, use gentle soaps.

Limpiar con un paño ligeramente húmedo, usar jabones suaves.

Do not drag, lift and move between two people.

No arrastre el mueble, levántelo entre dos personas.

Avoid direct contact with water, fire or exposure to heat sources.

Evite el contacto directo con el agua, el fuego o la exposición a fuentes de calor.





Never allow children to climb or manipulate the cabinet, furniture tip over can cause serious injuries or death.


Nunca permita que los niños escalen o manipulen el mueble, la caída de este puede provocar lesiones graves o la muerte.

INDEX ÍNDICE

Assembly Hardware 4	Herrajes para Armado	4
Assembly Parts 5	Piezas de Armado	5
Suggested Loads 6	Cargas Sugeridas	6
Assembly Recommendations 6	Recomendaciones de Ensamble	6
Assembly Steps 7-17	Pasos de Armado	-17
Warranty	Garantía ······	18

REQUIRED TOOLS*

HERRAMIENTAS NECESARIAS*



^{*}Not included, and not shown actual size.

^{*}No incluidas y no se muestran en tamaño real.

ASSEMBLY HARDWARE

HERRAJES PARA ARMADO

Please check that the hardware content is correct. If any item is missing, please call to our customer service line.

Compruebe que el contenido de los herrajes sea el correcto. En caso de que falte alguna pieza, por favor llame a nuestra línea de atención al cliente.









x36 Minifix Cams Minifix



x40 Cover Caps Tapa Adhesiva Minifix




x6 Nail-on Glide Deslizador Puntilla



Wall Anchor + Drvwall Screw Chazo Mariposa + Tornillo de Ensamble

ASSEMBLY PARTS


PIEZAS DE ARMADO




A - x1	G - x1	M - x1
B - x1	H - x1	N - x2
C - x1	I - x1	O - x1
D - x1	J - x3	P - x1
E - x1	K - x2	
F - x1	L - x1	

MAX SUGGESTED LOADS

CARGAS MÁXIMAS SUGERIDAS





ASSEMBLY RECOMMENDATIONS

RECOMENDACIONES DE ENSAMBLE

Two people are recommended to assemble the product.


Ensamble el mueble entre dos personas.


Assemble the cabinet on a flat, smooth surface, preferably on a carpeted floor or the carton box of the product.


Ensamble el mueble sobre una superficie plana y lisa, preferiblemente sobre un tapete o el cartón de la caja

Carefully read the assembly instructions and identify every wood and hardware part before start assemblying the cabinet.


Lea cuidadosamente las instrucciones e identifique todas las piezas y herrajes antes de empezar a armar el mueble.











4




















Page 12



Page 13








18

Rotate to tighten.


Gire para apretar.





H


19



Be careful turning over the cabinet. Tenga cuidado al voltear el mueble.




Fixing the cabinet to the wall Instalación del mueble a la pared





*Floor / Piso



After you finish the adjustment of the cams, cover them with the cover caps.

Después de ajustar todas las cajas minifix, cúbralas con las tapas adhesivas.



After you finish assembling the cabinet, take off the adhesive letters.

Al terminar de armar, desprenda las letras adhesivas.

WARRANTY POLICY PÓLIZA DE GARANTÍA

Furniture has a 1 year warranty coverage in wooden parts and hardware pieces since its manufacturing date, which you can see in the lot number printed on the product box and the assembly instructions leaflet.

Warranty covers materials and workmanship imperfections which impair the assembly or correct functioning of the cabinet.

This warranty is not valid if the defects or imperfections are caused by the incorrect following of the assembly instructions, warnings and recommendations, misuse, intentional damage, fire or flood, or after modifications or any kind of alteration, or repaired by someone not authorized, when it's been assembled 3 months after the date of purchase. These defects MUST be reported before the warranty coverage period ends. Once the product has been assembled, the company will not be responsible for defective and/or damaged parts.

This warranty is ONLY valid for the ORIGINAL PURCHASER, it doesn't apply if the product has been resold, rented, etc.

Furniture will take no liability for incidental or consequential damages caused to or by the product (This may not apply in your state).

To make this warranty valid you must write to our customer service email describing the product defect, lot number and submitting your sales reciept or proof of purchase, or contact us at our customer service line. Replaced parts will be under the products original warranty coverage period. Damaged parts will become property of the company.

There are no other warranties applicable to this product.