

ULTRALOOP®-ULT-MVP-2

TWO CHANNEL MULTIVOLTAGE VEHICLE LOOP DETECTOR

The ULTRALOOP® two channel multi-voltage vehicle loop detector combines small size with a 12VDC to 240VAC input range.

- 2 channels with AB logic
- ULTRAMETER™ sensitivity display - easy set-up and installation by selecting the correct sensitivity
- Crosstalk and RFI interference display - easy identification of interference problems
- Small size - fits into small operator housings, saving space (73 x 38 x 78mm)
- 10 sensitivity settings - gives the user the ability to select the best sensitivity level
- Low current draw - green product
- **DETECT-ON-STOP™** or (DOS®) feature will allow detection only when a vehicle has come to a complete stop on the loop. This EMX exclusive feature is a major advantage if you want to ignore cross traffic in tight spaces.

The ULT-MVP-2 provides relay contact outputs indicating vehicle presence, pulse, AB logic (directional mode) or the new EMX feature, Detect-On-Stop™ (DOS®) for each channel. The ULT-MVP-2 features automatic sensitivity boost (ASB) and infinite or normal (5 min.) presence.

The detector is easily installed and has user-friendly features that simplify set-up, operation and troubleshooting. Sensitivity selection is simplified by the ULTRAMETER™ display that indicates the appropriate sensitivity setting with the vehicle positioned on the loop. The 10 sensitivity settings allow for finer adjustment of the detection level, while the 4 frequency selections provide greater flexibility in preventing crosstalk in multi-loop applications.

ULT-MVP-2



Model Table

FEATURE	ULT-MVP-2
Presence/pulse output	•
AB logic	•
Detect-On-Stop	•
ABS	•
Normal/infinite presence	•

DESCRIPTION	US Wiring	European Wiring
	ULT-MVP-2U	ULT-MVP-2E
Power	1	1
Power	2	2
Channel 1 loop	7	3
Channel 1 loop	8	4
Channel 2 loop	10	5
Channel 2 loop	11	6
Channel 2 NO contact	3	7
Channel 2 common contact	9	8
Ground	4	9
Channel 1 NO contact	6	10
Channel 1 common contact	5	11



HAR-11



LD-11



PR-XX



ULT-MVP-2

Technical Data

Sensitivity	10 levels, 0-9
ULTRAMETER™ Display	Indicates optimum sensitivity level, 0-9 Diagnostic aid
Loop Frequency	4 settings (low, med-low, med-hi, high)
Loop Inductance	20...2000μH (Q factor > 5)
Grounded Loop	Isolation transformer allows operation with poor quality loops
Automatic Tuning	Detector tunes to loop on power-up and following frequency count function
Environmental Tracking	Automatic compensation
Surge Protection	Loop circuitry protected by surge suppressors
Channel 1 Relay	SPST relay contacts (form A)
Channel 2 Relay	SPST relay contacts (form A)
Contact Rating (Resistive Load)	2A @ 30VDC, 0.5A @ 125VAC
Detect / Channels 1 and 2	Red LED
Detect-On-Stop™	Requires vehicle to stop for a minimum of 1 second (1-2s typical)
ASB (Automatic Sensitivity Boost)	Increases sensitivity after initial detection to prevent dropout due to high-bed vehicles
Power	12...60 VDC (Max. 1.0 VA) 12...240 VAC (48...62Hz) (Max. 2 VA)
Operating Current	37mA standby / 55mA detect
Operating Temperature	-40°C...82°C (-40°F...180°F) 0...95% relative humidity
Dimensions (L x W x H)	73mm (2.9") x 38mm (1.2") x 78mm (3.1")
Weight	0.25 lbs. (113 g)
Housing	ABS plastic, IP30
Connections	Socket mount - 11 pin male (JEDEC B11-88)

Ordering Information

- ULT-MVP-2U Ultra MVP Multi-Voltage Vehicle Loop Detector, dual channel AC/DC, US wiring
- ULT-MVP-2E Ultra MVP Multi-Voltage Vehicle Loop Detector, dual channel AC/DC, EU wiring
- HAR-11 3 foot 11 pin harness
- LD-11 11 pin socket base DIN rail mount
- PR-XX EMX Lite Preformed Loop (XX- specify size)

WARRANTY EMX INC. the product described herein for a period of 2 years under normal use and service from the date of sale to our customer. The product will be free from defects in material and workmanship. This warranty does not cover ordinary wear and tear, abuse, misuse, overloading, altered products, or damage caused by the purchaser from incorrect connections, or lightning damage. There is no warranty of merchantability. There are no warranties expressed, implied or any affirmation of fact or representation which extend beyond the description set forth herein. EMX Inc. sole responsibility and liability, and purchaser's exclusive remedy shall be limited to the repair or replacement at EMX's option of a part or parts not so conforming to the warranty. In no event shall EMX Inc. be liable for damages of any nature, including incidental or consequential damages, including but, not limited to any damages resulting from non-conformity defect in material or workmanship. Rev 1.3 02/17/2020

