


SINGLE PHASE WIRING DIAGRAM

NOT FOR RESIDENTIAL USE




WARNING: FOR CONTINUED PROTECTION AGAINST FIRE, REPLACE FUSES ONLY WITH THE SAME TYPE AND RATING



THREE PHASE WIRING DIAGRAM


NOT FOR RESIDENTIAL USE




THREE PHASE WIRING DIAGRAM

TROUBLESHOOTING LED's

STB ENABLE	ON = STB ENABLED	OFF = STB DISABLED
+ 24 VOLTS DC	ON = POWER AVAILABLE	OFF = CHECK AC POWER SUPPLY. CHECK FUSES




EXTERNAL WIRING DIAGRAM



P/N 111281.0001



575 VOLT PHASE WIRING DIAGRAM




WARNING: FOR CONTINUED PROTECTION AGAINST FIRE, REPLACE FUSES ONLY WITH THE SAME TYPE AND RATING




575 VOLT PHASE WIRING DIAGRAM

TROUBLESHOOTING LED's

STB ENABLE	ON = STB ENABLED	OFF = STB DISABLED
+ 24 VOLTS DC	ON = POWER AVAILABLE	OFF = CHECK AC POWER SUPPLY. CHECK FUSES



EXTERNAL WIRING DIAGRAM



P/N 111379.0001

