





INTENDED USE


The De Novo® Deluxe Self-Cleaning Lint Brush is intended to be used on all fabric surfaces, not including leather, to help remove lint and hair from the fabric.

SPECIFICATIONS


Material: ABS + PP + PE | Color: White, Green, Red | Weight: 1 lb | Dimensions: 34.1 x 9.3 x 9.3cm



While holding the base firmly, pull the brush straight out of the base. Do not twist the handle.



Hold the brush so that the straight side is facing up and the curved side is facing down.




Swipe the brush along the surface you want to clean in a downward direction only.



To clean your brush when it is full of hair or lint, insert the brush back into the base and pull it back out. Repeat this until your brush is clean.



Take the brush out of the base. While holding the base, twist the lid so that its ridges align with the openings in the base, and pull the bottom lid off.




With both rims removed, pull the two mid-sections apart. This will expose the micro bristles inside.



While holding both mid-sections together, reattach the top rim by pushing it back on.



Dispose of the hair or lint that has collected inside the lint brush and on the bottom lid.



Remove and dispose of any hair or lint that remains on the microbristles.



To reattach the bottom lid, align the small ridges of the lid with the openings in the base. Push the lid and the base together and then twist to lock the lid in place.



While holding the base firmly pull the top rim off with one straight motion.



To reassemble, hold both midsections together so that they align and push them together.



Insert the brush back into the top of the base.