

little tikes

633072M
632433M

XIM632433-1R1 - 8/22

www.littletikes.com

www.littletikes.co.uk

www.littletikes.nl

www.littletikes.pl

US:
THE LITTLE TIKES COMPANY
2180 BARLOW ROAD, HUDSON, OH 44236



UK:
MGA ENTERTAINMENT UK LTD.
50 PRESLEY WAY, MILTON KEYNES, MK8 0ES, UK

AU:
MGA ENTERTAINMENT AUSTRALIA PTY LTD.
SUITE 2.02, 32 DELHI ROAD, MACQUARIA PARK NSW
2113, AU.

FR, ES, DE, NL, IT, PT:
MGA ENTERTAINMENT (Netherlands) B.V.
BARONIE 68-70, 2404XG ALPHEN A/D RIJN, ND.

PL:
MGA ENTERTAINMENT POLAND SP. Z.O.O.
ARTURA GROTTGERA 15 A, 76-200 SŁUPSK, PL.



ENGLISH

FOLD 'N STORE PICNIC TABLE

Ages: 2 - 8 years

Please save sales receipt for proof of purchase.

⚠ WARNING:

ADULT ASSEMBLY REQUIRED.


- Keep these instructions for future reference.
- Failure to follow all warnings and instructions could result in serious injury.
- Prior to assembly, this package contains small parts: hardware which is a choking hazard and may contain sharp edges and sharp points. Keep away from children until assembled.
- Adult supervision required. Do not leave children unattended.
- Place this product on level ground and at least 6' (2 m) away from a fence, building, overhead branches, laundry lines or electrical wires.
- Use this product on a firm, level surface and avoid using near swimming pools, on or near steps, hills or inclines.
- Do not allow children to sit, stand, play or climb on the top surface. Failure to do so may cause the product to become unstable.
- This product is intended for use by children ages 2 - 8 years.
- When temperatures fall below 0°F/-18°C, outdoor use of this product is not recommended. In extreme cold, plastic materials lose resilience and may become brittle and crack upon impact. Store product in a warmer, protected place.
- Components should be regularly checked for wear or breakage. Failure to do so may cause the product to fail.
- Limit 8 children.

ASSEMBLY HINTS

- Assemble legs to seats using a table top or other large work surface, then move to floor to finish assembly.



YouTube



EN Adult assembly required. Approximate assembly time: 20 minutes.

FR Assemblage par un adulte requis. Temps de montage estimé : 20 minutes

ES El montaje debe ser realizado por un adulto.

Tiempo aproximado de montaje: 20 minutos

DE Zusammenbau muss durch Erwachsene erfolgen. Ungefähre Montagezeit: 20 Minuten

PL Montaż powinna wykonać osoba dorosła.

Przybliżony czas montażu: 20 minut

NL Montage door volwassene is vereist. Geschatte montagemtijd: 20 minuten.

IT L'assemblaggio deve essere eseguito da un adulto.

Tempo approssimativo di assemblaggio: 20 minuti.

PT Deve ser montado por um adulto. Tempo aproximado de montagem: 20 minutos.

EN Tools required (not included)

FR Outils Requis (non compris)

ES Herramientas Requeridas (no incluidas)



DE Erforderliches Werkzeug (nicht enthalten)

PL Niezbędne narzędzia (nie są objęte zestawem)

RU Бенедигдн гереэдшчп (нлет инбегрен)

IT Strumenti richiesti (non inclusi)

PT Ferramentas necessárias (não incluídas)



7/16" (6.35 mm)


(L x24) 1 3/4" (4.44 cm)



(D x16) 2 1/4" (5.71 cm)



(M x4) 2" (5.08 cm)



E x16



F x16



J x4

CUSTOMER SERVICE

United States:

www.littletikes.com

1-800-321-0183 Monday - Friday

Little Tikes Consumer Service

2180 Barlow Road, Hudson, OH 44236

FRANÇAIS

TABLE DE PIQUE NIQUE PLIABLE ET RANGEABLE

Age : 2 à 8 ans







Prière de conserver le reçu comme preuve d'achat.

⚠ ATTENTION :

UN ADULTE DOIT EFFECTUER L'ASSEMBLAGE.

- Conserver ces instructions à titre de référence.
- Le non respect des avertissements et des instructions peut résulter en blessures graves.
- Avant l'assemblage du produit, ce paquet contient des petites pièces de matériel qui peuvent présenter un risque d'étouffement, et des bords et des arrondis tranchants. Tenir hors de portée des enfants avant l'assemblage complet.
- La surveillance par un adulte est recommandée. Ne laisser jamais un enfant sans surveillance.
- Placer ce produit en terrain plat et à plus de 2 m de toute clôture, corde à linge, immeuble, branche basse ou fil métallique.
- Ce produit doit être utilisé sur une surface nivelée et solide. Dans la mesure du possible, ne l'utilisez pas près d'une piscine, sur des marches, des collines ou des surfaces inclinées ou à proximité de ces dernières.
- Ne laissez pas les enfants grimper, s'asseoir, jouer ou se mettre debout sur la surface de la table. De tels comportements peuvent rendre la table instable.
- Cet appareillage ne peut être utilisé que par des enfants âgés de 2 à 8 ans.
- Ne peut être utilisé qu'avec les accessoires fournis.
- Les composants doivent être vérifiés régulièrement afin de détecter toute usure ou cassure. Tout manquement à cette consigne peut provoquer la défaillance du produit.
- Limité à 8 enfants.

Please keep this manual as it contains important information.



Illus. 2-10: To assemble legs to seats, make sure leg is hanging straight down, as shown. Hold plate and seat in place with your hand, and hold the hex nut from underneath with your finger. Loosely tighten bolt #1 first, then install bolt #2. Continue on all bolts and nuts until all 4 legs are loosely in place.

