


MY FIRST MIGHTY BLASTERS™ SLING BLASTER



AGES 3+ YEARS
SKU: 656231
ADULT SUPERVISION REQUIRED


CONTENTS

- A. 1 Sling Blaster
- B. 2 Power Pods




Illustrations are for reference only. Styles may vary from actual contents.
Please remove all packaging including tags, ties & tacking stitches before giving this product to a child.


QUICK START



Before beginning, make sure the sling handle is on the hook. Then, hold the Sling Blaster in an upright position and place a Power Pod on the fork of the Blaster.



After loading a Power Pod, place one hand on the handle under the fork. With your other hand, pull it back, aim and release to launch it!
NOTE: When pulling the sling back, do not go beyond the hook, as it might get stuck on the hook when releasing.



Store the Power Pods in the slots on the sides of the Blaster.

PRO TIPS

- For the perfect shot, make sure to pull the sling handle straight and directly behind the Power Pod (Fig. 1).
- To keep the sling handle out of the way while loading a new Power Pod, make sure to store it on the hook (Fig. 2).
- While playing and moving around, keep the sling handle on the hook, but make sure to remove it after playing. Do not store the Sling Blaster with the sling on the hook to avoid damaging the elastic string.




FIG. 1




FIG. 2

MONSTER TARGET

Pop out the monster on the box. Then fold the sides so it can stand.
Place in an area away from fragile objects, and use it as a target.



IMPORTANT INFORMATION

- Before playing, make sure the area is open and free of obstacles.
- Never launch the Power Pods at anyone's eyes or face.
- **Never place hands or fingers in between the sling handle and the Power Pod while launching.**
- Only use Power Pods with this product. Never use other objects.
- After loading the Sling Blaster, keep it in an upright position so the Power Pod doesn't fall out.

LIMITED WARRANTY

The Little Tikes Company makes fun, high quality toys. We warrant to the original purchaser that this product is free of defects in materials or workmanship for one year * from the date of purchase (dated sales receipt is required for proof of purchase). At the sole election of The Little Tikes Company, the only remedies available under this warranty will be the replacement of the defective part or replacement of the product. This warranty is valid only if the product has been assembled and maintained per the instructions. This warranty does not cover abuse, accident, cosmetic issues such as fading or scratches from normal wear, or any other cause not arising from defects in material and workmanship. *The warranty period is three (3) months for daycare or commercial purchasers.

U.S.A and Canada: For warranty service or replacement part information, please visit our website at www.littletikes.com, call 1-800-321-0183 or write to: Consumer Service, The Little Tikes Company, 2180 Barlow Road, Hudson OH 44236, U.S.A. Some replacement parts may be available for purchase after warranty expires—contact us for details.

Outside U.S.A and Canada: Contact place of purchase for warranty service. This warranty gives you specific legal rights, and you may also have other rights, which vary from country/state to country/state. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Please keep this manual as it contains important information.



© The Little Tikes Company, an MGA Entertainment company.
LITTLE TIKES® is a trademark of Little Tikes in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of Little Tikes.

Printed in China • 0920-0-E/INT



www.littletikes.com
www.littletikes.co.uk
www.littletikes.com.au

Little Tikes Consumer Service
2180 Barlow Road
Hudson, Ohio 44236 U.S.A.
1-800-321-0183

MGA Entertainment UK Ltd.
50 Presley Way, Crownhill, Milton
Keynes, MK8 0ES, Bucks, UK
support@LittleTikesStore.co.uk
Tel: +0 800 521 558

MGA Entertainment (Netherlands) B.V.
Baronie 68-70, 2404 XG Alphen a/d Rijn,
The Netherlands
Tel: +31 (0) 172 758038
E-mail: klantenservice@mgae.com

**Imported by MGA Entertainment
Australia Pty Ltd**
Suite 2.02, 32 Delhi Road
Macquarie Park NSW 2113
1300 059 676