




Totally Huge Sports™ T-Ball

SKU: 659904C3

AGES 18+ MONTHS
ADULT SUPERVISION REQUIRED
ADULT ASSEMBLY REQUIRED

CONTENTS

- A. Inflatable Baseball Bat
- B. Bat Handle
- C. Base
- D. Tee
- E. Inflatable Baseball
- F. Patch Kit




Illustrations are for reference only. Styles may vary from actual contents.
Please remove all packaging including tags and tacking stitches before giving this product to a child.

BASEBALL BAT


Inflate:

1. Locate the valve on the inflatable baseball bat.
2. Fill halfway with air (Fig. 1). NOTE: Filling more than half of the inflatable baseball bat will make the following steps difficult to complete.
3. Place bat handle in the opening of the inflatable baseball bat, making sure the threaded end goes in first (Fig. 2).
4. Once the threaded end has been gently pushed in all the way, turn bat handle clockwise until tight (Fig. 3).
5. Finish inflating the inflatable baseball bat until firm and secure nozzle (Fig. 4). NOTE: Do not over-inflate. Completely inflating your barrel should take approximately 2-3 minutes to complete.




BASEBALL TEE

1. Place base on the ground.
2. Place the tee's threaded end into the opening of the base (Fig. 1).
3. Once the threaded end has been gently pushed in as far as it can go, turn the tee clockwise until it is secure (Fig. 2). NOTE: Ensure the tee is on tight before allowing a child to play with this toy.



BASEBALL

1. Locate the valve on the ball.
2. Fill with air until firm and secure nozzle.
NOTE: Do not over-inflate.



LET'S PLAY SOME BASEBALL!

Place the ball on the top of the tee to play (Fig. 1). Be sure to place tee a good distance from the player's body before swinging the bat towards the ball (Fig. 2).




FIG. 1




FIG. 2

⚠ WARNING

This is not a lifesaving device and is not to be used in or near water. It is not an aquatic toy. Do not leave children unattended. Adult assembly required.

IMPORTANT INFORMATION

- DO NOT use devices with a compressor to inflate, as it may burst the toy.
- Secure the valve before giving this toy to a child.
- To avoid tipping over, use product on a flat, level surface.
- Ensure the play area is clear of any obstructions and sharp objects to avoid injury to the person or damage to the product.
- Do not use in windy conditions.
- Do not expose to extreme temperatures. Always store indoors and out of direct sunlight when not in use.
- Wipe product with a soft, clean cloth and mild soap. Do not use abrasive cleaners.
- Only one (1) hitter at a time should play with this unit.

LIMITED WARRANTY

The Little Tikes Company makes fun, high quality toys. We warrant to the original purchaser that this product is free of defects in materials or workmanship for 90 days * from the date of purchase (dated sales receipt is required for proof of purchase). At the sole election of The Little Tikes Company, the only remedies available under this warranty will be the replacement of the defective part or replacement of the product. This warranty is valid only if the product has been assembled and maintained per the instructions. This warranty does not cover abuse, accident, cosmetic issues such as fading or scratches from normal wear, or any other cause not arising from defects in material and workmanship. *The warranty period is three (3) months for daycare or commercial purchasers. U.S.A and Canada: For warranty service or replacement part information, please visit our website at www.littletikes.com, call 1-800-321-0183 or write to: Consumer Service, The Little Tikes Company, 2180 Barlow Road, Hudson OH 44236, U.S.A. Some replacement parts may be available for purchase after warranty expires—contact us for details. Outside U.S.A and Canada: Contact place of purchase for warranty service. This warranty gives you specific legal rights, and you may also have other rights, which vary from country/state to country/state. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Please keep this manual as it contains important information.



© The Little Tikes Company, an MGA Entertainment company.
LITTLE TIKES® is a trademark of Little Tikes in the U.S. and other countries.
All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of Little Tikes.

Printed in China
0821-0-C3



www.littletikes.com
www.littletikes.co.uk
www.littletikes.com.au

Little Tikes Consumer Service
2180 Barlow Road
Hudson, Ohio 44236 U.S.A.
1-800-321-0183

MGA Entertainment UK Ltd.
50 Presley Way, Crownhill, Milton
Keynes, MK8 0ES, Bucks, UK
support@LittleTikesStore.co.uk
Tel: +0 800 521 558

MGA Entertainment (Netherlands) B.V.
Baronie 68-70, 2404 XG Alphen a/d Rijn
The Netherlands
Tel: +31 (0) 172 758038

**Imported by MGA Entertainment
Australia Pty Ltd**
Suite 2.02, 32 Delhi Road
Macquarie Park NSW 2113
1300 059 676