




Totally Huge Sports™ Football





SKU: 659928C3

AGES 2+ YEARS
ADULT SUPERVISION REQUIRED
ADULT ASSEMBLY REQUIRED

- A. Inflatable Goal Post
- B. Foot Pump
- C. 4 Stakes
- D. Inflatable Football
- E. Tee
- F. Patch Kit



CONTENTS





Illustrations are for reference only. Styles may vary from actual contents.
Please remove all packaging including tags and tacking stitches before giving this product to a child.

SETTING UP YOUR GOAL POST AND FOOTBALL

Inflate:



1. Locate the first valve on the backside of the goal bottom base.
 2. Insert the pump's nozzle into the valve. NOTE: The pump's hose should be connected to the blue nozzle of the pump to inflate.
 3. Press down on pump pedal repeatedly using your foot to inflate goal post base.
 4. Once the base is inflated, secure the nozzle.
 5. Repeat the process on the center post, the horizontal bar of the goal post and the football.
- NOTE: Do not over-inflate. Completely inflating your goal post should take approximately 15 minutes to complete.



BACK SIDE



Deflate:

1. Locate the valve on the horizontal bar of the goal post.
2. Insert the pump's nozzle into the valve. NOTE: The pump's hose should be connected to the red nozzle of the pump to deflate.
3. Press down on pump pedal repeatedly using your foot to deflate goal post's center bar.
4. Once the goal post is deflated, secure the nozzle.
5. Repeat the process for the center post, the bottom base and the football.



OUTDOOR PLAY

1. Locate the tags on the bottom base.
2. Place the stake tip through the hole of the goal bottom base's tag. Use appropriate force to secure into the ground.
3. Repeat this process for the three remaining tags (four in total).



BACK SIDE

LET'S PLAY SOME FOOTBALL!

Use the included tee to hold your ball in place when practicing field goals. Place the tee at a good distance from the front side of the goal post (Fig. 1). Then place your ball on the stand with one end in the opening, allowing the ball to stand upright (Fig. 2).




FIG. 1




FIG. 2

⚠ WARNING

This is not a lifesaving device and is not to be used in or near water. It is not an aquatic toy. Do not leave children unattended. Adult assembly required.

IMPORTANT INFORMATION

- Only use the included pump to inflate the toy. DO NOT use other devices with a compressor as it may burst the toy.
- Remove the pump and secure the valve before giving this toy to a child.
- To avoid tipping over, use product on a flat, level surface.
- Ensure the play area is clear of any obstructions and sharp objects to avoid injury to the person or damage to the product.
- Stakes are meant to be used outdoors on soft ground.
- Do not use in windy conditions.
- Do not expose to extreme temperatures. Always store indoors and out of direct sunlight when not in use.
- Wipe product with a soft, clean cloth and mild soap. Do not use abrasive cleaners.

LIMITED WARRANTY

The Little Tikes Company makes fun, high quality toys. We warrant to the original purchaser that this product is free of defects in materials or workmanship for 90 days * from the date of purchase (dated sales receipt is required for proof of purchase). At the sole election of The Little Tikes Company, the only remedies available under this warranty will be the replacement of the defective part or replacement of the product. This warranty is valid only if the product has been assembled and maintained per the instructions. This warranty does not cover abuse, accident, cosmetic issues such as fading or scratches from normal wear, or any other cause not arising from defects in material and workmanship. *The warranty period is three (3) months for daycare or commercial purchasers. U.S.A and Canada: For warranty service or replacement part information, please visit our website at www.littletikes.com, call 1-800-321-0183 or write to: Consumer Service, The Little Tikes Company, 2180 Barlow Road, Hudson OH 44236, U.S.A. Some replacement parts may be available for purchase after warranty expires—contact us for details. Outside U.S.A and Canada: Contact place of purchase for warranty service. This warranty gives you specific legal rights, and you may also have other rights, which vary from country/state to country/state. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Please keep this manual as it contains important information.



© The Little Tikes Company, an MGA Entertainment company.
LITTLE TIKES® is a trademark of Little Tikes in the U.S. and other countries.
All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of Little Tikes.

Printed in China
0821-0-C3



www.littletikes.com
www.littletikes.co.uk
www.littletikes.com.au

Little Tikes Consumer Service
2180 Barlow Road
Hudson, Ohio 44236 U.S.A.
1-800-321-0183

MGA Entertainment UK Ltd.
50 Presley Way, Crownhill, Milton
Keynes, MK8 0ES, Bucks, UK
support@LittleTikesStore.co.uk
Tel: +0 800 521 558

MGA Entertainment (Netherlands) B.V.
Baronie 68-70, 2404 XG Alphen a/d Rijn
The Netherlands
Tel: +31 (0) 172 758038

Imported by MGA Entertainment Australia Pty Ltd
Suite 2.02, 32 Delhi Road
Macquarie Park NSW 2113
1300 059 676