EICHHOLTZ 3-E

Assembly instruction

117569 (117569A + 117569B) Coffee Table Bergman

Attention! Place the item on a padded area to prevent damage to the item. Care instructions: Dust regularly and clean with a soft dry cloth. Remove spills immediately to avoid staining and always use coasters.

