

C022-417-201
AVONDALE

ASSEMBLY INSTRUCTIONS


TWO (2) PEOPLE AND PHILIP WRENCH REQUIRED

PLEASE UNPACK ALL PARTS AND CHECK AGAINST PARTS LIST ON THIS INSTRUCTION SHEET BEFORE DISCARDING PACKING AND CARTON!!





- 1) Turn the Top / Apron Assembly (1) face down on a smooth, cleaning surface.
- 2) Attach the leg (3) to the Top / Apron Assembly (1) using flat washers (C), lock washers (B) and bolts (A) tighten by wrench provided (D) as shown in (Drawing A).
- 3) Using TWO (2) people carefully return the table to the upright position. Then place the leaves in the table as shown in (Drawing C).

***** NOTE KEEP THIS SHEET!!! *****

In the unlikely event that you would need a replacement part for your table, please contact your local authorized Schnadig International dealer. If you need replacement hardware quickly, it could be purchased from your local hardware store.



C022-417-201		
DINING TABLE		
Part Description	Part No.	QTY
Top / Apron Assembly (1)	C022-417-201-40123	1
Dining Table Leaf (2)	C022-417-201-4060	2
Dining Table Lock	C022-417-201-40150	6sets
Legs (3)	C022-417-201-4018	4
Metal Ferrule	C022-417-201-4006	4
RTA Hardware	C022-417-201-4001	1

NO.	Hardware List			Q'ty
A		Bolt	5/16"	8
B		Lock Washer	5/16"	8
C		Flat Washer	5/16"	8
D		Wrench	5/16"	1

