CLA-421-101-121H/F/R-141R INNER PASSION QUEEN/KING/CK BED CARACOLE CLASSIC

ASSEMBLY INSTRUCTIONS

TWO(2)PEOPLE AND PHILIP'S SCREWDRIVER REQUIRED

UNPACK ALL PARTS AND CHECK AGAINST PARTS LIST ON THIS INSTRUCTION SHEET BEFORE DISCARDING PACKING AND CARTON!!

1) Connect the side rails and headboard / footboard by bolt (F).

2) Assemble the side rails and headboard / footboard using the curved washer (A), flat washer (B), lock washer (C), and nut (D) tighten with wrench provided (E), as shown in Diagram A.

3) Attach the support legs to slats using flat washer (K), lock washer (L) and bolt (J), tighten by wrench provided (M). Adjust the support leg if necessary as shown in Diagram B.

4) Attach the adjustable slats system (H) to the side rails and locked to a needed position, using Philips screw drive to tighten the screw (G) if necessary. Attach the assembled slats & support leg to the adjustable slats system using bolt (N), tighten by wrench provided (R)

and (S). Using Philips screw drive to tighten the screw (G) if necessary as shown in Diagram C.

Note: Touch-up pen is provided for repair of minor issues resulting from transit, handling and normal use.

*** NOTE KEEP THIS SHEET !!! ***

In the unlikely event that you would need a replacement part for your furniture, please contact your local authorized Caracole International dealer. If you need replacement hardware quickly, it could be purchased from your local hardware store.

| | CLA-421-101H/F/R | | CLA-421-121H/F/R | | CLA-421-121H/F/1441R | |
|------------------|---------------------|-----|---------------------|-----|----------------------|-----|
| | QUEEN BED | | KING BED | | CAL KING BED | |
| Part Description | Part No. | QTY | Part No. | QTY | Part No. | QTY |
| Headboard (1) | CLA-421-101-H | 1 | CLA-421-121-H | 1 | CLA-421-121-H | 1 |
| Footboard (2) | CLA-421-101-F | 1 | CLA-421-121-F | 1 | CLA-421-121-F | 1 |
| Side rail (3) | CLA-421-101-R | 2 | CLA-421-101-R | 2 | CLA-421-1441-R | 2 |
| Slat (4) | CLA-421-101-F-3067 | 5 | CLA-421-121-F-3067 | 5 | CLA-421-121-F-3067 | 5 |
| Support leg(5) | CLA-421-101-F-30305 | 5 | CLA-421-121-F-30305 | 5 | CLA-421-121-F-30305 | 5 |
| RTA Hardware(6) | CLA-421-101-F-3001 | 1 | CLA-421-121-F-3001 | 1 | CLA-421-121-F-3001 | 1 |
| RTA Hardware(7) | CLA-421-101-R-3001 | 1 | CLA-421-101-R-3001 | 1 | CLA-421-1441-R-3001 | 1 |
| Touch -up Pen | CLA-421-011-30439 | 1 | CLA-421-011-30439 | 1 | CLA-421-011-30439 | 1 |

| RTA Hardware 7 for side rails | | | |
|-------------------------------|---------------|-------------------------|----|
| NO. | Hardware List | | |
| Α | Curved Washer | | 8 |
| в | ۲ | Flat Washer | 8 |
| С | 0 | Lock Washer | 8 |
| D | 9 | Nut | 8 |
| Е | ۳ ا | Wrench(5/16) | 1 |
| F | 1 | Bolt | 8 |
| G | <u> </u> | Screw(3.5x18) | 20 |
| н | ંજ | Adjustable slats system | 10 |
| | | | |

| | RTA Hardware (6) For Support leg and slat | | | |
|-----|-------------------------------------------|---------------|----|--|
| NO. | Hardware List Q'ty | | | |
| J | () | 10 | | |
| К | ٥ | Flat Washer | 10 | |
| L | 0 | Lock Washer | 10 | |
| М | l | Wrench | 1 | |
| Ν | | Bolt | 10 | |
| R | Γ | Wrench | 1 | |
| G | Dinm- | Screw(4.2x20) | 20 | |

