KHC-022-532 BOWIE TV CONSOLE HOUSE OF HOPPEN

ASSEMBLY INSTRUCTIONS

PLEASE UNPACK ALL PARTS AND CHECK AGAINST PARTS LIST ON THIS INSTRUCTION SHEET BEFORE DISCARDING PACKING AND CARTON!!

This is a set-up case and no assembly is required except for anti-tip restraint strap. (follow instruction for anti-tip restraint assembly)

*** NOTE KEEP THIS SHEET!!! ***

In the unlikely event that you would need a replacement part for your furniture, please contact your local authorized Caracole International dealer. If you need replacement hardware quickly, it could be purchased from your local hardware store.

	KHC-022-532		
	BOWIE TV CONSC	BOWIE TV CONSOLE	
Part Description	Part No.	QTY	
Soft-closing Guide	KHC-022-451-30424	2est	
Nail-in Floor Glide	KHC-022-412-2086	6	
Anti-tip Restraint	KHC-022-062-30157	1	

